# OUTLANDER AND OUTLANDER MAX 6X6(T CATEGORY MODELS)



# OPERATOR'S GUIDE

Includes Safety, Use and Maintenance Information

2025

## ⚠ WARNING

Read this operator's guide thoroughly. It contains important safety information.
Minimum recommended operator age: 16 or older.
Keep this operator's guide with the vehicle at all times.
The removal or modification of evaporative emission-related parts on this OHRV is illegal.
Violators may be subject to civil and/or criminal penalties under California and federal law.

219002435_REV1

Original Instruction

**⚠ WARNING**

**YOUR VEHICLE CAN BE HAZARDOUS TO OPERATE. A collision or roll-over can occur quickly, if you fail to take proper precautions, even during routine maneuvers such as turning and driving on hills or over obstacles. For your safety, understand and follow all the warnings contained in this operator's guide and on the labels on your vehicle. Failure to follow these warnings can result in SEVERE INJURY OR DEATH.**
**Keep this operator's guide with the vehicle at all times.**

**⚠ WARNING**

**Disregarding any of the safety precautions and instructions contained in the Operators's Guide, SAFETY VIDEO and on product safety labels could cause injury including the possibility of death.**

**⚠ WARNING**

**This vehicle may exceed the performance of other vehicles you may have ridden in the past. Take time to familiarize yourself with your new vehicle.**

™® Trademarks of BRP or its affiliates.
This is a non-exhaustive list of trademarks that are the property of Bombardier Recreational Products Inc. or its affiliates.
Trademarks may not be registered in every jurisdiction.

| | | | |
|---|---|---|---|
| Can-Am® | D.E.S.S.™ | DPS™ | Outlander™ |
| ROTAX® | TTI™ | XPS® | |

All rights reserved. No parts of this operator's guide may be reproduced in any form without the prior written permission of Bombardier Recreational Products Inc.
©Bombardier Recreational Products Inc. (BRP) 2024

| | |
|---|---|
| Deutsch | Dieses Handbuch ist möglicherweise in Ihrer Landessprache verfügbar. Bitte wenden Sie sich an Ihren Händler oder besuchen Sie: **www.operatorsguides.brp.com** |
| English | This guide may be available in your language. Check with your dealer or go to: **www.operatorsguides.brp.com** |
| Español | Es posible que este manual esté disponible en su idioma. Consulte a su distribuidor o visite: **www.operatorsguides.brp.com** |
| Français | Ce guide peut être disponible dans votre langue. Vérifier avec votre concessionnaire ou aller à: **www.operatorsguides.brp.com** |
| Italiano | Questa guida potrebbe essere disponibile nella propria lingua. Contattare il concessionario o consultare: **www.operatorsguides.brp.com** |
| 中文 | 本手册可能有您的语种的翻译版本。请向经销商问询，或者登录 www.operatorsguides.brp.com 查询。 |
| 日本語 | このガイドは、言語によって翻訳版が用意されています。. ディーラーに問い合わせるか、次のアドレスでご確認ください： **www.operatorsguides.brp.com** |
| Nederlands | Deze handleiding kan beschikbaar zijn in uw taal. Vraag het aan uw dealer of ga naar: **www.operatorsguides.brp.com** |
| Norsk | Denne boken kan finnes tilgjengelig på ditt eget språk. Kontakt din forhandler eller gå til: **www.operatorsguides.brp.com** |
| Português | Este manual pode estar disponível em seu idioma. Fale com sua concessionária ou visite o site: **www.operatorsguides.brp.com** |
| Русский | Воспользуйтесь руководством на вашем языке. Узнайте о его наличии у дилера или на странице по адресу **www.operatorsguides.brp.com** |
| Suomi | Käyttöohjekirja voi olla saatavissa omalla kielelläsi. Tarkista jälleenmyyjältä tai käy osoitteessa: **www.operatorsguides.brp.com** |
| Svenska | Denna bok kan finnas tillgänglig på ditt språk. Kontakta din återförsäljare eller gå till: **www.operatorsguides.brp.com** |

| Covered Models | |
|---|---|
| Outlander 650 XU+ | Outlander MAX 650 XU+ |
| Outlander 1000 XU+ | Outlander MAX 1000 XU+ |

In Canada, products are distributed and serviced by Bombardier Recreational Products Inc. (BRP).

In the USA, products are distributed and serviced by BRP US Inc.

In the European Economic Area (which is comprised of the member states of the European Union plus the United Kingdom, Norway, Iceland and Liechtenstein), the Commonwealth of the Independent States (including Ukraine and Turkmenistan) and Turkey, products are distributed and serviced by BRP European Distribution S.A. and other affiliates or subsidiaries of BRP.

For all other countries, products are distributed and serviced by Bombardier Recreational Products Inc. (BRP) or its affiliates.

# TABLE OF CONTENTS

## *GENERAL INFORMATION*

**GENERAL INFORMATION ..... 10**
Know Before you Go ..... 10
Safety Messages ..... 10
About this Operator's Guide ..... 11

## *SAFETY INFORMATION*

**GENERAL PRECAUTIONS ..... 14**
Avoid Carbon Monoxide Poisoning ..... 14
Avoid Gasoline Fires and Other Hazards ..... 14
Avoid Burns from Hot Parts ..... 14
Accessories and Modifications ..... 14
**SPECIAL SAFETY MESSAGES ..... 16**
2–UP Models – Driver's Responsibilities ..... 18
2–UP Models – Passenger's Responsibility ..... 18
**OPERATION WARNINGS ..... 19**
Passenger(s) to sit on Front Rack or In Rear Cargo Box ..... 23
Vehicle on Paved Surfaces ..... 24
**PRE-RIDE INSPECTION ..... 46**
Pre-Ride Inspection Check List ..... 46
**RIDING THE VEHICLE ..... 49**
Riding Gear ..... 50
Carrying a Passenger ..... 51
Recreational Riding ..... 52
Environment ..... 52
Design Limitation ..... 53
Off-Road Operation ..... 53
Riding Techniques ..... 53
**MOVING LOADS AND DOING WORK ..... 65**
Working with Your Vehicle ..... 65
Carrying Loads ..... 65
Loading the Cargo Racks ..... 66
Loading the Cargo Bed ..... 67
Operating While Carrying a Load ..... 67
Tilting the Cargo Bed ..... 68
Hauling a Load ..... 69
Pulling a Trailer ..... 70
**IMPORTANT ON-PRODUCT LABELS (COUNTRIES OUTSIDE CANADA AND UNITED STATES) ..... 72**
Safety Pictogram ..... 73

## *VEHICLE INFORMATION*

**PRIMARY CONTROLS ..... 92**
HANDLEBAR ..... 93
THROTTLE LEVER ..... 93
BRAKE LEVER ..... 93

BRAKE LOCK LEVER ..... 93
BRAKE PEDAL ..... 94
ENGINE STOP SWITCH ..... 94
RF D.E.S.S. KEY AND POST ..... 95
**SECONDARY CONTROLS ..... 96**
THROTTLE LEVER CONTROL HOUSING ..... 97
SHIFT LEVER ..... 100
MULTIFUNCTION SWITCH ..... 101
OPERATOR'S HEATED GRIPS (If Equipped) ..... 106
HEATED THROTTLE LEVER (If Equipped) ..... 106
INDICATOR LEDS ..... 107
**EQUIPMENT ..... 108**
OPERATOR'S SEAT ..... 108
PASSENGER'S SEAT ..... 108
GLOVE BOX ..... 109
FOOTPEGS ..... 110
12-VOLT POWER OUTLET ..... 111
CARGO RACKS ..... 111
GAUGE SUPPORT ..... 111
TOOL KIT ..... 111
WINCH (If Equipped) ..... 112
CARGO BED TILT RELEASE HANDLE ..... 112
REAR STORAGE COMPARTMENT ..... 113
RECOVERY HOOK ..... 114
CARGO BOX ANCHORING HOOKS ..... 114
REAR BOX SIDE WALL ..... 114
TRAILER HITCH ..... 117
TRAILER CONNECTOR ..... 117
LICENSE PLATE LIGHT ..... 118
**4.5” DIGITAL DISPLAY ..... 119**
MULTIFUNCTION DISPLAY ..... 119
Indicator Lamps ..... 120
SETTINGS ..... 121
**FUEL ..... 124**
Fuel Requirements ..... 124
Vehicle Fueling Procedure ..... 124
**BREAK-IN PERIOD ..... 126**
Operation During Break-In ..... 126
**BASIC PROCEDURES ..... 127**
Waking Up the Electrical System ..... 127
Starting the Engine ..... 127
Stopping the Engine ..... 127
Applying the Parking Brake ..... 128
Changing Gear Selection ..... 128
**SPECIAL PROCEDURES ..... 129**
Fuel Flooded Engine ..... 129
Water Into the CVT ..... 129
Water Into the Air Filter Housing ..... 129
Vehicle is Turned Over ..... 130
Vehicle is Immersed in Water ..... 130
**TUNE YOUR RIDE ..... 132**
Usage of Unlockable Stabilizer Bar ..... 132

Suspension Adjustment – Factory Settings ..... 132
Dynamic Power Steering (DPS) Assist Level Adjustment (Models with DPS) ..... 133
**LIFTING THE VEHICLE ..... 135**
General Safety Information for Lifting ..... 135
Lifting the Entire Vehicle ..... 135
**TRANSPORTING THE VEHICLE ..... 137**
Using Vehicle Power to Climb Onto Trailering Equipment ..... 138
Using a Winch to Pull Vehicle Onto Trailering Equipment ..... 138
Securing Vehicle for Transport ..... 139
Getting Vehicle Out of Trailer ..... 139

## *MAINTENANCE*

**MAINTENANCE SCHEDULE ..... 142**
Post Operation Care After Each Use in an Extreme Environment ..... 142
Severe Duty Conditions ..... 142
Deep Mud / Water Use ..... 143
Maintenance Schedule ..... 143
Maintenance Records ..... 154
**MAINTENANCE PROCEDURES ..... 159**
Resetting the Message: Maintenance Required ..... 159
ENGINE AIR FILTER ..... 159
CVT AIR FILTER ..... 162
ENGINE OIL ..... 163
ENGINE OIL FILTER ..... 165
EVAPORATIVE EMISSION SYSTEM FILTER ..... 166
FUEL VENT BREATHER FILTER ..... 166
RADIATOR ..... 167
ENGINE COOLANT ..... 167
EXHAUST SYSTEM ..... 170
GEARBOX ..... 172
SPARK PLUGS ..... 173
CVT COVER ..... 174
DRIVE BELT ..... 175
DRIVE AND DRIVEN PULLEYS ..... 177
BATTERY ..... 177
FUSES ..... 178
LIGHTS ..... 179
DRIVE SHAFT BELLOW AND PROTECTOR ..... 180
WHEEL BEARING ..... 180
WHEELS AND TIRES ..... 181
STEERING ..... 184
SUSPENSION ..... 184
BRAKES ..... 185
**VEHICLE CARE ..... 187**
Vehicle Cleaning and Protection ..... 187

**STORAGE AND PRESEASON PREPARATION** ..... **189**

## *TECHNICAL INFORMATION*

**INTENDED USE** ..... **192**
**VEHICLE IDENTIFICATION** ..... **193**
Vehicle Identification Number ..... 193
Engine Identification Number (EIN) ..... 194
Compliance Label ..... 195
Technical Information Labels ..... 197
**BRP RF DESS POST GEN3 (MOWP)** ..... **200**
USA and Canada ..... 200
Mexico ..... 201
Brazil ..... 201
Japan ..... 202
Europe ..... 202
**NOISE EMISSION AND VIBRATION VALUES** ..... **206**
**EC-DECLARATION OF CONFORMITY** ..... **207**
**UK-DECLARATION OF CONFORMITY** ..... **208**
**EAC DECLARATION OF CONFORMITY** ..... **209**

## *TECHNICAL SPECIFICATIONS*

**TECHNICAL SPECIFICATIONS** ..... **212**

## *PARTS CATALOG*

**ONLINE PARTS CATALOG** ..... **220**

## *TROUBLESHOOTING*

**TROUBLESHOOTING GUIDELINES** ..... **222**
Engine Does Not Turn ..... 222
Engine Turns Over But Fails To Start ..... 222
Engine Lacks Acceleration or Power ..... 223
Engine Overheats ..... 223
Engine Backfire ..... 224
Engine Misfire ..... 224
Vehicle Cannot Reach Full Speed ..... 224
Shift Lever Is Hard To Move ..... 225
The RPM Increases But The Vehicle Does Not Move ..... 225
Reduced Power Steering Assist ..... 225

**DIGITAL DISPLAY MESSAGES.....226**

## *WARRANTY*

**BRP LIMITED WARRANTY USA AND CANADA: 2025 CAN-AM® ATV..230**
**US EPA EMISSION - RELATED WARRANTY.....233**
**CALIFORNIA EVAPORATIVE EMISSIONS CONTROL WARRANTY STATEMENT.....236**
**BRP INTERNATIONAL LIMITED WARRANTY: 2025 CAN-AM® ATV ....239**
**BRP LIMITED WARRANTY FOR THE EUROPEAN ECONOMIC AREA, THE COMMONWEALTH OF THE INDEPENDENT STATES AND TURKEY: 2025 CAN-AM® ATV .....243**

## *CUSTOMER INFORMATION*

**DATA PRIVACY INFORMATION .....248**
**CONTACT US .....250**
Asia Pacific .....250
Europe, Middle East and Africa.....250
Latin America .....251
North America .....251
**CHANGE OF ADDRESS AND OWNERSHIP .....252**

This page is intentionally blank

# GENERAL INFORMATION

# GENERAL INFORMATION

Congratulations on your purchase of a new Can-Am® ATV vehicle. It's backed by the BRP limited warranty and a network of authorized Can-Am dealers ready to provide the parts, accessories or service you may require.

At delivery, you were informed of the warranty coverage and signed the Pre-delivery Check List to ensure your new vehicle was prepared to your entire satisfaction.

Your dealer is committed to your satisfaction. If you need more information, please ask your dealer.

## Know Before you Go

To learn how to reduce the risk of accident for you or bystanders, read this Operator's Guide before you operate the vehicle.

Also, read all safety labels on your vehicle and watch the *Safety Video* located at:

**https://can-am.brp.com/off-road/safety**

Or use the following QR code.

Failure to follow the warnings contained in this Operator's Guide can result in SERIOUS INJURY or DEATH.

### *Age Recommendation*

This vehicle is a category G, always follow this age recommendation:

– A person under 16 years old should never operate this vehicle.
– Passenger on 2–UP models must be capable of keeping his feet on the footrests and his hands on grab handles at all times when seated on this vehicle.

### *Training Course*

Never operate this vehicle without proper instruction. **Take a training course.** All operators should receive training from a certified instructor.

For more information about ATV safety, contact an authorized Can-Am Off-road dealer to find out about available training courses nearest you.

## Safety Messages

The types of safety messages, what they look like and how they are used in this guide are explained as follows:

The safety alert symbol ⚠ indicates a potential injury hazard.

**⚠ WARNING**

**Indicates a potential hazard which, if not avoided, could result in serious injury or death.**

**⚠ CAUTION**

**Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.**

***NOTICE***

**Indicates an instruction which, if not followed, could result in severely damaged vehicle components or other property.**

## About this Operator’s Guide

This Operator's Guide has been prepared to acquaint the owner/operator of a new vehicle with the various vehicle controls, maintenance and safe operating instructions. It is indispensable for the proper use of the product.

Keep this Operator's Guide in the vehicle as you can refer to it for things such as maintenance, troubleshooting and instructing others.

Note that this guide is available in several languages. In the event of any discrepancy, the English version shall prevail.

If you want to view and/or print an extra copy of your Operator's Guide, simply visit the following website:

**www.operatorsguides.brp.com**

The information contained in this document is correct at the time of publication. BRP, however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on products previously manufactured. Due to late changes, some differences between the manufactured product and the descriptions and/or specifications in this guide may occur. BRP reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring any obligation upon itself.

This Operator's Guide should remain with the vehicle when it is sold.

This page is intentionally blank

# SAFETY INFORMATION

# GENERAL PRECAUTIONS

## Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion and eventually death.

Carbon monoxide is a colorless, odorless, tasteless gas that may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly, and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air and seek medical treatment.

To prevent serious injury or death from carbon monoxide:

– Never run the vehicle in poorly ventilated or partially enclosed areas such as garages, carports or barns. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.
– Never run the vehicle outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

## Avoid Gasoline Fires and Other Hazards

Gasoline is extremely flammable and highly explosive. Fuel vapors can spread and be ignited by a spark or flame many feet away from the engine. To reduce the risk of fire or explosion, follow these instructions:

Gasoline is poisonous and can cause injury or death.

– Never siphon gasoline by mouth.
– If you swallow gasoline, get any in your eye(s), or inhale gasoline vapor, see your doctor immediately.
– If gasoline spills on you, wash with soap and water and change your clothes.

## Avoid Burns from Hot Parts

Certain components like brake rotors and exhaust components become hot during operation. Avoid contact with those parts during and shortly after operation to avoid burn wounds.

## Accessories and Modifications

Any modifications or addition of accessories approved by BRP may affect the handling of your vehicle. It is important to take the time to get familiar with the vehicle once modifications are made to understand how to adapt your driving behavior accordingly.

Avoid installing equipment not specifically approved by BRP for the vehicle and avoid unauthorized modifications. These modifications and equipment have not been tested by BRP and may create hazards. For example, they could:

– Create a loss of control and increase risk of crash.
– Cause overheating or short circuits increasing the risk of fire or burn injuries.
– Affect the protection features provided by the vehicle.
– Affect the behavior of the trailer when the vehicle is transported.

– Cause a risk of losing objects on the road when transported.

Your vehicle may also become illegal to ride.

See your authorized BRP dealer for available BRP accessories for your vehicle.

For safety reasons, some BRP accessories must be installed by a BRP dealer but if you decide to install the accessory by yourself, when not required to be done by the dealer, it is important to follow all the instructions carefully and, if applicable, understand all the information on how to use the product or for servicing.

If the accessory has been installed on your vehicle by another person than you, BRP strongly recommends you to read the corresponding instruction sheet as there may be more for information on how to use it safely or for the servicing.

The instruction sheets can be found at this address:

– *HTTPS://INSTRUCTIONS.BRP.COM*

# SPECIAL SAFETY MESSAGES

**THIS VEHICLE IS NOT A TOY AND CAN BE HAZARDOUS TO OPERATE.**

– This vehicle handles differently from other vehicles including motorcycles and cars. A collision or rollover can occur quickly, if you fail to take proper precautions, even during routine maneuvers such as turning and driving on hills or over obstacles.

**SEVERE INJURY OR DEATH** can result if you do not comply with the following instructions:

– Read this Operator's Guide and all on-product safety labels carefully and follow the operating procedures described. Watch and pay attention to the safety video before operating the vehicle.
– Always follow this age recommendation: A person under 16 years old should never operate this vehicle.
– Never take place on this vehicle without wearing an approved helmet of the proper size and other required riding gears. Refer to *RIDING GEAR* in *RIDING THE VEHICLE* for detailed information.
– Always inspect and confirm the safe operating condition of your vehicle prior to ride. Refer to *PRE-RIDE INSPECTION*. Always follow the maintenance schedules as described in this Operator's Guide. Refer to *MAINTENANCE*.
– On 1-UP models, do not make any modifications to accommodate a passenger or use racks to carry a passenger.
– Never carry a passenger on this vehicle unless you are operating a 2-UP model. Passenger(s) affect balance and steering and increase risk of losing control.
– Never operate this ATV after using drugs or alcohol, when tired or ill. This must be applied also to the passenger (if applicable). Your reaction time and judgement is greatly affected under these conditions. Always operate your ATV prudently.
– Never attempt wheelies, jumps, or other stunts.
– Never operate at excessive speeds. Always go at a speed that is proper for the terrain, visibility, and operating conditions, and your experience.
– Always go slowly and be extra careful when operating on unfamiliar terrain. Always be alert to changing terrain conditions when operating this vehicle.
– Never operate on excessively rough, slippery or loose terrain until you have learned and practiced the skills necessary to control this vehicle on such terrain. Always be especially cautious on these kinds of terrain.
– Always follow proper procedures for turning as described in *RIDING TECHNIQUES*.
– Never operate this vehicle on hills too steep for the vehicle or for your abilities.
– Always follow proper procedures for climbing hills as described in *RIDING TECHNIQUES*. Check the terrain carefully before you start up any hill. Never climb hills with excessively slippery or loose surfaces.
– Always follow proper procedures for going down hills and for braking on hills as described in *RIDING TECHNIQUES*. Check the terrain carefully before you start down any hill.
– Always follow proper procedures for crossing the side of a hill as described in *RIDING TECHNIQUES*. Avoid hills with excessively slippery or loose surfaces.
– Always use proper procedures if you stall or roll backwards when climbing a hill. To avoid stalling, use low gear and maintain a steady speed when

climbing a hill. If you stall or roll backwards, follow the driving technique procedures as described in *RIDING TECHNIQUES*.

- Always check for obstacles before operating in a new area. Never attempt to operate over large obstacles, such as large rocks or fallen trees. Always follow proper procedures when operating over obstacles as described in *RIDING TECHNIQUES*.
- Always be careful when skidding or sliding. Learn to safely control skidding or sliding by practicing at low speeds and on level smooth terrain. On extremely slippery surfaces, such as ice, go slowly and be very cautious in order to reduce the chance of skidding out of control. If you are operating a 2-UP model and have a passenger on-board, never attempt skidding or sliding; overturn or passenger ejection may occur.
- Always be sure there are no obstacles or people behind the vehicle when you operate in reverse. When it is safe to proceed in reverse, go slowly. Take into account that on a 2-UP model the passenger can obstruct your view.
- Never exceed the stated load limits for this vehicle including operator, passenger (2-UP models), all other loads and added accessories. Cargo should be properly distributed and securely attached. Reduce speed and follow instructions in this guide for carrying cargo or pulling a trailer. Allow greater distance for braking.
- This vehicle is not designed for jumping, nor can it fully absorb the high impact energy generated during manoeuvres such as jumping which, can be passed on to you, the operator. Performing wheelies can cause the vehicle to flip over onto you. Both practices have a high risk for you and your passenger (2-UP models) and should be avoided at all times.
- Never operate this vehicle through deep or fast flowing water. Water should never exceed the center of the wheels. Remember that wet brakes may have reduced stopping ability. Test your brakes after leaving water, mud or snow. If necessary, apply them several times to let friction dry out the pads.
- Always keep in mind that braking distance is readily affected by but not limited to; weather and terrain conditions, braking system and tire conditions, vehicle speed and attitude, and vehicle load including towing. Remember to adjust your driving accordingly.
- BRP recommends sitting on your ATV when operating in reverse. Avoid standing up. Your weight could shift forward against throttle lever, causing an unexpected acceleration and may lead to a loss of control.
- Never operate the vehicle if the controls do not function normally.
- Always maintain proper tire pressure. When replacing tires, use only the recommended tire size and type. For tire information, refer to *TECHNICAL SPECIFICATIONS* in this guide.
- Riding your vehicle too fast for your skills or the conditions may result in injury. Apply only enough throttle to proceed safely. Statistics show that mishaps and injury usually result from high speed turns. Always remember that this vehicle is heavy! Its pure weight alone may entrap you should it fall resulting in injury.
- Never modify this vehicle through improper installation or use of accessories. Only use BRP's approved accessories.
- Never exceed the stated load limits for this vehicle including operator, all other loads and added accessories. Cargo should be properly distributed and securely attached. Reduce speed and follow instructions in this manual for carrying cargo or pulling a trailer. Allow greater distance for braking.

## 2–UP Models – Driver’s Responsibilities

**Driver must:**

- Not forget is responsible for the safety of the passenger.
- Inform the passenger concerning the basic rules for a safe ride.
- Instruct the passenger to read the vehicle’s safety labels and to watch the *safety video*.
- Always practice the maneuvers described in this Operator's Guide without and with a passenger. Greater skills are required with a passenger.
- Always remember that the vehicle handling and stability may be affected when riding with a passenger. Safely reduce speed. Use proper judgement. If in doubt, do not attempt and disembark the passenger before executing any maneuver.
- Always remember that the vehicle braking distance may be longer when riding with a passenger. Allow greater distance for braking.
- Never carry passenger on a 2-UP model if the passenger seat is not properly installed.
- Never carry more than one (1) passenger. Do not allow passenger to sit anywhere else than the designated passenger's seat.
- Never carry a passenger if you judge his ability or judgement insufficient to concentrate on the terrain conditions and adapt accordingly.
- Never carry a passenger who has used drugs or alcohol, or is tired or ill. These slow reaction time and impair judgment.

## 2–UP Models – Passenger’s Responsibility

**Passenger must:**

- Be capable of resting his feet on the footrests and his hands on grab handles when seated on this vehicle.
- Never take place on this vehicle without wearing an approved helmet (including a chin guard) that fits properly. The passenger should also wear eye protection (goggles or face shield), gloves, boots, long sleeved shirt or jacket, and long pants.
- Be seated on the designated passenger's seat.
- Always keep hands on grab handles and feet on the footrests during operation. Never hold on to the operator.
- Never get up during vehicle operation. An excessive movement could cause loss of control.
- Pay attention to vehicle and operator movements.
- Don’t hesitate and tell the driver to slow down or stop if you feel uncomfortable or insecure for any reason.

# OPERATION WARNINGS

The following warning and their format have been requested by the United States Consumer Product Safety Commission and are required to be in the Operator's Guide for all ATVs.

The following illustrations are general representations only. Your model may differ.

## Operating Vehicle Without Proper Instruction

**⚠ WARNING**

**POTENTIAL HAZARD**
**Operating this vehicle without proper instruction.**
**WHAT CAN HAPPEN**
**The risk of an accident is greatly increased if the operator does not know how to operate this vehicle properly in different situations and on different types of terrain.**
**HOW TO AVOID THE HAZARD**
**Beginners and inexperienced operators should complete a training course. They should then regularly practice the skills learned during the course as well as the operating techniques described in this Operator's Guide.**
**For more information about a training course, contact an authorized Can--Am dealer.**

## Age Recommendations

**⚠ WARNING**

V00A1AQ

POTENTIAL HAZARD

**Failure to follow the age recommendations for this vehicle.**

WHAT CAN HAPPEN

**A lack of respect for this age recommendation can lead to severe injury or death of the child.**

**Even though a child may be within the age group for which this vehicle is recommended, he may not have the skills, abilities, or judgment needed to operate this vehicle safely and may be involved in a serious accident.**

HOW TO AVOID THE HAZARD

**No one under 16 should operate this vehicle.**

## Physical Limitations of the Passenger

**⚠ WARNING**

***2–UP Models***

**POTENTIAL HAZARD**
**Failure to respect the physical limitations of the passenger on 2-UP models.**
**WHAT CAN HAPPEN**
**A passenger that cannot completely lean his feet on footrests can be ejected when riding on uneven terrain.**
**HOW TO AVOID THE HAZARD**
**The passenger must be capable of keeping his feet on the footrests and his hands on grab handles at all times when he is seated on the vehicle.**

## Carrying More than one (1) Passenger

**⚠ WARNING**

**2-UP Models Only**

POTENTIAL HAZARD
**Carrying more than one (1) passenger on this vehicle.**
WHAT CAN HAPPEN
**Carrying more than one (1) passenger reduces your ability to balance and control this vehicle.**
**Could cause an accident, resulting in harm to you and/or your passengers.**
HOW TO AVOID THE HAZARD
**Never carry more than one (1) passenger. Even with a long seat that provides unrestricted operator movement, the vehicle is not designed nor intended to carry more than one (1) operator and one (1) passenger.**
**The passenger must use the designated passenger's seat when he is seated on the vehicle with feet firmly planted on footrests and always hold on to the grab handles.**

## Passenger(s) to sit on Front Rack or In Rear Cargo Box

**⚠ WARNING**

**POTENTIAL HAZARD**
**Allowing passenger(s) to sit on front rack or in the rear cargo box.**
**WHAT CAN HAPPEN**
**Allowing a passenger could:**

- **Impair vehicle stability which could lead to a loss of control.**
- **Result in injury to passenger(s) from impact on hard surfaces.**
- **Cause an accident, resulting in harm to you and/or your passenger(s).**

**HOW TO AVOID THE HAZARD**
**Never allow any passenger to sit on front rack or in the rear cargo box.**

## Vehicle on Paved Surfaces

**⚠ WARNING**

**POTENTIAL HAZARD**
**Operating this vehicle on paved surfaces.**
**WHAT CAN HAPPEN**
**The tires are designed for off-road use only, not for use on pavement. Paved surfaces may seriously affect handling and control of this vehicle, and may cause the vehicle to go out of control.**
**HOW TO AVOID THE HAZARD**
**If a road usage is allowed in your area, operate your vehicle on paved surfaces only for short distance and for the only purpose of moving the vehicle from an off-road usage to another.**
**Always operate your vehicle at low speed (never exceed 40 km/h (25 MPH) and reduce the speed before making a turn.**
**Always respect all road traffic laws when operating your vehicle on public roads or streets.**

## Riding Without Protective Gear

**⚠ WARNING**

POTENTIAL HAZARD

**Riding this vehicle without wearing an approved helmet, eye protection and protective gear. On 2-UP models, passenger should also have an approved helmet with a rigid chin guard.**

WHAT CAN HAPPEN

- **Riding without an approved helmet increases the chances of a severe head injury or death in the event of an accident.**
- **Riding without eye protection can result in an accident and increases the chances of a severe injury in the event of an accident.**
- **Riding without protective gear increases the chances of severe injury in the event of an accident.**

HOW TO AVOID THE HAZARD

**Always wear an approved helmet that fits properly. You should also wear:**

- **Eye protection (goggles or face shield)**
- **Rigid chin guard**
- **Gloves and boots**
- **Long sleeved shirt or jacket**
- **Long pants.**

## Drugs or Alcohol

**⚠ WARNING**

V00A07Q

**POTENTIAL HAZARD**
**Using this vehicle with drugs or alcohol.**
**WHAT CAN HAPPEN**
**Could cause the passenger to fall off (2-UP models).**
**Could seriously affect your judgment.**
**Could cause you to react more slowly.**
**Could affect your balance and perception.**
**Could result in an accident or death.**
**HOW TO AVOID THE HAZARD**
**The operator and the passenger (2-UP models) should never use this vehicle with drugs or alcohol.**

## Excessive Speeds

**⚠ WARNING**




V00A08Q

POTENTIAL HAZARD

**Operating this vehicle at excessive speeds.**

WHAT CAN HAPPEN

**Increases your chances of losing control of the vehicle, which can result in an accident.**

HOW TO AVOID THE HAZARD

**Always travel at a speed which is appropriate for the terrain, visibility and operating conditions, and your experience.**

**On 2-UP models, the vehicle handling, stability and braking distance may be affected when riding with a passenger. Safely reduce speed when riding with a passenger. Allow greater distance for braking.**

## Wheelies, Jumps and Other Stunts

**⚠ WARNING**

POTENTIAL HAZARD
**Attempting wheelies, jumps and other stunts.**
WHAT CAN HAPPEN
**Increases the chance of an accident, including an overturn.**
HOW TO AVOID THE HAZARD
**Never attempt stunts, such as wheelies or jumps. Do not try to show off.**

## Vehicle Inspection

**⚠ WARNING**

POTENTIAL HAZARD
**Failure to inspect the vehicle before operating.**
**Failure to properly maintain the vehicle.**
WHAT CAN HAPPEN
**Increases the possibility of an accident or equipment damage.**
HOW TO AVOID THE HAZARD
**Always inspect your vehicle prior to ride to make sure the vehicle is in safe operating condition.**
**Always follow the maintenance schedule described in this Operator's Guide.**

## Frozen Waterways

**⚠ WARNING**

POTENTIAL HAZARD
**Riding on frozen waterways.**
WHAT CAN HAPPEN
**Breaking through the ice can lead to severe injury or death.**
HOW TO AVOID THE HAZARD
**Never ride this vehicle on a frozen surface before you are sure the ice is thick enough and sound enough to support the vehicle and its load, as well as the force that is created by a moving vehicle.**

## Proper Position on the Vehicle

**⚠ WARNING**

POTENTIAL HAZARD
**Removing hands from handlebars for the operator and from grab handles for the passenger (2-UP models), or feet from the footrests during operation.**
WHAT CAN HAPPEN
**Removing even one hand or foot can reduce your ability to control the vehicle or could cause you to lose your balance and fall off the vehicle. If you remove a foot from the footrests, your foot or leg may come into contact with the rear wheels, which could injure you or cause an accident.**
HOW TO AVOID THE HAZARD
**Operator must always keep both hands on the handlebars and passenger (2-UP models) on grab handles. Both feet (operator and passenger on 2-UP models) must rest on the footrests during vehicle operation.**

## Unfamiliar Terrain

**⚠ WARNING**

**POTENTIAL HAZARD**
**Failure to use extra care when operating this vehicle on unfamiliar terrain.**
**WHAT CAN HAPPEN**
**You can come upon hidden rocks, bumps, or holes, without enough time to react.**
**Could result in the vehicle overturning, passenger ejection (2-UP models) or loss of control.**
**HOW TO AVOID THE HAZARD**
**Go slowly and be extra careful when operating on unfamiliar terrain.**
**Always be alert to changing terrain conditions when operating the vehicle.**
**Do not forget, on 2-UP models, the operator is responsible for the safety of his passenger. Safely reduce speed when riding with a passenger.**

## Operating on Excessively Rough, Slippery or Loose Terrain

**⚠ WARNING**

**POTENTIAL HAZARD**
**Failure to use extra care when operating on excessively rough, slippery or loose terrain.**
**WHAT CAN HAPPEN**
**Could cause loss of traction or vehicle control, which could result in an accident, including an overturn or passenger ejection (2-UP models).**
**HOW TO AVOID THE HAZARD**
**Do not operate on excessively rough, slippery or loose terrain until you have learned and practiced the skills necessary to control this vehicle on such terrain.**
**Always be especially cautious on these kinds of terrain.**
**Do not forget, on 2-UP models, the operator is responsible for the safety of the passenger. In doubt, disembark him before operating on these terrains.**

## Turning Improperly

**⚠ WARNING**

**POTENTIAL HAZARD**
**Turning improperly.**
**WHAT CAN HAPPEN**
**Vehicle could go out of control, causing a collision or an overturn or a passenger ejection (2-UP models).**
**HOW TO AVOID THE HAZARD**
**Always follow proper procedures for turning as described in this Operator's Guide. Practice turning at low speeds before attempting to turn at faster speeds.**
**Do not forget, on 2-UP models, the operator is responsible for the safety of the passenger. Never perform this maneuver with a passenger. Always remember that the vehicle handling, stability and braking distance may be affected when riding with a passenger.**
**Do not turn at excessive speed.**

## Excessively Steep Hills

**⚠ WARNING**

**POTENTIAL HAZARD**
**Operating on excessively steep hills.**
**WHAT CAN HAPPEN**
**The vehicle can overturn more easily on extremely steep hills than on level surfaces or small hills.**
**HOW TO AVOID THE HAZARD**
**Never operate this vehicle on hills too steep for the vehicle or for your abilities.**
**Practice, without and with passenger (2-UP models), on smaller hills before attempting larger hills.**
**Always remember that, on 2-UP models, even if this vehicle can climb some steep hills, it is not recommended to climb such hills with a passenger; always disembark him before attempting this maneuver. Show good judgement.**

## Climbing Hills

**⚠ WARNING**

**POTENTIAL HAZARD**
**Climbing hills improperly.**
**WHAT CAN HAPPEN**
**Could cause loss of control, passenger ejection (2-UP models) or cause vehicle to overturn.**
**HOW TO AVOID THE HAZARD**
**Always follow proper procedures for climbing hills as described in this Operator's Guide.**
**Always check the terrain carefully before you start up any hill. Do not forget, on 2-UP models, the operator is responsible for the safety of the passenger. In doubt, disembark him before climbing hill. Always remember that the vehicle handling, stability and braking distance may be affected when riding with a passenger.**
**Never climb hills with excessively slippery or loose surfaces.**
**Shift your weight forward (operator and passenger on 2-UP models).**
**Never open the throttle suddenly or make sudden gear changes. The vehicle could flip over backwards.**
**Never go over the top of any hill at high speed. An obstacle, a sharp drop, or another vehicle or person could be on the other side of the hill.**

## Down a Hill

**⚠ WARNING**

**POTENTIAL HAZARD**
**Going down a hill improperly.**
**WHAT CAN HAPPEN**
**Could cause loss of control, passenger ejection (2-UP models) or cause vehicle to overturn.**
**HOW TO AVOID THE HAZARD**
**Always follow proper procedures for going down hills as described in this Operator's Guide.**

**NOTE:**
**A special technique is required when braking as you go down a hill.**

**Always check the terrain carefully before you start down any hill. Do not forget, on 2-UP models, the operator is responsible for the safety of the passenger. In doubt, disembark him before going down hill. Always remember that the vehicle handling, stability and braking distance may be affected when riding with a passenger.**
**Shift your weight backward (operator and passenger on 2-UP models).**
**Never go down a hill at high speed.**
**Avoid going down a hill at an angle which would cause the vehicle to lean sharply to one side. Go straight down the hill where possible.**

## Crossing or Turning on Hills

**⚠ WARNING**

POTENTIAL HAZARD
**Improperly crossing hills or turning on hills.**
WHAT CAN HAPPEN
**Could cause loss of control, passenger ejection (2-UP models) or cause vehicle to overturn.**
HOW TO AVOID THE HAZARD
**Never attempt this maneuver on 2-UP models when the passenger is on board. Always disembark him before executing.**
**Never attempt to turn the vehicle around on any hill until you have mastered the turning technique as described in this Operator's Guide on level ground. Be very careful when turning on any hill.**
**Avoid crossing the side of a steep hill if possible.**
**When crossing the side of a hill:**
**Always follow proper procedures as described further in this Operator's Guide.**
**Avoid hills with excessively slippery or loose surfaces.**
**Operator and passenger (2-UP models) must shift weight to the uphill side of the vehicle.**

## Stalling, Rolling Backwards or Dismounting While Climbing a Hill

**⚠ WARNING**



POTENTIAL HAZARD
**Stalling, rolling backwards or improperly dismounting while climbing a hill.**
WHAT CAN HAPPEN
**Could result in vehicle overturning.**
HOW TO AVOID THE HAZARD
**Use low gear and maintain steady speed when climbing a hill.**
**If you lose all forward speed:**

- **Operator and passenger (2-UP models) must keep their weight uphill. Never open the throttle suddenly or make sudden gear changes. The vehicle could flip over backwards.**
- **Apply the brakes.**
- **Apply the parking brake after you have stopped.**
- **Disembark on uphill side, or to a side if pointed straight uphill (passenger first on 2-UP models).**

**If you begin rolling backwards:**

- **Operator and passenger (2-UP models) must keep their weight uphill. Never open the throttle suddenly or make sudden gear changes. The vehicle could flip over backwards.**
- **Never apply the rear brake while rolling backwards.**
- **Apply the front brake gradually.**
- **When fully stopped, apply rear brake as well and apply the parking brake.**
- **Disembark on uphill side, or to a side if pointed straight uphill (passenger first on 2-UP models).**
- **Turn the vehicle around and remount, following the procedure described further in this Operator's Guide.**

## Operating Over Obstacles

**⚠ WARNING**

**POTENTIAL HAZARD**
**Improperly operating over obstacles.**
**WHAT CAN HAPPEN**
**Could cause loss of control (passenger ejection on 2-UP models), or a collision.**
**Could cause the vehicle to overturn.**
**HOW TO AVOID THE HAZARD**
**Before operating in a new area, check for obstacles.**
**Never attempt to ride over large obstacles, such as large rocks or fallen trees.**
**On 2-UP models, the operator is responsible for the safety of his passenger. In doubt, disembark him before riding over obstacles. Always remember that the vehicle handling and stability may be affected when riding with a passenger.**
**When you go over obstacles, always follow proper procedures as described in this Operator's Guide.**

## Skidding or Sliding

**⚠ WARNING**

**POTENTIAL HAZARD**
**Skidding or sliding improperly.**
**WHAT CAN HAPPEN**
**You may lose control of this vehicle.**
**You may also regain traction unexpectedly, which may cause the vehicle to overturn or passenger ejection (2-UP models).**
**HOW TO AVOID THE HAZARD**
**Learn to safely control skidding or sliding by practicing at low speeds and on level smooth terrain.**
**On 2-UP models, never slide or skid with passenger. Always remember that the vehicle handling and stability may be affected when riding with a passenger.**
**On extremely slippery surfaces, such as ice, go slowly and be very cautious in order to reduce the chance of skidding or sliding out of control.**

## Deep or Fast Flowing Water

**⚠ WARNING**

POTENTIAL HAZARD
**Operating this vehicle through deep or fast flowing water.**
WHAT CAN HAPPEN
**Tires may float, causing loss of traction and loss of control, which could lead to an accident.**
HOW TO AVOID THE HAZARD
**Never operate this vehicle in fast flowing water or in deep water.**
**Check water depth and current before you attempt to cross any water.**
**Water should not go above the center of the wheels.**
**Remember that wet brakes may have reduced stopping ability. Test your brakes after leaving water. If necessary, apply them several times to let friction dry out the pads.**

## Operating in Reverse

**⚠ WARNING**

**POTENTIAL HAZARD**
**Improperly operating in reverse.**
**WHAT CAN HAPPEN**
**You could hit an obstacle or person behind the vehicle, resulting in serious injury.**
**HOW TO AVOID THE HAZARD**
**When you select reverse gear, make sure there are no obstacles or people behind the vehicle. When it is safe to proceed, go slowly. On 2-UP models, take account that the passenger can obstruct your view.**

## Tire Pressure

**⚠ WARNING**

POTENTIAL HAZARD
**Operating this vehicle with improper tires, or with improper or uneven tire pressure.**
WHAT CAN HAPPEN
**Use of improper tires on this vehicle, or operation of this vehicle with improper or uneven tire pressure, may cause loss of control, tire blow outs, tire to move around on its rim, and increases the risk of an accident.**
HOW TO AVOID THE HAZARD
**Always use the size and type of tires specified in this Operator's Guide for this vehicle.**
**Always maintain proper tire pressure as described in this Operator's Guide.**
**Always replace wheels or tires that are damaged.**

## Improper Modifications

**⚠ WARNING**

**POTENTIAL HAZARD**
**Operating this vehicle with improper modifications.**
**WHAT CAN HAPPEN**
**Improper installation of accessories or modification of this vehicle may cause changes in handling which in some situations could lead to an accident.**
**HOW TO AVOID THE HAZARD**
**Never modify this vehicle through improper installation or use of accessories. All parts and accessories added to this vehicle should be approved by BRP and should be installed and used according to instructions. If you have questions, consult an authorized Can-Am dealer.**
**NEVER install an aftermarket passenger seat on a 1-UP models or use the racks to carry a passenger.**
**Modification of the vehicle to increase speed and performance may violate the terms and conditions of your vehicle limited warranty. In addition, certain modifications including the removal of engine or exhaust components are illegal under most laws.**

## Loading, Carrying or Towing Cargo

**⚠ WARNING**

POTENTIAL HAZARD
**Overloading this vehicle, carrying or towing cargo improperly.**
WHAT CAN HAPPEN
**Could cause changes in vehicle handling which could lead to an accident.**
HOW TO AVOID THE HAZARD
**Never exceed the stated load capacity for this vehicle including operator and passenger (2-UP models) as well as other loads and added accessories.**
**Cargo should be properly distributed and securely attached.**
**Reduce speed when carrying cargo or pulling a trailer. Allow greater distance for braking.**
**Always follow the instructions in this Operator's Guide for carrying cargo or pulling a trailer.**

## Transporting Flammable or Dangerous Material

**⚠ WARNING**

V03M01Q

**POTENTIAL HAZARD**
**Transporting flammable or dangerous material can lead to explosions.**
**WHAT CAN HAPPEN**
**This can cause serious injury or death.**
**HOW TO AVOID THE HAZARD**
**Never transport flammable or dangerous material.**

# PRE-RIDE INSPECTION

**⚠ WARNING**

**Perform a pre-ride inspection before each ride to detect any potential problem that could occur during operation. The pre-ride inspection can help you monitor component wear and deterioration before they become a problem. Correct any problem that you discover to reduce the risk of a breakdown or crash.**

Before using this vehicle, the operator should always perform the following pre--ride inspection check list:

## Pre-Ride Inspection Check List

***What to Do Before Starting the Engine (Key OFF)***

| Items to be Inspected | Inspection to Perform | ✓ |
|---|---|---|
| Engine oil | Check engine oil level. | |
| Coolant | Check coolant level. | |
| Brake fluid | Check brake fluid level | |
| Leaks | Check for any leaks under vehicle | |
| Throttle lever | Activate throttle lever several times to ensure it operates freely. It must return to idle position when released | |
| Brake lock lever | Engage the brake lock lever and check if it operates properly | |
| Engine air filter | Inspect and clean engine air filter | |
| CVT air filter | Inspect and clean CVT air filter | |
| Exhaust system | If not already done, clean the area surrounding the exhaust system, especially if during the last ride, the vehicle was used in a swamp, bog, hay or dead leaves. | |
| Radiator | Check cleanliness of the radiator | |
| Seat(s) | Ensure operator's seat is properly locked in position by pulling back and up several time. Even if a distinctive snap is heard during the installation, always pull it back and up to confirm proper latching. | |
| | Check if passenger seat or the glove box are in place and properly latched (2-UP Models) | |
| | Check the passenger backrest and grab handles condition (2-UP Models) | |

| Items to be Inspected | Inspection to Perform | ✓ |
|---|---|---|
| Tires | Check tire pressure and condition. Refer to the *Tire Pressure and Maximum Load* label and adjust according to load. | |
| Wheels | Check wheels for damage and for abnormal play, and check lug nuts are tightened. Tighten wheel beadlock bolts (if equipped). Refer to *Wheels and Tires* in *Maintenance Procedures* for torque specification. | |
| Drive shaft bellows | Check drive shaft bellows and protectors condition | |
| Cargo | If you transport a cargo, respect the load capacity. Refer to *Loading the Cargo Racks*.<br>Ensure cargo is properly secured to the racks | |
| | If you are pulling a trailer or another equipment:<br>– Check hitch and trailer ball condition<br>– Respect the tongue capacity and towing capacity as indicated on the label affixed to the hitch or refer to *Technical Specifications*.<br>– Ensure trailer is properly secured to hitch. | |
| Storage compartment | Check if rear storage compartment is properly latched | |
| Chassis and suspension | Check underneath vehicle for any debris on chassis or suspension components and clean them properly | |

***What to Do Before Starting the Engine (Key ON)***

| Items to be Inspected | Inspection to Perform | ✓ |
|---|---|---|
| Digital display | Check operation of indicator lamps in digital display(during first few seconds of key ON). | |
| | Check for messages on digital display. | |
| Lights | Check operation and cleanliness of:<br>– Headlights (High and Low)<br>– Taillights<br>– Brake lights<br>– Turn signal lights<br>– Position lights<br>– Hazard lights. | |

| Items to be Inspected | Inspection to Perform | ✓ |
|---|---|---|
| Fuel level | Check the fuel level. | |
| Horn | Check operation of the horn (If equipped). | |

***What to Do After the Engine is Started***

| Items to be inspected | Inspection to perform | ✓ |
|---|---|---|
| Steering | Check if steering operates freely by completely turning it from side to side | |
| Shift lever | Check operation of shift lever (P, R, N, H and L) | |
| 4WD/6WD selector | Check operation of 4WD/6WD selector | |
| Brakes | Drive forward slowly a few feet and apply brake lever and brake pedal individually. The brakes must fully apply. Lever and pedal must fully return when released | |
| Engine stop switch | Check that the engine stop switch is working properly | |
| RF D.E.S.S. Post | Check if D.E.S.S. post is working properly by pulling the D.E.S.S. key from the D.E.S.S. post and stopping the engine | |

# RIDING THE VEHICLE

To fully appreciate the pleasures and excitement of riding this vehicle, there are some basic rules and tips that you MUST follow. Some may be new to you while others may be common sense or obvious.

Please take the time to study this Operator's Guide and all on-product safety labels as well as the safety video located at https://can-am.brp.com/off-road/safety. They more completely describe what you should know about this vehicle before riding it.

Whether you are a new user or an experienced rider, it is important for your personal safety that you know the controls and features of this vehicle. Equally important is knowing how to properly ride.

This is a high performance ATV. Inexperienced riders may overlook risks and be surprised by the specific behavior of this ATV in any terrain condition.

Information in this Operator's Guide is limited. It is strongly recommended that you obtain further information and training from your local authorities, ATV clubs, a recognized ATV training organization or contact an authorized Can-Am Off--road dealer.

We recommend following the age recommendation indicated on the safety label affixed on the unit. Even though a person may be within the age group for which this vehicle is recommended, he may not have the skills, abilities, or judgment needed to operate this vehicle safely and may be involved in a serious accident.

Individuals with cognitive or physical impairments or who are high risk takers have an increased exposure to overturns or collisions which may result in injury including death.

Not all vehicles are the same. Each has its own unique performance characteristics, controls and features. Each will ride and handle differently.

Become completely familiar with the operational controls and the general operation of the vehicle before venturing into off road conditions. Practice driving in a suitable area free of hazards and feel the response of each control. Drive at low speeds. Higher speeds require greater experience, knowledge and suitable riding conditions.

Riding conditions vary from place to place. Each is subject to weather conditions which may radically change from time to time and from season to season.

Riding on sand is different than riding on snow or through forests or marshes. Each location may require a greater degree of awareness and skill. Show good judgement. Always proceed with caution. Please do not take any unnecessary risks that could leave you stranded or possibly injured.

Never assume that the vehicle will go everywhere safely. Sudden changes in terrain caused by holes, depressions, banks, softer or harder “ground” or other irregularities may cause the vehicle to topple or become unstable. To avoid this, slow down and always observe the terrain ahead. If the vehicle does begin to topple or tip over, the best advice is to immediately get off AWAY from the direction of the tip over!

If a road usage is allowed in your area, operate your vehicle on paved surface only for short distance and for the only purpose of moving the vehicle from an

off-road usage to another. Always operate your vehicle at low speed (never exceed 40 km/h (25 MPH) and reduce the speed before making a turn. This vehicle is not equipped with a rear differential (rear wheels are always turning at the same speed). For this reasons, pavement may seriously affect the handling and control of the vehicle.

Always respect all road traffic laws when operating your vehicle on public roads or streets. If you have to cross a road, the lead driver should get off his vehicle the observe and give direction to the other riders. The last person after crossing then assists the lead driver to cross. Do not travel on sidewalks. They are designated for pedestrian use.

We encourage you to have an Annual Safety Inspection of your vehicle. Please contact an authorized Can-Am Off-road dealer for further details. Though not required, it is recommended that an authorized Can-Am Off-road dealer performs the preseason preparation of your vehicle. Each visit to your authorized Can-Am Off-road dealer is a great opportunity for your dealer to verify if your vehicle is included in any safety campaign. We also urge you to visit your authorized Can-Am Off-road dealer in a timely manner if you become aware of any safety related campaigns.

See an authorized Can-Am Off-road dealer for available accessories you may require.

## Riding Gear

Actual weather conditions should help you decide how to dress. Dress for the coldest weather expected. Thermal underwear next to the skin also provides a good insulation. It is important that the operator always wears the appropriate protective riding gear and apparel, including an approved helmet, eye protection, boots, gloves, a long sleeved shirt and pants. This type of clothing will provide you protection from some of the minor hazards you may encounter en route. The operator must never wear loose clothing such as a scarf that may get entangled in the vehicle or on tree branches and shrubs. Depending on conditions, anti-fogging goggles or sunglasses may be required. Different colored lenses available for goggles or sunglasses help you distinguish terrain variations. Sunglasses should only be worn during the daytime.

Riders with appropriate riding gear

## Carrying a Passenger

### 1-UP Models

This vehicle is designed to carry ONE (1) operator only. Do not install passenger seat or use the racks to carry a passenger.

### 2-UP Models

This vehicle is designed specifically to carry an operator and ONE (1) passenger only. The passenger must be seated on the designated passenger's seat and hold on to the grab handles at all times. NEVER install other passenger's seat other than the one recommended by BRP. Do not use the racks or their location to carry passenger (s). Carrying more than one (1) passenger may affect the stability and your control of the vehicle. When the glove box is installed (in place of rear seat), the vehicle becomes a ONE-RIDER vehicle (1-UP model) and NO PASSENGER must be allowed on it.

### 1-UP Models

This vehicle is designed to carry ONE (1) operator only.

NEVER install a passenger's seat.

Do not use the front rack or the cargo box to carry passenger(s).

### 2-UP Models

This vehicle is designed specifically to carry an operator and ONE (1) passenger only.

The passenger must be seated on the designated passenger's seat and hold on to the grab handles at all times.

NEVER install other passenger's seat.

Do not use the front rack or the cargo box to carry passenger(s).

Carrying more than one (1) passenger may affect the stability and your control of the vehicle.

## Recreational Riding

Respect the rights and limitations of others. Stay away from areas designated for other types of off road use. This includes snowmobile trails, equestrian trails, cross country ski trails, mountain bike trails, etc. Never assume there are no other users on the trail. Always stay to the complete right of the trail and do not zigzag to one side of the trail then the other. Be prepared to stop or pull off to the side if another trail user appears in front of you.

Join a local ATV club. It will provide you with a map and advice or inform you where you can ride. If a club does not exist in your area, help to start one. Group riding and club activities provide a pleasurable, social experience.

Always keep a safe distance from other riders. Your judgment of speed, terrain conditions, weather, mechanical condition of your vehicle and the “trust in judgment” you have in others around you will help you make a better choice of appropriate safe distance. This vehicle, like any other motorized vehicle, cannot stop “on a dime”.

Before you ride, tell someone where you are planning to travel and your expected time of return.

Depending on the length of your ride, carry additional tools , drinking water, food and emergency equipment. Find out where you can get additional gasoline and oil. Be prepared for the possible conditions you may encounter.

| | |
|---|---|
| First aid kit | Adjustable wrench |
| Mobile phone | Knife |
| Friction tape | Flashlight |
| A rope | Colored lens goggles |
| Spare light bulbs | Trail map |
| Provided tool kit | Snack |

## Environment

One of the benefits of this vehicle is that it can take you off the beaten path away from most communities. However, you should always respect nature and the

rights of others to enjoy it. Do not ride in environmentally sensitive areas. Do not drive over forest crops or shrubs, nor cut down trees or take down fencing, nor spin your wheels and destroy the terrain. “Tread Lightly”.

This vehicle can cause OHV wildfires if debris builds up near the exhaust or other engine hot spots and ignites then falls off into dry grass. Avoid riding in wet areas, through muskeg or tall grass, where debris can build up. Should you ride in those areas, inspect and remove all debris from your engine and hot spots. Refer to *Vehicle Care* for details.

Chasing wildlife is in many areas illegal. Wildlife can die of exhaustion after being chased by a motorized vehicle. If you encounter animals on the trail, stop and observe quietly and with caution. It will be one of the better memories of your life.

Observe the rule “what you take in, carry out”. Do not litter. Do not start campfires unless you have permission to do so, and then only away from dry areas. The hazards you may create on the trail may cause injury to others or yourself, even at a later date.

Respect farm lands. Always obtain the permission of the landowner before riding on private land. Respect crops, farm animals and property lines.

Finally, do not pollute streams, lakes or rivers and do not modify the engine or exhaust system, or remove any of its components as it will alter the vehicle emissions.

## Design Limitation

Although the vehicle is exceptionally rugged for its class, it is still a light vehicle by definition and its operation must be restricted to its proper purpose.

The addition of weight to any part of the vehicle changes its gravitational stability and modifies its performance.

## Off-Road Operation

The very nature of off-road operation is dangerous. Any terrain, which has not been specially prepared to carry vehicles, presents an inherent danger where terrain substance, shape and steepness are unpredictable. The terrain itself presents a continual element of danger, which must be knowingly accepted by anyone venturing over it.

An operator who takes a vehicle off-road should always exercise the utmost care in selecting the safest path and keeping close watch on the terrain ahead of him. The vehicle should never be operated by anyone who is not completely familiar with the driving instructions applicable to the vehicle, nor should it be operated on steep or treacherous terrain.

## Riding Techniques

Information in this guide is limited. Increase your knowledge and improve your skills by following a certified training course.

Care, caution, experience and driving skill are the best precautions against the hazards of vehicle operation.

Respect and follow all posted trail signs. They are there to help you and others.

In off-road operation, power and traction, not speed, are important. Never drive faster than visibility and your own ability to select a safe route permits.

Constantly watch the terrain ahead for sudden changes in slopes or obstacles, such as rocks or stumps, that may cause loss of stability, resulting in tip over or rollover.

It is also wise to know the terrain condition on the other side of a hill or bank. All too often there exists a sharp drop-off that is impossible to negotiate or descend.

Whenever there is the slightest doubt that the vehicle can safely negotiate an obstacle or a particular piece of terrain, always choose an alternate route.

Always use proper riding techniques to avoid vehicle overturns on hills and rough terrain and in turns.

### *Body Position*

To maintain proper control, it is strongly advised that you keep your hands on the handlebar and within easy reach of all controls. The same holds true for your feet on the foot pegs. To minimize the possibility of a leg or foot injury, keep your feet on the foot pegs at all times. Do not direct your toes outwards nor extend your feet out to assist in turning as they can be hit or be snagged on passing obstacles, or may come into contact with the wheels.

Even though there is a suspension on this vehicle, there are “washboard” or rough terrain conditions that will make you feel uncomfortable and can even cause a back injury. “Posting” or riding in a crouched position will often be required. Slow down and allow your flexed legs to absorb part of the impact energy.



### *2–UP Models*

The passenger must keep his hands on the grab handles and his feet on the footrests at all time.

The passenger must also synchronize his movements with the operator.

### *Crossing Roads*

If you have to cross a road, ensure to have complete visibility on both sides for incoming traffic and decide on exit point on other side of road. Drive in a straight line toward that point. Do not make sharp direction changes or abrupt accelerations as it may result in a rollover situation. Do not travel on sidewalks or bicycle trails as they are designated specifically for those uses.

### *Riding on Road*

Always respect all road traffic laws when operating your vehicle on public roads or streets.

Do not travel on sidewalks. They are designated for pedestrian use.

### *Turning*

Practice turning at low speeds before attempting to turn at faster speeds.

Keep both hands on handlebars and feet on footpegs.

Maintain a constant speed or a slight acceleration during turn.

To reduce the risk of rollovers:

- Use care when turning.
  - Do not turn the handlebar too far or too fast for your speed and environment. Adjust steering inputs accordingly.
  - Slow down before entering a turn. Avoid hard braking during a turn.
  - Avoid sudden or hard acceleration when turning, even from a stop or low speed.
- Never attempt donuts, skids, slides, fishtails, jumps, or other stunts. If vehicle starts to skid or slide, steer in the direction of the skid or slide. Never slam the brakes and lock the wheels.
- Driving on paved surfaces is different from driving in Off-Road conditions. It requires a different approach in regards to the steering inputs and braking. Turn gradually, go slowly, and avoid abrupt acceleration and braking.

Avoid sudden inputs to steering, throttle or brakes while turning.

| ⚠ WARNING |
| --- |
| **Do not attempt turns at excessive speed.** |



If you do get into a slide or skid, it may help to turn the handlebar in the direction of the skid until you regain control. Never jam the brakes and lock the wheels.

**⚠ WARNING**

**The tires of this vehicle are not suited for paved road use. Also this vehicle is not equipped with a rear differential (rear wheels are always turning at the same speed). For these reasons, pavement may seriously affect the handling and control of the vehicle.**

### *Braking*

Always keep both hands on handlebars and feet on footpegs when braking.

Practice braking to get familiar with the brake response.

- Do it at low speed first, then increase the speed.
- Practice braking in straight line at different speeds and different braking force.
- Practice emergency braking; optimal braking is obtained in straight line, with high force applied, without locking the wheels.

Remember, braking distance depends on vehicle speed, load and the type of surface. Also, the tires and brakes conditions play a major role.

**NOTE:**
If going forward the vehicle weight is transferred to the front wheels when braking. To obtain greater stopping efficiency, the brake system distributes more braking force to the front wheels. This will affect vehicle handling and steering control when braking vigorously. Take it into account when braking.

**Brake lever**: Each time the brake lever is used, the front and rear brakes are activated, whether in 4x6 or 6x6 mode.

**Brake pedal:**

- In 4x6 mode, the brake pedal activates ONLY the rear brakes.
- In 6x6 mode, the brake pedal activates ALL brakes (front and rear).

### *Reverse Operation*

When operating in reverse, check that the path behind the vehicle is free of people or obstacles. Proceed slowly and avoid sharp turns.

When riding on a 2-UP model, take into account that the passenger can obstruct your view. Disembark the passenger if necessary.

We recommend sitting on your ATV when operating in reverse. Avoid standing up. Your weight could shift forward against throttle lever, causing an unexpected acceleration.

**⚠ WARNING**

**Unexpected acceleration when the ATV is operated in reverse can cause a loss of control.**

### *Obstacles*

Obstacles in the “trail” should be traversed with caution. This includes loose rocks, fallen trees, slippery surfaces, fences, posts, and embankments and depressions.

You should avoid them whenever possible. Remember that some obstacles are too large or dangerous to cross and should be avoided.

Small rocks or fallen trees may be safely crossed approach at a 90° angle.

Stand on the footrests while keeping your knees flexed. Adjust speed without losing momentum and do not “gun” the throttle.

Hold handlebar (operator) or grab handles (passenger on 2-UP models) firmly. Place body weight rearwards (operator and passenger 2-UP models) and proceed.

Do not try to lift the vehicle front wheels off the ground. Be aware that the object may be slippery or may move while crossing.

When riding on 2-UP models, the operator is responsible for the safety of the passenger; in doubt, disembark the passenger before proceeding.

## Uphill Driving



### 1–UP Models

Before trying to climb a hill, keep these things in mind.

Hill climbing should only be attempted by experienced operators.

Start on shallow slopes.

Always drive straight uphill and keep your body weight forward towards the top of the hill.

Keep your feet on the footrests, shift your ATV into a lower gear and accelerate before you start to climb.

Try to keep a steady speed and go easy on the throttle to avoid acceleration.

Abrupt slope or terrain variation or rolling one wheel over an obstacle could have a big impact on the stability as it will lift the front of the vehicle increasing the risk of tipping over.

Some hills are too steep to safely stop or recover from after an unsuccessful climbing attempt.

Try to avoid steep inclines. If you're not careful, you could tip over when going up hills.

If the hill is too steep and you cannot proceed or the vehicle begins to roll backwards, apply the brake, being careful not to slide, apply the parking brake. Dismount on the left side then use the “K” turn (while walking back, next to the vehicle on the up hill side and with a hand on the brake lever, slowly back the rear of the vehicle toward the top of the hill then drive downhill).

Always walk or dismount on the upside of the slope while keeping clear of the vehicle and its rotating wheels.

Do not try to hold on to the vehicle if it begins to topple. Stay clear.

Do not ride over the crest of the hill at high speed. Obstacles, including sharp drop-offs, may exist.

### 2–UP Models

The passenger must synchronize his movements with the operator. The passenger must remain seated at all times.

Do not forget, the operator is responsible for the safety of the passenger. In doubt, disembark the passenger before climbing a hill.

Before trying to climb a hill, keep these things in mind. Hill Climbing should only be attempted by experienced operators.

Start on shallow slopes. Always drive straight uphill.

Operator and passenger must keep their body weight forward, towards the top of the hill. Keep feet on the footrests, shift the ATV into a lower gear and accelerate before you start to climb. Try to keep a steady speed and go easy on the throttle to avoid acceleration.

Abrupt slope or terrain variation or rolling one wheel over an obstacle could have a big impact on the stability as it will lift the front of the vehicle increasing the risk of tipping over.

Some hills are too steep to safely stop or recover from after an unsuccessful climbing attempt. Try to avoid steep inclines. If you're not careful, you could tip over when going up hills.

If the hill is too steep and you cannot proceed or the vehicle begins to roll backwards, apply the brake, being careful not to slide and apply the parking brake. Ask the passenger to dismount first, then use the “K” turn (while walking back, next to the vehicle on the up hill side and with a hand on the brake lever, slowly back the rear of the vehicle toward the top of the hill then drive downhill). Always walk or dismount on the upside of the slope while keeping clear of the vehicle and its rotating wheels.

Do not try to hold on to the vehicle if it begins to topple. Stay clear. Do not ride over the crest of the hill at high speed. Obstacles, including sharp drop-offs, may exist.

The passenger should get on the vehicle only when the vehicle has returned to a safe location.

### Vehicle Behaviors

Due to configuration, this vehicle has excellent climbing ability, so much so that it is possible to tip over before traction is lost. For example, it is common to encounter terrain situations where the top of the hill has eroded to a point that the hill peak rises very sharply. The vehicle can readily negotiate such a condition, however, in doing so, when the front of the vehicle is driven to a point that the vehicle's balance moves rearward, a tip over can occur.

The same situation may apply if an embedded object causes the front of the vehicle to climb more than desired. If such a situation occurs take an alternate route. Be aware of side hilling dangers when doing so. Refer to .

### *Downhill Driving*



#### *1–UP Models*

Keep your body weight rearwards. Stay seated. Apply the brake gradually to prevent skidding. Do not “coast” down the slope using solely engine compression or in neutral gear.

Decelerating while negotiating a slippery downhill slope could “toboggan” the vehicle. Maintain steady speed and/or accelerate slightly to regain control. Try to avoid steep inclines. If you're not careful, you could tip over when going down hills.

#### *2–UP Models*

The operator is responsible for the safety of the passenger; in doubt, disembark the passenger before proceeding.

Always remember that the vehicle handling, stability and braking distance may be affected when riding with a passenger.

The passenger must synchronize his movements with the operator. The passenger must remain seated at all times.

Operator and passenger must keep their body weight rearwards. Apply the brake gradually to prevent skidding. Do not “coast” down the slope using solely engine compression or in neutral gear. Try to avoid steep inclines. If you're not careful, you could tip over when going down hills.

#### Vehicle Behaviors

This vehicle can climb slopes that are steeper than it can safely descend. Therefore, it is essential to ensure that a safe route exists to descend a slope before you climb it.

### *Side Hilling*

This is one of the **most risky** types of riding because it can drastically change the balance of the vehicle. It should be avoided whenever possible. However, if it is necessary to do so, it is important that you ALWAYS keep your body weight on

the upside of the slope and be prepared to dismount on that side should the vehicle begin to topple.

Avoid all objects or depressions that will intensify the raising of one side of the vehicle higher than the other, thus causing rollover.

**⚠ WARNING**

**Do not try to stop or save the vehicle from damage.**

**⚠ WARNING**

**Be careful when loading and transporting liquid reservoirs. They can affect vehicle stability when side hilling by pulling downhill and increasing the risk of a rollover.**



### *2–UP Models*

The passenger must synchronize his movements with the operator. The passenger must remain seated at all times.

The operator is responsible for the safety of the passenger; when in doubt, disembark the passenger before proceeding.

### *Drop-Offs*

**⚠ WARNING**

**Avoid negotiating drop-offs. Reverse and select an alternate route.**

This vehicle will “bottom out” and usually stop if either the front or rear wheels are driven over a drop-off. If the drop is sharp or deep, the vehicle will nose dive and tip over.

When riding on a 2–UP model, the operator is responsible for the safety of the passenger; in doubt, disembark the passenger before processing.

### *Crossing Water*

Water can be a unique hazard. If it is too deep the vehicle may “float” and topple. Check the water depth and current before you attempt to cross any water.

Water should not go above the footrest.

Be wary of slippery surfaces such as rocks, grass and logs, both in the water and on its banks. A loss of traction may occur. Do not attempt to enter the water at high speed. The water will act as a brake and could throw you off the vehicle, on the ground.

Wet brakes will affect the braking ability of your vehicle. Make sure you dry the brakes by applying them several times after the vehicle leaves the water, mud or snow. Allow greater distance for braking.

Mud or marsh lands may be encountered near water. Be prepared for sudden “holes” or changes in depth. Similarly, be watchful of hazards such as rocks and logs that are partially covered by vegetation.

### *Riding on Ice*

If your route crosses frozen waterways, make sure the ice is thick enough and sound enough to support the total weight of yourself, your passenger (2-UP models), the vehicle and its load. Be ever watchful of open water it is a sure indication that the ice thickness will vary.

On 2-UP models, the operator is responsible for the safety of the passenger; in doubt, do not attempt to cross.

Ice will also affect the control of the vehicle. Slow down and do not “gun” the throttle. This will only result in spinning of the tires and possible tip over of the vehicle or passenger ejection (2-UP models).

Avoid rapid braking. This again will possibly result in an uncontrolled slide and tip over of the vehicle or passenger ejection (2-UP models).

Slush should be avoided at all times since it could block the operation or controls of the vehicle.

### *Riding on Snow Covered Surfaces*

When performing the pre-ride inspection, pay special attention to locations on the vehicle where snow and/or ice accumulations may obstruct visibility of the taillight and reflectors, clog ventilation openings, block the radiator and fan, and interfere with the movement of control levers, switches and brake pedal. Before starting with your ATV check the steering, throttle and brake lever and pedal controls for interference free operation.

Whenever an ATV is ridden on a snow covered drive path the tire grip is generally reduced causing the vehicle to react differently to control inputs from the operator. On low grip surfaces, the steering responses are not as crisp and precise, stopping distances are lengthened and acceleration becomes sluggish. Slow down and do not "gun" the throttle. This will only result in spinning of the tires and possibly in an over steering slide of the vehicle. Avoid hard braking. This will possibly result in a straight line slide of the vehicle. Again, the best advice is to safely reduce speed in anticipation of a maneuver so to give yourself time and distance to regain total vehicle control before it spins out of your control.

As you drive your ATV over a loose snow covered surface, snow dust will be picked up in the wake turbulence of the moving vehicle and transported to contact and accumulate or melt on some exposed components including rotating parts like brake discs. Water, snow or ice may affect the response time of the brake system of your ATV. Even when not required to reduce vehicle speed apply brakes frequently to prevent ice or snow accumulation and to dry brake pads and discs. While doing so in low risk driving situations you will test for grip level and keep yourself alerted to how the vehicle reacts to your control inputs. Always keep brake pedal, footrests, floor boards, brake and throttle levers free of snow and ice. Frequently wipe snow off seat, hand grips, headlights, taillights and reflectors.

The depth of the snow cover may hide rocks, tree stumps or other objects and if it is wet may totally impede the driveability as the vehicle becomes bogged down or completely looses traction in slushy snow. Look far ahead and always be watchful of any visible clues that might indicate the presence of such obstacles. In doubt steer clear. Avoid driving on any frozen body of water before checking that the ice will safely support the ATV, its riders and its load of cargo. Remember that a given thickness of ice may be sufficient to support a snowmobile but not an ATV of an identical weight because of the smaller load bearing surface of the four tire contact patches as compared to that of a snowmobile track and skis.

To maximize comfort and avoid frostbite, always wear clothing and ATV protective equipment appropriate for the weather conditions you will be exposed to during your ride.

At the end of each ride it is a good practice to clean the vehicle body and all moving components (e.g., brakes, steering components, drivelines, radiator fan and controls) from any snow or ice accumulations. Wet snow will turn to ice during the shut down period and become more difficult to remove at the next pre-ride inspection.

Riding in snow may reduce the brakes stopping capability. Safely reduce speed and allow greater distance for braking. Snow projection may cause ice build up

or snow accumulation on brake components and controls. Apply brakes frequently to prevent ice or snow accumulation.

### *Riding on Sand*

Riding on sand or sand dunes is another unique experience, but there are some basic precautions that should be observed.

Wet, deep or fine sand may create a loss of traction and cause the vehicle to slide, drop off or become “bogged” down.

If this occurs look for a firmer base. Again, the best advice is to slow down and be watchful of the conditions.

Slow down even more when riding with a passenger.

When riding in sand dunes it is advisable to equip the vehicle with an antenna--type safety flag. This will help make your location more visible to others over the next sand dune.

Proceed carefully should you see another safety flag ahead.

Since the antenna type safety flag can snag and rebound on your body if caught, do not use it in areas where there are low hanging branches or obstacles.

Always remember when riding that the vehicle handling and stability may be affected when riding with a passenger.

### *Riding on Loose Stones*

Riding on loose stones or gravel is very similar to riding on ice. They will affect the steering of vehicle possibly causing it to slide or tip over, especially at high speeds (resulting in operator and passenger ejection (2–UP models)).

Again, the best advice is to slow down and be watchful of the conditions. When you ride with a passenger (2–UP models), slow down even more.

In addition, braking distance may be affected. Remember that “gunning” the throttle or sliding may cause loose stones to be ejected rearwards into the path of another rider. Never do it deliberately.

# MOVING LOADS AND DOING WORK

## Working with Your Vehicle

Your vehicle can help you perform a number of different LIGHT tasks ranging from snow removal to pulling wood or carrying cargo. A variety of accessories are available from your authorized Can-Am Off-road dealer. To prevent possible injury, follow the instructions and warnings that accompany the accessory. Always respect the load limits of the vehicle. Overloading the vehicle can overstress the components and cause failure. Avoid overexerting yourself if you lift or pull heavy loads or manually push the vehicle.

**⚠ WARNING**

**Mounted machinery must be lowered on the ground before leaving the vehicle.**

## Carrying Loads

Any load carried on the vehicle including a passenger (2-UP models) and/or the carrying rack (s) will affect the handling, stability and braking distance of the vehicle.

Do not exceed the total load allowed for this vehicle, including the weight of operator and passenger, cargo, accessories and trailer tongue weight. Refer to *Technical Specifications*.

Always make sure the cargo is secured, properly distributed and cannot interfere with your proper control or lights.

Always be aware that the “cargo” may slide or fall off and cause an accident.

Avoid cargo that may protrude sideways and get snagged or caught in bushes or other obstacles.

Safely reduce speed according to terrain conditions when carrying cargo or pulling a trailer.

Allow greater distance for braking.

Always secure cargo as low as possible on the rear rack to reduce the effect of a higher center of gravity.

**⚠ WARNING**

**The vehicle handling, stability and braking distance are affected when loading racks and using the vehicle. Correct loading and weight distribution are therefore important. Never overload, tow or carry cargo improperly. Always ensure the cargo is safely secured and properly distributed on the rack(s) before operating the vehicle. Safely reduce speed according to terrain conditions when carrying cargo or pulling a trailer, and avoid hills and rough terrain. Allow greater distance for braking, especially on inclined surfaces and when a passenger (2-UP models) is on board. Be careful not to skid or slide. Always secure cargo as low as possible on the rack(s) to reduce the effect of a higher center of gravity. Failure to follow the recommendations here could cause changes in vehicle handling which could lead to an accident.**

| Maximum Payload Table | | |
|---|---|---|
| Total payload allowed | 460 kg (1,015 lb) | Includes weight of operator, passenger, cargo, accessories and trailer tongue weight. |
| Front cargo area | 45 kg (100 lb) | Evenly distributed. |
| Rear cargo load | 318 kg (700 lb) | Evenly distributed.<br>Includes rear cargo box, lower cargo box and trailer tongue load<br>(318 kg (700 lb) of which, at least, 45 kg(100 lb) in the lower cargo box). |

| Example of Suitable Vehicle Total Loads | | | | | |
|---|---|---|---|---|---|
| **Total vehicle payload** | **Operator and passenger** | **Front rack** | **Cargo box load** | **Accessories** | **Tongue load** |
| 460 kg (1,015 lb) | 137 kg (302 lb) | 40 kg (88 lb) | 250 kg (551 lb) | 10 kg (22 lb) | 23 kg (51 lb) |

When carrying heavy loads in the cargo box or pulling a trailer:

– Adjust the suspension accordingly
– Position the shift lever to L (Low) position.

## Loading the Cargo Racks

Load cargo as low as possible – a higher load can raise the vehicle's center of gravity, which can reduce stability. Position cargo on the rack as evenly distributed as possible.

Secure the load on the cargo rack. Do not secure cargo to other parts of the vehicle. If it is not properly secured, a load may slide or fall off, possibly striking occupants or bystanders; or it may shift during riding, affecting the handling of the vehicle.

Objects that are high may affect visibility for the driver and may act as projectiles in case of an accident. Loads that protrude sideways can get snagged or caught in bush, branches or other obstacles. Avoid covering and obstructing the brake lights with the cargo. Ensure no cargo protrudes outside the cargo rack and that cargo will not interfere with your visibility or control of the vehicle.

| *NOTICE* |
|---|
| **Do not exceed the cargo racks capacity. Always refer to the safety labels on the vehicle.** |

Never carry gasoline container(s) or any dangerous liquids on the cargo rack(s).

## Loading the Cargo Bed

Load cargo as low as possible – a higher load can raise the vehicle's center of gravity, which can reduce stability. Position cargo toward the front and center of the cargo bed and as evenly distributed as possible.

Secure the load to the tie down hooks inside cargo bed. Use only the tie down hooks on the bottom of the cargo bed; do not secure cargo to the cage or other part of the vehicle. If it is not properly secured, a load may slide or fall off, possibly striking operator or bystanders; or it may shift during riding, affecting the handling of the vehicle.

Objects that are higher than the walls of the cargo bed may affect visibility for the driver and may act as projectiles in case of an accident. Loads that protrude sideways can get snagged or caught in bush, branches or other obstacles. Avoid covering and obstructing the brake lights with the cargo. Ensure no cargo protrudes outside the box and that cargo will not interfere with your visibility or control of the vehicle.

Do not overload the cargo box.

| Maximum Cargo Bed Load | | |
|---|---|---|
| Lower cargo load | 318 kg<br>(700 lb) | Evenly distributed and safely secured.<br><br>Including the rear cargo box, lower cargo box and tongue load. |
| Rear cargo load | 273 kg<br>(602 lb) | Evenly distributed on floor separator. |
| Upper tailgate | 100 kg<br>(220 lb) | Load can only be applied to the tailgate when the accessory support bracket is installed.<br><br>Only while loading cargo into the cargo box. |
| Lower tailgate | 50 kg<br>(110 lb) | Only while loading cargo into the cargo box. |

| ⚠ WARNING |
|---|
| **Never operate with an opened tailgate.** |

## Operating While Carrying a Load

Reduce your speed when carrying cargo and turn gradually.

Avoid hills and rough terrain.

Allow more distance for braking.

This vehicle may require additional stopping distance if carrying heavy loads, especially on inclined surfaces.

Keep stabilizer bar locked on both sides when driving on roads. It will reduce the tilting of the vehicle in winding road. Refer to *Tune Your Ride* for complete procedure.

Adjust the suspension accordingly.

Position the shift lever to L (LOW) position.

## Tilting the Cargo Bed

The cargo bed can be tilted to ease unloading. Use release handle on right side of Cargo bed to unlock.

*1. Cargo bed release handle*

**NOTICE**

**Always turn off engine when tilting the cargo bed.**

**⚠ WARNING**

- **Always ensure no one is standing behind the cargo bed before you actuate the release handle.**
- **The load weight may affect the operation of the cargo bed tilting feature (tilting or lowering).**
- **Always take care when opening the cargo bed, as the muffler could be hot.**

Be very careful with the operation of the cargo bed as the load may have moved during transport.

To lower the cargo bed, simply push it down into place and secure with hairpin clip.




1. *Release handle*
2. *Hairpin clip*

**⚠ WARNING**

- **Keep yourself and others clear of the cargo bed and vehicle frame junction when lowering cargo bed.**
- **Ensure to properly latch the cargo bed before riding.**
- **Secure cargo bed with hairpin clip**
- **Make sure you do not leave objects between lifted cargo bed and vehicle frame to ensure proper latching of the cargo bed when lowered.**

## Hauling a Load

Never pull a load by attaching it to the bumper; this can cause the vehicle to tip over. Use only the trailer hitch (if installed) to pull a load.

In an emergency situation, use the recovery hook to recover a stuck vehicle, refer to *Recovery Hooks*.

When pulling loads with a chain or cable:

- Ensure that there is no slack before starting and maintain tension while pulling.
- Be sure to brake progressively. The inertia of the load could lead to an impact.

**⚠ WARNING**

**A slack in the chain or cable can cause it to break and snap back.**

When hauling a load, respect the maximum hauling capacity, refer to *Pulling a Trailer*.

When pulling another vehicle, be sure that someone is controlling the pulled vehicle. They must brake and steer to prevent the vehicle from going out of control.

Reduce your speed when hauling a load and turn gradually.

Avoid hills and rough terrain.

Never attempt steep hills.

Allow more distance for braking, especially on inclined surfaces and when a passenger (2-up models) is on board.

Be careful not to skid or slide.

## Pulling a Trailer

Check the maximum axle loads of the vehicle identification plate (statutory plate).

Can-Am T category tractor can tow a trailer on the road. Check the trailer maximum load on its identification plate.

Check regulations for your area regarding the use of a tractor and trailer on the road.

Connect the trailer lights.

**NOTICE**

**A BRP approved rear hitch must be properly installed on the vehicle for hauling trailers.**

Riding this vehicle with a trailer substantially increases the risk of toppling, especially on inclined slopes. If a trailer is used behind the vehicle make sure that its hitch is compatible with the one on the vehicle. Make sure the trailer is horizontal with the vehicle. (In some instances a special extension may have to be installed on the vehicle hitch). Use security chains or cables to secure the trailer with the vehicle.

Reduce your speed when pulling a trailer and turn gradually. Avoid hills and rough terrain. Never attempt steep hills. Allow more distance for braking, especially on inclined surfaces and when a passenger (2-up models) is on board. Be careful not to skid or slide.

Improperly loading a trailer may cause a loss of control.

Do not exceed the towing capacity or tongue capacity. Refer to *Technical Specifications*.

Make sure there is at least some weight on the tongue.

Always make sure load is evenly distributed and safely secured on the trailer; an evenly balanced trailer is easier to control.

Always put the shift lever to L (low range) for hauling a trailer – in addition to providing more torque, operating in low range helps account for the increased load on the rear tires.

When stopped or parked, block the vehicle and trailer wheels from possible movement.

Use caution when disconnecting a loaded trailer; it or its load may topple on you or others.

When hauling a trailer, respect the maximum hauling capacity indicated on the label on the hitch.

The towing capacity includes the trailer weight.

**⚠ WARNING**

**Stay clear from the area between the vehicle and the trailed vehicle.**

**⚠ WARNING**

**Strictly follow the instructions outlined in the user's guide of the mounted or trailed machinery or trailer, and not to operate the combination vehicle - machine or vehicle - trailer unless all instructions have been followed.**

# IMPORTANT ON-PRODUCT LABELS (COUNTRIES OUTSIDE CANADA AND UNITED STATES)

Read and understand all the safety labels on your vehicle.

These labels are affixed to the vehicle for the safety of the operator, passengers or bystanders.

The following labels are on your vehicle, and they should be considered permanent parts of the vehicle. They need to be clean and visible at all times. If missing or damaged, they need to be replaced. Safety labels are free of charge. See an authorized Can-Am Off-road dealer.

Upon replacement of parts that have warnings on them, make sure to order (free of charge) the applicable safety warnings if not already installed on the replacement part.

**NOTE:**
In the event of any discrepancy between this guide and the vehicle, the safety labels on the vehicle have precedence over the labels in this guide.

## Safety Pictogram

Read and understand all the safety labels on your vehicle.

These labels are affixed to the vehicle for the safety of the operator, passenger (2–UP) or bystanders.

The safety labels on your vehicle should be considered permanent parts of the vehicle.

If missing or damaged, they can be replaced free of charge. Contact an authorized Can-Am Off-road dealer.

**NOTE:**
In the event of any discrepancy between this operator guide and the vehicle, the safety labels on the vehicle have precedence over the labels in this document.

## General Warning Pictogram

**⚠ WARNING**

- **Improper ATV use can result in SEVERE INJURY or DEATH. Follow all instructions and warnings.**
- **Always use an approved helmet and protective gear.**
- **Always wear ear protection.**
- **Locate and read operator's guide and watch the safety video.**
- **Reduce your speed if you must used paved roads.**
- **Never carry a passenger on 1-up models and NEVER carry more than one passenger on 2-up models.**
- **Never use with drugs or alcohol.**

1-UP Models




2-UP Models






## Passenger Warning Pictogram

**⚠ WARNING**

- **Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**
- **NEVER carry a passenger on 1-up models and NEVER carry more than 1 passenger on 2-up models.**
- **Passenger on 2-up models must always use an approved helmet and protective gear.**
- **Passenger on 2-up models must NEVER ride after using drugs or alcohol.**

1-UP Models




2-UP Models






## Tire Pressure and Maximum Load - Warning Pictogram

**⚠ WARNING**

- **ALWAYS maintain proper tire pressure as shown. Improper tire pressure or overloading can cause loss of control, resulting in SEVERE INJURY or DEATH.**
- **When the load on the vehicle is lower than 234 kg (515 lb) the front and rear tire pressure should be 34.5 kPa (5 PSI)**
- **When the load on the vehicle is higher than 234 kg (515 lb) up the vehicle's limit of 460 kg (1 015 lb) the front and rear tire pressure should be 48.3 kPa (7 PSI)**
- **Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**






## Maximum Front Rack Loading – Warning Pictogram

**⚠ WARNING**

- NEVER carry a passenger on this carrier.
- MAXIMUM FRONT LOAD: 45 kg (100 lb) evenly distributed.






## Rear Cargo Load Warning Pictogram

**⚠ WARNING**

- **NEVER exceed the load capacity of 460 kg (1015 lb) including weight of operator, cargo, accessories, and trailer tongue weight.**
- **NEVER carry a passenger on this carrier.**
- **Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**
- **MAXIMUM FRONT LOAD: 45 kg (100 lb) evenly distributed.**
- **MAXIMUM REAR LOAD: 318 kg (700 lb) evenly distributed (including trailer tongue weight if applicable).**






## Cargo Bed Operation Warning Pictogram

**⚠ WARNING**

- **Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**
- **NEVER carry passenger on the cargo bed.**
- **ALWAYS secure locking handles using the safety pins.**
- **ALWAYS remove fuel containers from vehicle before fueling them.**






## Glove Box Installation - Warning Pictogram

1–UP models

**⚠ WARNING**

1. **Open glove box cover and turn latch to the unlock position.**
2. **Align and insert glove box latching system into the vehicle's "LINQ" opening.**
3. **Turn latch to the lock position.**
4. **Close cover and verify if glove box is locked in position.**

**Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**






## Passenger's Seat and Glove Box Installation - Warning Pictogram

2–UP models

**⚠ WARNING**

**To install passenger seat**

1. **Ensure the latch lever is in the open position by pulling it towards the front of seat.**
2. **Using a forward motion, insert both front tabs of the seat into the vehicle anchor housings.**
3. **Rotate downwards to engage the rear latch.**
4. **Close the latch lever by pushing it rearwards to secure seat in position.**
5. **Check if the seat is firmly secured in position before using it.**

1. **To install glove box**
2. **Open glove box cover and turn latch to the unlock position.**
3. **Align and insert glove box latching system into the vehicle's "LINQ" opening.**
4. **Turn latch to the lock position.**
5. **Close cover and verify if glove box is locked in position.**

**Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**



## Recommended Age - Warning Pictogram

**⚠ WARNING**

**Operating this ATV if you are under the age of 16 increases the chance of SEVERE INJURY or DEATH to the operator, and to both the operator and passenger on 2-up models.**
**NEVER operate this ATV if you are under age 16.**






## Shifting Procedures - Notice Pictogram

**NOTICE**

**This vehicle must be stopped before shifting lever. ALWAYS apply foot brake to shift from Park (P) and Neutral (N).**






## Pulling Load Warning Pictogram

**⚠ WARNING**

- **NEVER sit on cargo bed.**
- **NEVER attach here or on the cargo bed to pull load. This can cause the vehicle to tip over.**
- **ALWAYS use the trailer hitch or the recovery hook to pull a load.**






## Tailgate Load Warning Label

**⚠ WARNING**

- **NEVER sit on tailgate.**
- **NEVER exceed the load capacity of 100 kg (220 lb) on the tailgate.**






## Pinch Point Warning Pictogram

**⚠ WARNING**

**Keep clear when lowering cargo bed.**






## Locking Release Handle – Warning Pictogram

**⚠ WARNING**

- **Locate and read operator's guide and watch the safety video. Improper ATV use can result in SEVERE INJURY or DEATH.**
- **ALWAYS secure the release handle with the safety pin.**






## Do Not Stand Here- Warning Pictogram

| ⚠ WARNING |
| --- |
| Do not stand here. |



## Coolant Hot - Warning Label

**⚠ WARNING**

**Do not open when HOT.**



## Possible Burn - Warning Pictogram

# VEHICLE INFORMATION

# PRIMARY CONTROLS




1. *Handlebar*
2. *Throttle lever*
3. *Brake pedal*
4. *RF D.E.S.S. post or ignition switch*
5. *Engine stop switch*
6. *Brake lever*
7. *Brake lock lever*

While reading this Operator's Guide, remember that:

| ⚠ WARNING |
| --- |
| Indicates a potential hazard which, if not avoided, could result in serious injury or death. |

## HANDLEBAR

The handlebar controls the steering of the vehicle.

As the handlebar is rotated to right or left, the front wheels are turned in this direction to steer the vehicle.

**⚠ WARNING**

**Fast reverse while turning, could result in loss of stability and control.**

## THROTTLE LEVER

The throttle lever is located on the RH side of the handlebar.

The throttle lever controls the engine speed.

To increase or maintain vehicle speed, press the throttle lever with your right thumb.

To decrease vehicle speed, release the throttle lever.

## BRAKE LEVER

The brake lever is located on the LH side of the handlebar.




*1. Brake lever*

The brake lever function is to slow down or stop the vehicle.

When the brake lever is compressed, the front and rear brakes are applied.



Braking effect is proportional to the force applied on the lever.

## BRAKE LOCK LEVER

The brake lock lever is located on the LH side of the handlebar.




*1. Brake lever*
*2. Brake lock lever*

Engage the brake lock whenever the vehicle is parked.

**⚠ WARNING**

**Always apply the parking brake when the vehicle is not in operation by engaging the brake lock lever and moving the shifter on the PARK position.**

To engage the brake lock lever proceed as shown:




1. *Brake lever*
2. *Brake lock lever*

**NOTE:**
The brake lock lever can be set to several positions.

**NOTICE**

**When the brake lock lever is applied , make sure the vehicle stays securely in place.**

To unlock the brake lock lever, simply squeeze the brake lever. It should return to the rest position.

**⚠ WARNING**

**Make sure brake lock lever is released before operating the vehicle.**
**If brake lock lever is left engaged while riding, it may cause damage to the brake system and cause loss of braking capacity and/or fire.**

## BRAKE PEDAL

The brake pedal is located on the RH side footrest.

1. *Brake pedal*

When the brake pedal is pressed down, the rear brake is applied.

When released, the brake pedal should return to its original position.

Braking effect is proportional to the force applied on the pedal.

**NOTE:**
The brake will have also an effect on front wheels through the drive train when 4WD is engaged.

Should the brake lever system fail, the rear brake can be used by depressing the brake pedal.

## ENGINE STOP SWITCH

This switch can be used to stop the engine and as an emergency control.

To stop engine, fully release throttle lever then set the engine stop switch to the STOP position.

Even if the engine can be stopped by either turning the ignition key to OFF position or by removing the D.E.S.S. key, we recommend the engine be stopped by setting the engine stop switch to the STOP position.

The engine stop switch is located at the top of the multifunction switch.




1. *STOP position*
2. *RUN position*

## RF D.E.S.S. KEY AND POST

### *D.E.S.S. Key*

These keys contain an electronic circuit that gives it a unique electronic serial number.

The D. E. S. S. system reads the key code and allows engine starting for keys it recognizes.

This vehicle can be operated using 2 different types of key programming:

– Normal
– Performance

Refer to your authorized Can-Am Off--road dealer for complete information.

The vehicle is delivered with 1 performance key.

**NOTE:**
Additional keys are available from your dealer as an accessory.

**⚠ WARNING**

**Rollovers, tipovers, collisions and loss of control resulting in serious injury or death are possible with the performance or normal key. Using the normal key is not a substitute for the operator being prepared, qualified, and operating with care.**

### Performance Key

The performance key allows the user to access the full torque of the engine as well as the top speed of the vehicle.

This may be useful for riders who prefer crisper throttle response, and for environments where higher speeds and greater acceleration are appropriate.

For example, in wide-open straight trails, operators may prefer the performance key.

### Normal Key

The normal key limits the vehicle rate of acceleration and/or the vehicle speed to 70 km/h (43 MPH).

**⚠ WARNING**

**On steep downhills, the engine speed limiter may not prevent the vehicle from accelerating beyond this speed.**

This key may be useful for riders who prefer more gradual acceleration, or for riding in environments where full speed and high acceleration are not desirable.

For example, in narrow, winding trails, operators may prefer a normal key.

### *D.E.S.S. Flexibility*

The D. E. S. S. of your vehicle can be programmed by your authorized Can--Am Off-road dealer to accept up to 8 different keys.

If you have more than one D. E. S. S. equipped Can-Am vehicle, each can be programmed by your authorized Can-Am Off-road dealer to accept the other vehicle D.E.S.S. keys.

# SECONDARY CONTROLS

Some features may not apply to your model or could be optional.




1. *Throttle lever control housing*
2. *Shifter lever*
3. *Operator's switch of heated grip and heated thumb*
4. *Multifunction switch*
5. *Indicator LEDs*

While reading this Operator's Guide, remember that:

| ⚠ WARNING |
| --- |
| Indicates a potential hazard which, if not avoided, could result in serious injury or death. |

# THROTTLE LEVER CONTROL HOUSING

### *Electronic Throttle Control (ETC)*




1. *4WD position*
2. *6WD position*
3. *6WDLock position*
4. *6WDLock telltale*

## Changing Traction Mode

Before passing in 4WD or in 6WD modes:

1. Stop the vehicle completely.
2. Let the engine idling.
3. Select desired mode.

**NOTICE**

**Front differential damage may occur if the 4WD/6WD selector is used while vehicle is moving.**

To engage or disengage the 6WDLock mode:

1. Make sure 6WD mode is selected.
2. Reduce your speed under 30 km/h (20 MPH).
3. Release the throttle.
4. Momentary fully press the selector up.
5. To disengage the 6WDLock mode, press the selector up again.

When the 6WDLock is activated, the telltale on the throttle lever control housing and the icon in the digital display will turn on and a beep sound will be heard.

**NOTE:**
If the telltale flashes then stays off, the request is not acknowledged. Reduce your speed under 30 km/h (20 MPH), release the throttle and try again.

## 4WD Mode

The engine power is distributed by the rear wheels only.

The transfer between the front wheels is made depending on traction using the Visco-Lok system

To engage the 4WD mode, move the selector **DOWN**.



## 6WD Mode

The engine power is distributed by both the front and the rear wheels.

The transfer between the front wheels is made depending on traction using the Visco-Lok system

To engage the 6WD mode, move the selector **in center**.



## 6WDLock Mode

**⚠ WARNING**

**Changing the direction abruptly can cause loss of control or injury. Never apply the 6WDLock mode before entering a turn or during the turn.**
**The vehicle behavior is modified when the 6WDLock mode is activated.**
**The turning radius is also increased.**

This mode is designed to lock the front differential allowing more traction to free the vehicle from a situation (ex: vehicle caught in mud or other soft terrains).

The engine power is then distributed equally at all 6 wheels.

To engage the 6WDLock mode, move the selector **UP**.

In 6WDlock mode, a speed limiter restricts the vehicle speed to 40 km/h (25 MPH). Refer to *Multifunction Switch* to have more information about how overriding this limitation.

## Driving Modes Selector




*1. Engine modes selector*

The driving modes selector is located on the top of the throttle lever control housing.

2 specific modes can be selected:

– ECO or WORK
– SPORT

The selected mode will be indicated in the Mode Display of the gauge.

Also, when the SPORT mode is activated a beep sound will be heard.

### *ECO or WORK Mode*

The ECO or WORK mode provides a smoother throttle response and is limited to a maximum speed of 70 km/h (43 MPH).

To activate the ECO or WORK mode, toggle the selector towards the LEFT.

Toggle to the RIGHT to deactivate.

### *SPORT Mode*

The SPORT mode provides a crisper throttle response.

This mode can be activated with all key types and provides the maximum power with the used key.

To activate the SPORT mode, toggle the selector towards the RIGHT.

Toggle to the LEFT to deactivate.

**NOTE: On 850, 1000 and 1000R models**, the SPORT mode is automatically disable after the complete shutdown of the digital display.

### Driving Modes Selector




*1. Driving modes selector*

The driving modes selector is located on the top of the throttle lever control housing.

2 specific modes can be selected:

– ECO or WORK
– SPORT

The selected mode will be indicated in the Mode Display of the gauge.

Also, when the SPORT mode is activated a beep sound will be heard.

#### *ECO or WORK Mode*

The ECO or WORK mode provides a smoother throttle response and is limited to a maximum speed of 70 km/h (43 MPH).

To activate the ECO or WORK mode, toggle the selector towards the LEFT.

Toggle to the RIGHT to deactivate.

#### *SPORT Mode*

The SPORT mode provides a crisper throttle response.

This mode can be activated with all key types and provides the maximum power with the used key.

To activate the SPORT mode, toggle the selector towards the RIGHT.

Toggle to the LEFT to deactivate.

**NOTE: On 850, 1000 and 1000R models**, the SPORT mode is automatically disable after the complete shutdown of the digital display.

### Intelligent Engine Braking (iEB) Mode Selector (if equipped)

The Intelligent Engine Braking (iEB) allows to user to adjust the level of the engine braking before or while riding.

**⚠ WARNING**

**The level of engine braking will have an effect on the deceleration rate when the throttle lever is released.**
**It's not recommended to change the iEB setting while performing some actions.**
**These actions include but not limited to the following: braking, turning or when descending.**
**Be ready to use the brake to reduce the speed when needed.**

The iEB selector is located on the back of the throttle lever housing.



Three (3) specific levels are available and the selected mode is indicated in the Mode Display of the gauge.

| Mode | Description | Display message |
|---|---|---|
| Mode 1 | Maximum engine braking | IEB MAX |
| Mode 2 | Medium engine braking | IEB MED |
| Mode 3 | Very low engine braking | IEB MIN |

Use the selector to change the iEB level or showing the selected level in the gauge.

– **Short press (less than 0.5 second)**: Display the current iEB level in the gauge.
– **Long press (more than 1 second)**: Change to the next level.

The level change is sequenced from MAX to MIN at each long press, and returns to MAX after MIN.

After a level change, the message into the gauge shows the new selected level.

When the MAX level is selected and the throttle lever is released, the engine braking alone is slowing down the vehicle significantly, allowing less usage of the brake lever.

With the MIN level, more brake lever input is required to slow down or stop the vehicle.

The last selected level is automatically activated when the vehicle is restarted after a complete shut down.

## SHIFT LEVER

The shift lever is located on the RH side of the vehicle near steering column.

*SHIFT LEVER LOCATION*

The shift lever is used to change the gearbox position.

The shift lever has 5 positions:

| Shift Lever Positions | |
|---|---|
| Position | Gear |
| P | Park |
| R | Reverse |
| N | Neutral |
| H | High range (forward) |
| L | Low range (forward) |

*SHIFT PATTERN*

The vehicle must be stopped and brakes applied prior to selecting any gear.

**NOTICE**

**This gearbox is not designed to shift while vehicle is moving.**

### *Park*

The park position locks the gearbox to help prevent vehicle movement.

**⚠ WARNING**

**Always use the PARK (P) position when the vehicle is not in operation. The vehicle can roll if the shift lever is not set to P (PARK).**

### *Reverse*

The reverse position allows the vehicle to go backwards.

**NOTE:**
In reverse operation, the engine's RPM is limited, thus limiting the vehicle reverse speed.

**⚠ WARNING**

**When driving downhill, gravity can increase the vehicle speed above the set limited speed.**

### *Neutral*

The neutral position disengages the gearbox.

**⚠ WARNING**

**Always use the PARK (P) position when the vehicle is not in operation. The vehicle can roll if the shift lever is set to N (NEUTRAL).**

### *High Range (Forward)*

This position selects the high speed range of the gearbox. It is the normal driving speed range. It allows the vehicle to reach its maximum speed.

### *Low Range (Forward)*

This position selects the low speed range of the gearbox. It allows the vehicle to move slowly with maximum torque at the wheels.

**NOTICE**

**Use the low speed range to pull a trailer, carry heavy cargo, go over obstacles, riding in mud or drive uphill and downhill.**

## MULTIFUNCTION SWITCH




1. *Headlight switch*
2. *Hazard switch*
3. *Flasher signal switch*
4. *Horn button*
5. *START/DPS/OVERRIDE button*
6. *OFF/ACCEL button*
7. *Set (ON)/DECEL button*
8. *Winch switch*

### *Headlight Switch*




1. *Dimmer/Light OFF*
2. *Low beam*
3. *High beam*

**High beam**: Move the switch upwards to select the high beam.

**Low beam**: Position the switch in the center to select the low beam.

**Dimmer / OFF**:

– Momentarily short press: To momentary switch high headlights ON.
– Long press: To turn headlights OFF.

### *Speed Limiter Control (if equipped)*

Speed limiter mode allows the operator to set a maximum speed that cannot be exceeded when riding.

This is useful to help the driver not to exceed certain limit, but it also helps to maintain a more constant speed when performing tasks with the ATV or when riding.

The operator can always vary the speed from 'Stop' position to the set speed using the throttle.

The operator must keep the throttle depressed to maintain its speed.

When the preset speed limit is reached, further movement of the throttle lever will have no effect, but speed can be reduced at any time by releasing the throttle lever.

**⚠ WARNING**

**During riding at constant speed, keep your attention level up to maintain good situational awareness.**
**When riding downhill, vehicle's speed may exceed the set speed. To slow down, release the throttle and apply brake normally.**

### Activating and Adjusting Speed Limiter Mode

There is 2 ways to set the speed limitation to the desired value.

**Before riding (engine on, idling standstill):**

1. Operator can preset the desired speed limitation by doing a long press (hold 1 sec) on the SET (ON)/DECEL button.



*SET (ON)/DECEL BUTTON*

2. When the vehicle is standstill, the speed limitation will automatically be set at the minimum vehicle speed for this function to work.
3. A 'beep' noise will confirm that the setting has been activated.
4. The operator can then increase the value by pressing the OFF/ACCEL button (short press).



*OFF/ACCEL BUTTON*

5. Press the SET (ON)/DECEL button to reduce the speed limit value (short press).



*SET (ON)/DECEL BUTTON*

**When riding (at speed):**

1. When the desired speed is reached, long press (1 sec) on SET(ON)/DECEL button.



*SET (ON)/DECEL BUTTON*

2. A 'beep' noise will confirm that the setting has been activated and the speed limiter indicator will turn on into the digital display.




3. The operator can then increase the value by pressing the OFF/ACCEL button (short press).



*OFF/ACCEL BUTTON*

4. Press SET (ON)/DECEL button to reduce the speed limit value (short press).



*SET (ON)/DECEL BUTTON*

When adjusting the speed limitation using OFF/ACCEL or SET (ON)/DECEL button, the speed will increase or decrease by step.

| Speed | Increase or decrease by step of... |
|---|---|
| Minimum speed to 30 km/h (19 MPH) | 1 km/h (1 MPH) |
| Over 30 km/h (19 MPH) | 2 km/h (2 MPH) |

**Speed Limiter Values**

## Metric Units

| Gear | Minimal Value | Maximal Value |
|---|---|---|
| L | 8 km/h | 70 km/h |
| H | 11 km/h | 100 km/h |

## Imperial Units

| Gear | Minimal Value | Maximal Value |
|---|---|---|
| L | 5 MPH | 44 MPH |
| H | 7 MPH | 62 MPH |

## Limitations

The throttle must be held in to maintain speed.

The speed can be varied normally anywhere from a complete stop (idle) up to the limited set speed using the throttle and brake.

When a speed limitation is activated, the operator can further adjust the speed limit. Press the SET (ON)/DECEL button to reduce speed limit, or the OFF/ACCEL button to increase speed limit.

If the speed limiter is activated when the vehicle speed is under the minimal value, the predetermined minimal value will be set by default.

### Deactivating the Speed Limiter Mode

There are 2 options to deactivate the function:

– Press and hold the OFF/ACCEL button for 1 second.



*OFF/ACCEL BUTTON*

– Press and hold the SET(ON)/DECEL button for 1 second.



*SET(ON)/DECEL BUTTON*

### *Start/DPS/Override Button*

This button has 3 functions.

– Start the engine
– Activate the override function
– Change DPS mode.

## Engine Start Button




Press and hold the button to start the engine.

Release the button as soon as the engine has started.

Refer to *Starting the Engine* in the *Basic Procedures* section.

## Override Function

This function allows to bypass the engine speed limiter when the vehicle is used in reverse or in the 4WDLock mode.

In 4WDLock, the override mode will allow to reach an other speed limitation:

– 60 km/h (37 MPH) in HIGH or LOW gear
– 25 km/h (16 MPH) in reverse.

**⚠ WARNING**

**Make sure the area around the vehicle is clear before using the override mode.**
**The override mode must be used only at low speed and when the vehicle is caught in mud or other soft terrain.**
**Do not use the override mode when driving normally in reverse, this would result in excessive speed,**
**Do not use the override mode when driving normally in 4WDLock, otherwise a loss of control could occur.**

To engage the override function, proceed as follows:

1. Ensure that the vehicle is completely stopped.
2. Press and hold the override/DPS button then press the throttle lever gradually.
3. When using the override function, the gauge will scroll an OVERRIDE message to confirm that the function is activated.
4. To disengage the override function, simply release the override/DPS button.

## DPS Function

This button is also used to change the Dynamic Power Steering (DPS) mode.

For complete information on DPS modes, refer to *Tune Your Ride*.

### *Winch Control Switch*




To let out the cable, press the switch down.

To reel in the cable, press the switch up.

### *Hazard Lights Button*



Push the button aside to activate the hazard lights. Push it on the other side to turn off.

The hazard lights system operates all the turn signals simultaneously. Used when the vehicle is stationary to indicate that the vehicle is temporarily obstructing traffic.

Hazard lights can be activated even when the vehicle electrical system is shut down.

### *Flasher Signal Switch*

Move the switch to the left to activate LH turn signals and to the right to activate RH turn signals.

To stop the turn signals, move the switch back to the middle position.



### *Horn Button*

Push the button to use the horn. It will stop when the button is released.



## OPERATOR'S HEATED GRIPS (If Equipped)

The heated grips have 4 levels of heat.

The heat level is indicated by LEDs above the switch. No LED lit indicates that the heated grips are off.




*1. LED heat level*

Press the switch once to turn on.




*1. Heated grips switch*

Press the switch again to increase the heat level. Each time the switch is pressed, the heat level increases.

To turn off, reach the maximum heat level, then press the switch once more.

## HEATED THROTTLE LEVER (If Equipped)

The heated thumb has 4 levels of heat.

The heat level is indicated by the LEDs above the switch. No LED lit indicates that the heated grips are off.

*1. LED heat level*

Press the switch once to turn on.

*1. Heated throttle lever switch*

Press the switch again to increase the heat level. Each time the switch is pressed, the heat level increases.

To turn off, reach the maximum heat level, then press the switch once more.

## INDICATOR LEDS

| Indicator LEDs | |
|---|---|
| | Trailer Flasher |
| | Position Lights |

While reading this Operator's Guide, remember that:

**⚠ WARNING**

Indicates a potential hazard which, if not avoided, could result in serious injury or death.

## OPERATOR'S SEAT

The seat is designed for an operator only.

**⚠ WARNING**

**Never allow anyone to seat as a passenger on this vehicle.**

### *Removing the Seat*

1. Push the seat latch upward. This latch is located underneath the rear of seat.

*1. Seat latch*

2. Pull seat upward then rearward.
3. Continue lifting movement until you can release the front retaining device then completely remove seat.

### *Installing the Seat*

1. Insert front tabs of seat into steel hooks of frame.
2. When seat rests in its position, firmly push seat down to latch. A distinctive snap will be felt.
3. Double check that the seat is secure by giving it a tug to confirm proper latching.

**⚠ WARNING**

**Ensure operator's seat is properly locked in position by pulling back and up several time. Even if a distinctive snap is heard during the installation, always pull it back and up to confirm proper latching.**

## PASSENGER'S SEAT

**⚠ WARNING**

**Never operate the vehicle without passenger's seat installed. Without its passenger's seat, the vehicle becomes a ONE RIDER vehicle (1-UP model) and NO PASSENGER must be allowed on vehicle.**

The passenger's seat is designed for a passenger only. The integrated backrest supports his back during the ride.




*1. Integrated backrest*
*2. Grab handle*
*3. Passenger's seat*

### *Removing the Passenger's Seat*

1. Pull the passenger's seat latch lever toward the front of the seat.




*1. Seat handle*

2. While maintaining latch lever pulled towards the front, apply downward pressure on the back of latch lever to clear rear latch from pin and toggle seat towards front using backrest.
3. On models with passenger's heated grips and/or heated visor, disconnect the electrical connector located under the seat.
4. Pull seat rearward and up out of location to clear the front tabs.

### *Installing the Passenger's Seat*

1. Ensure the latch lever is in the open position by pulling it towards the front of seat.
2. Using a forward motion, insert both front tabs of the seat into the vehicle anchor housings.
3. On models with passenger's heated grip and/or heated visor, connect the electrical connector located under the seat.
4. Rotate downwards to engage the rear latch.
5. Close the latch lever by pushing it rearwards to secure seat in position.
6. Check if the seat is firmly secured in position before using it.

**⚠ WARNING**

**It is of the upmost importance for the passenger's safety that you confirm that the passenger's seat is properly locked in position by pulling back and up several times.**

## GLOVE BOX

*1. Glove box*

### *Installing the Glove Box*

1. Open glove box cover and turn latch to the unlock position.
2. Align and insert glove box latching system into the vehicle's "LINQ" opening.




1. *Glove box latch*
2. *"LINQ" opening*

3. Turn latch to the lock position.




1. *Latch*

4. Close cover and verify if glove box is locked in position.

### *Removing the Glove Box*

1. Unlock latch on each side of glove box and open lid.
2. Turn latch counter clockwise to unlock.




1. *Latch*

3. Remove glove box.

## FOOTPEGS

The operator footpegs are located on the RH and LH side of the vehicle.

### 1-UP Models

1. *Operator's LH footpeg*

**⚠ WARNING**

**Operator must have both feet on footpegs at all times during vehicle operation.**

### 2-UP Models

The passenger footpegs are located on the RH and LH side of the vehicle behind the operator footpegs.




1. *Operator's LH footpeg*
2. *Passenger's LH footpeg*

**⚠ WARNING**

**Passenger must have both feet on footpegs at all time during vehicle operation.**

## 12-VOLT POWER OUTLET

Convenient for handheld spotlight or other portable equipment.




*1. 12 V power outlet*

Remove protective cap to use. Always reinstall it after use to protect against weather.

## CARGO RACKS

**⚠ WARNING**

- **Never carry a passenger on a cargo rack.**
- **Cargo must never interfere with the drivers line of sight or affect his ability to properly steer the vehicle.**
- **Do not overload the vehicle.**
- **Always ensure all cargo is properly secured and does not extend out pass the racks.**

Always refer to the *Maximum Racks Loading - Warning Label* for cargo weight recommendations.

## GAUGE SUPPORT

### *Removing the Gauge Support*

Lift the rear of gauge support, then push forward.




### *Installing the Gauge Support*

Slide the gauge support backwards to hook the front tabs.

Push the rear of gauge support to secure it.




## TOOL KIT

The tool kit is located under seat. It contains tools for basic maintenance.

## WINCH (If Equipped)

**⚠ WARNING**

**To avoid severe injury or death or important components damages.**

- **Never use the winch cable/ rope to retain a vehicle during trailering.**
- **Never ride with the winch cable/rope attached to a load or another vehicle.**
- **Only use the winch to help a stuck vehicle (snow, mud, etc.).**
- **Always refer to the winch manufacturer's instruction before pulling loads.**

A roller fairlead is used to prevent damages to the vehicle and guide the wire rope into the winch.




1. *Winch*
2. *Roller fairlead*
3. *Winch hook*
4. *Hook strap*

**NOTE:**
Using the winch intensively over a long period of time may discharge the battery.

The following tips will help to reduce the risk of discharging the battery:

**Unwind manually:** Unlock the winch using the handle then pull on the hook strap to unreel.

It is recommended to let the engine run while winching or rewinding. Do not stop the engine immediately after winching to let battery recharge.

Also, when winching for more than 30 seconds, it is recommended to increase engine RPM in the range of 3000 RPM to increase charging power to the battery.

**NOTICE**

**Make sure vehicle is in NEUTRAL (N) before increasing engine RPM.**

Refer to the winch manufacturer's instruction, supplied with the vehicle, for more information about the winch.

## CARGO BED TILT RELEASE HANDLE

The latching mechanism of the cargo bed can be actuated from right side of the vehicle through a release handle.

### *To Tilt Cargo Bed*

Release the hairpin clip.

Pull cargo bed release handle and at the same time lift edge of the cargo bed.




1. *Cargo bed release handle*
2. *Hairpin clip*

### *To Lower Cargo Bed*

To lower the cargo bed, simply push it down into place and secure with hairpin clip.

Refer to *Carrying Loads* in the *SAFETY information* section.

## REAR STORAGE COMPARTMENT

Convenient location to carry personal articles.

*1. Rear storage compartment hatch*

**⚠ WARNING**

**Always engage the PARK position on the shift lever before opening cover. Never leave any heavy or loose breakable objects in the storage area. Always latch cover before riding.**

### *To Open Rear Storage Compartment*

#### To Open Storage Compartment Hatch

Unlatch storage compartment hatch.




***PULL LATCHES UPWARDS***

*1. Rubber latches*

Lift and tilt it rearwards.



#### To Open Storage Compartment Cover

Pull, lift and remove the storage compartment cover.




### *To Close Rear Storage Compartment*

#### To Close Storage Compartment Hatch

Gently pull, lift and push hatch into place.

Lock latches.

### To Close Storage Compartment Cover

Reverse from opening procedure.

## RECOVERY HOOK

Convenient hook that can be use to recover a stuck ATV.




*1. Front recovery hook*

*1. Rear recovery hook*

## CARGO BOX ANCHORING HOOKS

To provide anchoring point to secure cargo inside the cargo bed, 4 anchoring hooks are located inside the cargo area.

## REAR BOX SIDE WALL

### *Side Walls and Tail Gate Removal*




*1. Side wall*
*2. Tail gate*

1. Open tail gate latches.




2. Lower tail gate.

**NOTE:**
Do not remove tail gate yet.



3. Remove locking handle hairpin clips from both sides.



4. Remove locking handles from both sides.



5. Lift side wall up and remove it.

   Repeat on other side.



**⚠ WARNING**

**Make sure to remove the side walls before tail gate.**

6. Remove tail gate.



7. Replace locking handles in their original position.



8. Secure with hairpin clip.



### *Side Walls and Tail Gate Installation*

1. Remove locking handle hairpin clips from both sides.



2. Remove locking handles.



3. Place side wall on flat bed and lower it on its place.

   Repeat on other side.



4. Place locking handles.



5. Secure with hairpin clip.



6. Install tail gate.



**⚠ WARNING**

**Make sure you do not leave any objects or hands between lifted tail gate and side walls to ensure proper latching of the tail gate.**

7. Close tail gate latches.




**⚠ WARNING**

**Make sure you do not leave hands between latches and tail gate.**

## TRAILER HITCH

Convenient hitch to install a ball to tow a trailer or other equipment. Install the proper ball size as per trailer manufacturer recommendations.

Refer to the *Towing and Tongue Weight - Warning Label* for carrying loads and towing recommendations.




1. *Trailer hitch*
2. *Safety label*




***TYPICAL***

1. *Trailer hitch*

**⚠ WARNING**

**Ensure to install the proper ball size that matches the equipment you will tow.**

**NOTE:**
Follow manufacturer's instructions for proper attachment.

## TRAILER CONNECTOR

Trailer connector to be used if trailer is equipped with lights.

For towing refer to towing instructions label located at trailer hitch.

When a trailer is connected and the turn signals or hazard lights are in function, an indicator lamp located on the handlebar cover, blinks. Refer to *Indicator LEDs*.

**NOTE:**
The Trailer Flasher Module is designed for trailer lights of a total of 40W. If the trailer lights have a different power, the blink frequency will be affected.

*1. Trailer connector*

## LICENSE PLATE LIGHT

Provides lighting for the license plate.



# 4.5” DIGITAL DISPLAY

## MULTIFUNCTION DISPLAY

### Lower Display

May display the following:

– RPM
– Speed statistics
– Engine Temperature
– Battery Voltage
– Settings
– Messages

Use LOWER button to change the displayed information.




1. *Upper button*
2. *Lower button*

### Left Lateral Display




The left lateral display includes:

– Fuel level indicator

### Right Lateral Display




The right lateral display includes:

– Engine Temperature
– 4X4 / 6X6 telltale

| Icon | Description |
|---|---|
| 4X4 | 4X6 icon |
| 6X6 | 6X6 icon |

### Central Display

The central display includes:

– Vehicle speed in km/h or mph or RPM.
– Track kit Active (if equipped)

### Transmission Position Display




This display shows gear position of gearbox:

– P (Park)
– R (Reverse)

– N (Neutral)
– H (High Range)
– L (Low Range)
– – (Invalid Range)

## Engine Mode Display




The engine mode display indicates the selected mode of operation:

– ECO or WORK (as per vehicle configuration)
– SPORT

To change between modes, hold LOWER button and short press LOWER button to cycle through available modes.

| Engine Mode | Message at Activation |
|---|---|
| Eco | ECO MODE |
| Work | WORK MODE |
| Sport | SPORT MODE |

## Trip Display




This display shows trip information:

– Cumulative distance odometer
– Trip A
– Trip B
– Vehicle hour meter
– Clock

Use UPPER button to change the displayed information.

Hold UPPER button to reset Trip A/B meters.




*1. Upper button*
*2. Lower button*

## Indicator Lamps

## Warning and Telltale Lights

| WARNING and Telltale Lights | |
|---|---|
| | GREEN - Flashers |
| | Hazard Warning Flasher - All front and rear turn signals will flash |
| | ORANGE - Vehicle Malfunction |
| | BLUE - High Beam |
| | RED - The engine temperature is too high. |
| | GREEN - Neutral |
| | RED - Brake lock lever is engaged or malfunction of the brake system |

| WARNING and Telltale Lights | |
|---|---|
| | RED - The battery voltage too low or problem with the electrical system |
| | RED - Low oil pressure Normally ON when engine is OFF |
| | ORANGE - Low fuel level |
| | ORANGE<br>**Turn on**: Malfunction of the vehicle emissions control system<br>**Blink**: Engine problems, the limp home mode is activated. Have the vehicle serviced immediately. |

## Icons and Indicators

| Icons and Indicators | |
|---|---|
| SPORT | – Denotes SPORT mode is selected. |
| WORK | – Denotes WORK mode is selected. |
| | – When lit, indicates that a maintenance is required.<br>– See your authorized Can-Am Off-road dealer or person of your own choosing for the maintenance. |
| | – Track kit active (when installed). |
| | – Denote front differential lock - Visco-4Lok is activated. When this option is available. |
| | – Denotes Speed Limiter is selected.<br>– When this option is available. |

## SETTINGS

The buttons to navigate through menus are located on the left side of the LCD display.




*1. Upper button*
*2. Lower button*

### *Setup*

Using LOWER button, select **SETTINGS** and hold to enter setting menu.

### *Speed Limiter Mode*

### *If available*

Speed limiter mode allows the operator to set the desired maximum speed.

This is useful when operating in limited speed zones.

The operator must keep the throttle depressed to maintain forward speed.

Once the maximum speed is set, the operator can vary vehicle speed from stopped to the set speed using the throttle.

The set speed will be exceeded when the throttle is fully depressed. At that time, the speed limiter will be temporary deactivated (the icon will blink) until vehicle speed is under or equal the speed limiter's set point.

As you proceed under a constant speed setting, keep your attention level up to maintain good situational awareness.

Slowing down is a matter of releasing the throttle.

### Activating Speed Limiter Mode

1. Press the gauge switch to go to the SETTINGS menu.
2. Select SPEED LIM, then you will have a choice of:

| Unit selection | Information displayed |
|---|---|
| Metric (km/h) | – - - (Unlimited)<br>– From 30 km/h to 100 km/h by step of 10 km/h. |
| Imperial (MPH) | – - - (Unlimited)<br>– From 20 MPH to 65 MPH by step of 5 MPH. |

The speed limiter indicator will turn on.




3. Hold menu button to confirm selected speed limit.

   Activating speed limiter mode of operation only limits the maximum speed available when depressing the throttle.

   The throttle must be held in to maintain forward speed.

   Speed can be varied from idle up to the set speed using the throttle once the speed limiter function is activated.

### Deactivating Speed Limiter Mode

1. To deactivate speed limiter mode, in SETTINGS, select SPEED LIM and then select the – (unlimited) limit.

### *Maintenance Reset*

To reset the maintenance message, refer to *Resetting the Message: Maintenance Required* in the *Maintenance Procedures* section.

**NOTE:**
Available only when the maintenance is due (after every 100 engine hours).

### *Fault Codes*

Available only when at least one code is activated.

Using LOWER button, select **CODES** and hold to see actives fault codes.

Fault codes will be scrolled on the Lower Display.

### *Reset Stats*

Using LOWER button, select **RESET STAT** and hold to reset.

### *Unit Selection*

This multifunction gauge is factory preset in Imperial units but it is possible to change it to Metric units.

Using LOWER button, select **UNITS** and hold button to change units.

### *Setting Clock*

All of the following action must be performed using the LOWER button.

1. Select **CLOCK** and hold to adjust clock.
2. Press the button to select clock display.
3. Push and hold the button for 1 second.
4. Press the button to select 12:00 AM PM or 24:00 time base.
5. Push and hold the button to acknowledge selection.
6. Press the button to change hours (hours flash).
7. Push and hold the button to acknowledge hour selection.
8. Press the button to switch to minutes (minutes flash).
9. Push and hold the button to acknowledge minutes selection.

### *Setting Language*

The gauge display language can be changed.

Refer to an authorized Can-Am dealer for language availability and to setup the gauge to your preference.

### *Setting Brightness*

The brightness of the LCD display can be adjusted.

Using LOWER button, select **BRIGHTNESS** and hold button to change brightness.

Using LOWER button, adjust brightness then push and hold the button to acknowledge selection.

# FUEL

While reading this Operator's Guide, remember that:

**⚠ WARNING**

Indicates a potential hazard which, if not avoided, could result in serious injury or death.

## Fuel Requirements

**NOTICE**

**Always use fresh gasoline. Gasoline will oxidize; the result is loss of octane, volatile compounds, and the production of gum and varnish deposits which can damage the fuel system.**

Alcohol fuel blending varies by country and region. Your vehicle has been designed to operate using the recommended fuels, however, be aware of the following:

- Use of fuel containing alcohol above the percentage specified by government regulations is not recommended and can result in the following problems in the fuel system components:
  - Starting and operating difficulties.
  - Deterioration of rubber or plastic parts.
  - Corrosion of metal parts.
  - Damage to internal engine parts.
- Inspect frequently for the presence of fuel leaks or other fuel system abnormalities if you suspect the presence of alcohol in gasoline exceeds the current government regulations.
- Alcohol blended fuels attract and hold moisture which may lead to fuel phase separation and can result in engine performance problems or engine damage.

### *Recommended Fuel*

The gasoline must have the following minimum octane requirements:

Common unleaded gasoline with an AKI (R+M)/2 octane rating of 87, or a RON octane rating of 91

Use unleaded gasoline containing MAXIMUM 10% ethanol.

**NOTICE**

**Never experiment with other fuels. Engine or fuel system damages may occur with the use of an inadequate fuel.**

**NOTICE**

**Do NOT use fuel from fuel pumps labeled E85.**

## Vehicle Fueling Procedure

**⚠ WARNING**

- **Fuel is flammable and explosive under certain conditions.**
- **Never use an open flame to check fuel level.**
- **Never smoke or allow flame or spark in vicinity.**
- **Always work in a well-ventilated area.**
- **Vehicle must be on a level surface to perform fueling.**

1. Stop engine.

**⚠ WARNING**

**Always stop engine before refueling.**

2. Have operator and/or passenger get off vehicle.

**⚠ WARNING**

**Do not allow anyone to remain in the vehicle while fueling. If there is a fire or explosion during fueling, a vehicle occupant could be unable to quickly leave the area.**

3. Unscrew slowly the fuel reservoir cap counterclockwise to remove it.




*1. Fuel reservoir cap*

**⚠ WARNING**

**If a differential pressure condition is noticed (whistling sound heard when loosening fuel reservoir cap) have vehicle inspected and/or repaired before further operation.**

4. Insert the spout into the filler neck.
5. Pour fuel slowly so that air can escape from the tank and prevent fuel flow back. Be careful not to spill fuel.
6. Stop filling when the fuel reaches the bottom of filler neck. **Do not overfill.**

**⚠ WARNING**

**Never top up the fuel tank before placing the vehicle in a warm area. As temperature increases, fuel expands and may overflow.**

7. Fully tighten fuel reservoir cap clockwise.

**⚠ WARNING**

**Always wipe off any fuel spillage from the vehicle.**

# BREAK-IN PERIOD

While reading this Operator's Guide, remember that:

**⚠ WARNING**

Indicates a potential hazard which, if not avoided, could result in serious injury or death.

## Operation During Break-In

A break-in period of 10 operating hours or 300 km (200 mi) is required for the vehicle.

### *Engine*

During the break-in period:

- Avoid full throttle operation.
- Avoid pressing the throttle lever more than 3/4 of the stroke.
- Avoid sustained accelerations.
- Avoid prolonged cruising speeds.
- Avoid engine overheating.

However, brief accelerations and speed variations contribute to a good break-in.

### *Brakes*

**⚠ WARNING**

**New brakes will not operate at their maximum efficiency until their break-in is completed. Braking performance may be reduced, so use extra caution.**
**Apply moderate braking force for the 40 to 50 first braking events.**

### *Belt*

A new belt requires a break in period of 50 km (30 mi).

During the break-in period:

- Avoid strong acceleration and deceleration.
- Avoid pulling a load.
- Avoid high speed cruising.

While reading this Operator's Guide, remember that:

**⚠ WARNING**

Indicates a potential hazard which, if not avoided, could result in serious injury or death.

## Waking Up the Electrical System

Press and release the START button for less than half a second and the electrical system will turn ON:

- For 30 seconds, **without** powering any equipment:
  - With the D.E.S.S. key not installed or ignition key in the OFF position, **OR**
  - With the Engine Stop switch sets to the STOP position
- For 10 minutes, powering equipment:
  - With the D.E.S.S. key installed or the ignition key in the ON position, **AND**
  - With the Engine Stop switch sets to the RUN position.

  The electrical system will be shutdown after 30 seconds if either the D.E.S.S. key or the ignition key is removed **OR** the Engine Stop switch is set to the STOP position.

***NOTICE***

**Waking up the electrical system repeatedly or using electrical equipment will discharge the battery and you may not be able to start the engine.**

## Starting the Engine

The shift lever must be set to PARK or NEUTRAL.

**NOTE:**
For your convenience, an override mode allows the engine to be started with the shift lever in any position. Press and hold the brake lever or the brake pedal while pressing the engine start button.

Depending your model:

- Install the D.E.S.S. key on the D.E.S.S. post, or
- Insert the key into the ignition switch and turn to the ON position.

Set the engine stop switch to RUN.

Press the engine start button and hold until the engine starts.

Release the engine start button immediately when the engine has started.

***NOTICE***

**If engine does not start after a few seconds, do not hold the start position more than 10 seconds. Refer to *Troubleshooting*.**

## Stopping the Engine

**⚠ WARNING**

**Avoid stopping the vehicle:**

- **On steep slope as the vehicle may roll away.**
- **In an area where hot parts of the vehicle can start a fire.**

**⚠ WARNING**

**Always apply the parking brake when stopping the vehicle.**

1. Select the flattest terrain available.
2. Stop the vehicle completely.
3. Apply the parking brake.
4. Use the vehicle engine stop switch to stop the vehicle.
5. Depending your vehicle:
   - Remove the D.E.S.S. key from the D.E.S.S. post, or
   - Place ignition key to the OFF position then remove it from the ignition switch..
6. When parking on a steep incline or if the vehicle is carrying cargo, block the wheels using wheel chocks. If not available use rocks or bricks.

## Applying the Parking Brake

Application of the parking brake is the combination of the 2 following actions.

1. After stopping completely the vehicle, move the shifter lever to the PARK position, AND...
2. Engage the brake lock lever, refer to *Brake Lock Lever* in *Primary Controls*.

**NOTE:**
When parking on a steep incline or if the vehicle is carrying cargo, block the wheels using wheel chocks. If not available use rocks or bricks.

## Changing Gear Selection

Apply brakes and immobilize vehicle, then select the desired shift lever position.

Release brakes.

| NOTICE |
| --- |
| **When changing gear selection, always completely stop the vehicle and apply the brakes prior to shifting. Damage to the gearbox may occur.** |

Gradually press the throttle lever to increase engine speed and thus engaging the continuously variable transmission (CVT).

At the opposite, when the throttle lever is released, the engine speed decreases.

## Fuel Flooded Engine

If the engine does not start and it is fuel-flooded, this special mode can be activated to prevent fuel injection and to cut ignition while cranking. Proceed as follows:

1. Move shift lever in park position.
2. Install key on D.E.S.S. post or turn the ignition key in ON position.
3. Press completely and HOLD throttle lever.
4. Press the engine START button for 20 seconds.
5. Release throttle lever.
6. Press the START button again to allow starting.

If the engine does not start:

1. Unplug injector electrical connector
2. Clean the spark plug caps area then remove them.
3. Remove the spark plugs.
4. Crank engine several times.
5. Install new spark plugs if possible or clean and dry spark plugs.
6. Start engine as explained above.

If engine continues to flood, see an authorized Can-Am Off-road dealer.

**NOTICE**

**Verify that there is no fuel in engine oil. If so, replace engine oil.**

## Water Into the CVT

The CVT drain plug is located on the rear portion of the CVT cover. It is accessible from the rear LH fender.

**NOTICE**

**If water is present in the CVT, it could result in belt slippage. The engine will accelerate but the vehicle will remain still.**

**NOTICE**

**See an authorized Can-Am Off--road dealer to have the CVT inspected and cleaned.**

1. Inspect the CVT drain reservoir to validate if water is present.




***NEAR LH FOOTREST***

*1. CVT drain reservoir*
*2. Spring clamp*

2. If so, remove the CVT drain reservoir to expel water.
3. Reinstall the CVT drain reservoir and secure it using the spring clamp. Make sure reservoir is properly inserted on the CVT cover nipple.

## Water Into the Air Filter Housing

1. Remove the LH side panel.

2. Inspect the drain reservoir underneath the air filter housing to validate if water is present.




*TYPICAL*

*1. Air filter housing drain reservoir*

3. If water is present, press clamp and remove reservoir to drain water from air filter housing.
4. If one of the following conditions is met, bring the vehicle to your nearest authorized Can-Am Off-road dealer to have the vehicle serviced:
   - If more than 50 ml (2 fl oz (US)) of water (approximately 5 drain reservoirs) is found in the air filter housing.
   - If any deposits are present in the drain reservoir.

   In such a case, the vehicle must be serviced for:
   - Vents
   - CVT air filter cleaning
   - CVT cleaning
   - Fuel tank breather replacement
   - Lubricant inspection and replacement as required (engine, gearbox and rear final drive).

**NOTICE**

**Failure to have vehicle serviced may lead to permanent damage to the following components but not limited to:**
- **Engine and gearbox**
- **Fuel pump**
- **CVT**
- **Front differential**
- **Rear final drive.**

## Vehicle is Turned Over

1. When vehicle is turned over or stays tilted on the side, put the vehicle back on its wheel.
2. Inspect vehicle for damages.

**⚠ WARNING**

**Never operate the vehicle if damaged.**
**Refer to an authorized Can-Am Off-road dealer.**

3. If vehicle has no damage, refer to *Maintenance Procedures* and inspect the following:
   - Inspect air filter housing for oil accumulation, if any oil is found, clean air filter and air filter housing.
   - Check engine oil level and refill if necessary.
   - Check engine coolant level and refill if necessary.
   - Check gearbox oil level and refill if necessary.
   - Check rear final drive oil level and refill if necessary.
   - Start engine. If the oil pressure light stays on, stop engine immediately. See an authorized Can-Am Off-road dealer.
4. Whenever the vehicle is turned over, it should be inspected by an authorized Can-Am Off-road dealer.

## Vehicle is Immersed in Water

Should the vehicle become immersed, immediately stop the engine.

Do not use any electrical equipment, including the winch.

It will be necessary to take the vehicle to an authorized Can-Am Off-road dealer as soon as possible. **NEVER**

## ATTEMPT TO START THE ENGINE!

**NOTICE**

**Immersion of the vehicle can cause serious damage if the correct restart procedure is not followed.**

As soon as vehicle is pulled out of water, carry out the following:

– Drain air filter housing, refer to *Water Into the Air Filter Housing*.
– Drain CVT, refer to *Water Into the CVT*.

**NOTICE**

**The vehicle should be serviced as soon as possible by an authorized Can-Am dealer.**

# TUNE YOUR RIDE

While reading this Operator's Guide, remember that:

**⚠ WARNING**

Indicates a potential hazard which, if not avoided, could result in serious injury or death.

**⚠ WARNING**

**Suspension adjustment could affect vehicle handling.**
**Always take time to familiarize yourself with the vehicle's behavior after any suspension adjustment has been made.**

Following are guidelines to fine-tune suspension.

Use suspension adjustment tool provided in the tool kit.



## Usage of Unlockable Stabilizer Bar

Keep stabilizer bar locked on both sides when driving on flat terrain. It will reduce the tilting of the vehicle on winding trails.




*1. Stabilizer bar pin locked*

Unlock stabilizer bar from both sides for off-road operations and when operating at high speed on bumpy trails.

It will provide independent travel of the suspension which will help to keep more wheels in contact with the ground and provide improved traction.

Stabilizer bar parts may be damaged if stabilizer bar is used at high speeds on bumpy trails.

Removed stabilizer bar pins can be stored in glove box.

**⚠ WARNING**

**Reduce your speed when carrying cargo and turn gradually.**
**Avoid hills and rough terrain.**
**Allow more distance for braking.**
**This vehicle may require additional stopping distance if carrying heavy loads, especially on inclined surfaces.**

## Suspension Adjustment – Factory Settings

Suspension adjustment and loading can have an effect on your vehicle handling and comfort.

Choice of suspension adjustments vary with driver's weight, personal preference, riding speed and field condition.

**NOTE:**
Factory settings are suitable for almost all conditions. Take into consideration that an increase in ground clearance can affect the handling of the vehicle.

## Front Suspension

| Spring Preload | |
|---|---|
| All models | Cam position 3 |

## Rear Suspension

| Spring Preload | |
|---|---|
| All models | Cam position 3 |

### *Spring Preload Adjustment*

**⚠ WARNING**

**The left and right shock adjustment on front or rear suspension must always be set to the same position.**
**Never adjust one shock only.**
**Uneven adjustment can cause poor handling and loss of stability, which could lead to an accident.**

Shorten the springs for a firmer ride and rough conditions.

Lengthen the springs for a softer ride and smooth conditions.




*TYPICAL*

1. *Adjustment cam*
2. *Softer adjustment*
3. *Firmer adjustment*

## Dynamic Power Steering (DPS) Assist Level Adjustment (Models with DPS)

The DPS mode cannot be changed if the transmission lever is set to REVERSE.

The tri-mode Dynamic Power Steering (DPS) offers easy steering assistance to the rider. The level of assistance will automatically adapt according to the vehicle's speed and rider’s demand, in order to provide maximum steering power at lower speed where the demand is normally higher. As speed increases, the assistance is progressively reduced to keep maximum steering feel and precision to the rider.

It is possible to choose between three modes of assistance: Minimum, Medium and Maximum. Each mode will continue to automatically adapt to the vehicle’s speed and rider’s demand, so it does not require to be changed when riding. These modes are used to set the level of assistance to match each rider's preferences.

The following DPS modes are preset in the vehicle.

| DPS MODE | |
|---|---|
| DPS MAX. | Maximum steering assist |
| DPS MED. | Medium steering assist |
| DPS MIN. | Minimum steering assist |

To change the DPS mode using the multifunction switch, the engine must be running. Wake up the electrical system is not enough to do this procedure.

To see which DPS mode is activated.

– Do a short press (1 second) on the DPS button.




– Repress on the same button to return to previous screen.

To change the DPS mode.

– Do a short press (1 second) on the DPS button to see which DPS mode is activated.
– Do a long press (2 seconds) on the DPS button to select another mode. Repeat until the desired mode is activated.

**NOTE:**
It is also possible to change the DPS mode by doing a long press on either the LOWER button of the cluster or on the TRIP/MENU switch (depending your model). To do this, the engine does not need to be running, but the electrical system must be awake.

# LIFTING THE VEHICLE

## General Safety Information for Lifting

1. Engage the 6WD mode.

**NOTE:**
6WD mode is engaged when engine is running and vehicle has moved about one meter.

2. Place the shift lever in PARK.
3. Lock the brakes.




*1. Apply brakes*
*2. Lock brakes*

4. Lift the vehicle using a suitable lifting device.

   The following label will be near the lifting points.




***ON SIDE OF CHASSIS - FRONT AND REAR***

**⚠ WARNING**

**Ensure all wheels are locked before lifting the vehicle. Do not exceed the lifting device capacity. Use only a device approved for lifting this type of vehicle. Do not move the vehicle using a lifting device. Refer to the manufacturer warnings and instructions prior to use.**

***TYPICAL — FRONT LIFTING POINT***

***TYPICAL — REAR LIFTING POINT***

## Lifting the Entire Vehicle

1. Place the vehicle on a firm level surface.
2. Place the shifter lever to P position and engage the brake lock lever.
3. Use a suitable lifting device and lift the front of the vehicle.
4. Secure the vehicle laterally using jack stands on the stabilization points.




*1. Front of vehicle*
*2. Front lifting point*
*3. LH stabilization point*
*4. RH stabilization point*
*5. Rear lifting point*

5. Lift the rear of the vehicle.
6. Adjust the height of the jack stands.

**⚠ WARNING**

**Never lift the front AND rear of the vehicle without securing the stabilization points. Never lift the vehicle only by the stabilization points.**

# TRANSPORTING THE VEHICLE

When contacting a towing or transporting service, be sure to ask if they have a flatbed trailer, loading ramp or power ramp to safely lift the vehicle and tie-down straps. Ensure the vehicle is properly transported as specified in this section.

**NOTICE**

**Do not tow this vehicle — towing can seriously damage the vehicle's drive system.**

**NOTICE**

**Avoid using chains to tie the vehicle — they may damage the surface finish or plastic components.**

**⚠ WARNING**

**To avoid severe injury or death or important components damages.**

- **Never use the winch cable/ rope to retain a vehicle during trailering.**
- **Never ride with the winch cable/rope attached to a load or another vehicle.**
- **Only use the winch to help a stuck vehicle (snow, mud, etc.).**
- **Always refer to the winch manufacturer's instruction before pulling loads.**

**⚠ WARNING**

**Make sure all seats, accessories, cargo and loose objects inside the vehicle are properly secured, or remove it to prevent from failing on the road and creating a hazard for following vehicles.**

**⚠ WARNING**

**Always transport the vehicle facing forward to avoid damaging the windshield or other components. Parts may detach during transport.**

**⚠ WARNING**

**Before attempting to mount vehicle onto a platform or a trailer, make sure to respect the following safety precautions.**

| SAFETY PRECAUTIONS | |
|---|---|
| Carrying equipment | The carrying item (platform or trailer or flat bed) must be of appropriate dimensions and capacity to safely support and transport the vehicle. |
| Hauling vehicle | Do not exceed vehicle hauling capacity and specifications. Ensure the trailer or platform is properly secured to the hauling vehicle hitch. |
| Visibility | Ensure you have a good visibility during the entire maneuver. |
| Terrain | The hauling vehicle and trailer must be on a leveled surface. Use wheel chocks on trailer and hauling vehicle to avoid any movement. |
| Ramps | Use ramps with proper rating and secure ramps to the trailer or platform. Avoid steep ramps. |

| SAFETY PRECAUTIONS | |
|---|---|
| Bystanders | Always make sure bystanders are not close to the vehicle or the trailering equipment while climbing up. |
| Seat and Accessories | Make sure all seats, accessories and cargo are properly secured, or remove it to prevent from falling on the road and creating a hazard for following vehicles. |

## Using Vehicle Power to Climb Onto Trailering Equipment

**When vehicle can climb on its own power, proceed as follows;**

1. Wear protective gear.
2. Use low gear only (if equipped).
3. When driving remain seated at all times.
4. Ensure proper alignment on rails or platform.
5. Start from a sufficient distance from the trailer to align the vehicle in a straight line with the ramps. Never attempt to turn while getting closer to the ramp. Rear wheels might not be aligned once you get to the ramp and vehicle may fall off.
6. Slowly climb the front wheels onto the ramp to verify alignment.
7. Back off the vehicle, verify ramps are still secure, then proceed at proper speed.
8. Carefully drive vehicle onto platform or trailer. Use sufficient speed to climb without spinning or abruptly accelerating. Avoid acceleration while on ramps to prevent ramps movement.
9. If trailer is inclined towards front, simply let vehicle roll in without acceleration.
10. Once vehicle is climbed, put shift lever to Park. Apply brake locking mechanism (if equipped).

    **When vehicle cannot move on its own power, or in case overshooting is a risk or if any dangerous condition prevents for embarking on its own power, proceed using a winch;**

## Using a Winch to Pull Vehicle Onto Trailering Equipment

**When vehicle cannot climb on its own power, proceed as follows;**

**⚠ WARNING**

**Have the help of an assistant. One person should be in vehicle to have access to vehicle steering, brakes and winch switch, while the other person controls the environment and safety of the maneuver.**

**⚠ WARNING**

**Ensure the winch hook can be safely attached to a proper anchoring point. Use proper rigging.**

**NOTE:**
If vehicle can be started safely, let engine idle during winching to avoid draining the battery.

1. Place shift lever to NEUTRAL (N).
2. If the vehicle is equipped with a winch, use the winch to roll the vehicle on the platform.
3. If the vehicle is not equipped with a winch, proceed as follows:
    1. Attach strap to lower front bumper anchor.
    2. Attach the strap to the winch cable of the towing vehicle.
    3. Pull the vehicle on the flatbed trailer with the winch.
4. Put shift lever to Park. Apply brake locking mechanism (if equipped).

## Securing Vehicle for Transport

When transporting this vehicle, secure it to a trailer or in pickup box with suitable tie-downs. Use of ordinary ropes is not recommended.

**⚠ WARNING**

**To avoid severe injury or death or important components damages.**

- **Never use the winch cable/ rope to retain a vehicle during trailering.**
- **Never ride with the winch cable/rope attached to a load or another vehicle.**
- **Only use the winch to help a stuck vehicle (snow, mud, etc.).**
- **Always refer to the winch manufacturer's instruction before pulling loads.**

**⚠ WARNING**

**Do not tow this vehicle behind a car or other vehicle. Use a trailer. Never tip this vehicle on end for transporting. The vehicle must be in its normal operating position (on all wheels).**

Remember to:

- Unload vehicle racks before transportation.
- Ensure seat(s) is/are properly locked in position by pulling back and up several time.
- Set the shift lever to PARK position.
- Engage the brake lock lever.
- Secure the vehicle by the front and rear tie-down points.

**⚠ WARNING**

**Make sure all seats, accessories and cargo are properly secured, or remove it to prevent from falling on the road and creating a hazard for following vehicles.**



*FRONT TIE-DOWN POINT LOCATION*

*TYPICAL*

*1. Rear tie-down point location*

***NOTICE***

**Securing vehicle at other locations may damage the vehicle.**

## Getting Vehicle Out of Trailer

**⚠ WARNING**

**Vehicle may have moved during transport. Ensure vehicle is properly aligned with ramps before proceeding.**

**⚠ WARNING**

**Visibility will be greatly reduced when backing off from the trailer. Have the help of an assistant to ensure proper alignment and safe environment.**

# MAINTENANCE

# MAINTENANCE SCHEDULE

Maintenance is very important for keeping your vehicle in safe operating condition. The vehicle should be serviced as per the maintenance schedule.

Proper maintenance is the owner's responsibility. A warranty claim may be denied if, among other things, the owner or operator caused the problem through improper maintenance or use.

Perform periodic checks and follow the maintenance schedule. **The maintenance schedule does not exempt the pre-ride inspection**.

Verifying fault codes, as first maintenance step, is a good practice and is highly recommended.

**⚠ WARNING**

**Failure to properly maintain the vehicle according to the maintenance schedule and procedures can make it unsafe to operate.**

## Post Operation Care After Each Use in an Extreme Environment

- Rinse the entire vehicle with fresh water.
- Clean the CVT air filter(s).
- Drain the CVT cover. Remove the cover and clean if water or mud is found.
- Inspect the engine air filter. Clean the engine air filter housing if water or mud is found.
- Visually check if any water is present into the vent hose of the gearbox, the front differential and the rear final drive. Bring the vehicle to your authorized Can-Am Off-road dealer for inspection and servicing if water is found.
- Clean shock absorber to prevent damage from dust or dirt.
- Clean the drive shaft bellows.

## Severe Duty Conditions

If your vehicle is used in the following conditions, refer to the **SEVERE DUTY** table of the maintenance chart:

- Repeated hauling loads at more than 75% the maximum capacity.
  - The increased workload applied to the drive system accelerates the differential, gearbox / transmission, and engine oil life. This reduces internal component longevity if not replaced more frequently.
- Driving at excessive speeds for a prolonged amount of time.

Higher than average utility / commercial use requires more frequent fluid / wear component replacement than regular trail, recreational, or occasional utility purposes.

### *Air Filter Maintenance Guideline*

Air filter maintenance should be adjusted according to riding conditions.

Air filter maintenance must be increased in frequency in the following dusty conditions:

- Riding on dry sand
- Riding on dry dirt covered surfaces

– Riding on snow covered surfaces
– Riding on dry gravel roads or similar conditions.

Riding in a group under these conditions increases the frequency of the air filter maintenance.

**NOTE:**
An accessory pre-filter should be used to avoid snow accumulation when the vehicle is used in such conditions. Contact an authorized Can-Am dealer for details.

## Deep Mud / Water Use

Whether your vehicle is a X mr model or was accessorized for deep mud / water use, this type of usage requires more frequent maintenance and inspections to ensure debris has not infiltrated mechanical components.

If you regularly ride in deep mud or water, refer to the *Deep Mud / Water* section of the maintenance schedule.

After every ride, be sure to perform the *Post Operation Care for Deep Mud / Water Environment* .

### *Post Operation Care for Deep Mud / Water Environment*

– Rinse the vehicle and its components with fresh water.
– Clean the CVT air filters.
– Drain the CVT compartment and clean if any water or mud is found.
– Inspect and clean engine air filters and engine air filter housing.
– Clean debris around exhaust pipe and muffler area and the spark arrester.
– Clean radiator.
– Visually inspect for any water accumulation in the vent hoses (fuel tank, gearbox, front differential and rear final drive). If there is water, bring the vehicle to your nearest authorized Can-Am off-road dealer for inspection and servicing of main components related to the vents.
– Clean front and rear shock absorbers to prevent seal from damage by dust or dirt.
– Clean drive shaft bellows and the propeller shaft yokes or boots.

## Maintenance Schedule

Make sure to perform proper maintenance at recommended intervals as indicated in the tables.

The maintenance chart intervals are based on 3 factors:
– Calendar time
– Vehicle hours
– Odometer reading.

Take in account whichever comes first to determine the maintenance threshold.

Your driving habits determines the factors you shall adhere too. For example:
– Someone who uses their vehicle every other weekend trail riding with friends would most likely follow the **odometer reading** to determine the maintenance interval.

– Someone who uses their vehicle seldomly over the year or only on a few occasions (hunting, camping) would most likely follow the **calendar time** to determine the maintenance interval.
– Someone who uses their vehicle daily / weekly for long periods of time such as agricultural / work would most likely follow the **vehicle hours** to determine the maintenance interval.

**IMPORTANT**: The following tables show the appropriate maintenance application for the first 3 years. For subsequent years, repeat the same pattern alternatively.

| Regular Maintenance Overview | | | |
|---|---|---|---|
| Calendar Years | Vehicle Hours | Odometer | Regular Duty |
| 1 | 100 | 3000 km (1900 mi) | **A** |
| 2 | 200 | 6000 km (3700 mi) | **A** and **B** |
| 3 | 300 | 9000 km (5600 mi) | **A** |

| Severe Duty and Mud/Water Maintenance Overview | | | |
|---|---|---|---|
| Calendar Years | Vehicle Hours | Odometer | Severe Duty and Deep Mud / Water |
| 0.5 | 50 | 1500 km (900 mi) | **A+** |
| 1 | 100 | 3000 km (1900 mi) | **A+** and **A** |
| 1.5 | 150 | 4500 km (2800 mi) | **A+** |
| 2 | 200 | 6000 km (3700 mi) | **A+** and **A** and **B** |
| 2.5 | 250 | 7500 km (4700 mi) | **A+** |
| 3 | 300 | 9000 km (5600 mi) | **A+** and **A** |

| REGULAR DUTY | A | B |
|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Air and Fuel Delivery | | |
| Engine air filter | **I, C, L or R** | |
| Air delivery components and function (air box, throttle body, ducts, clamps)* | **I, C** | |
| Fuel components and function (Fuel tank cap, fuel tank, hoses, clamps, leaks)* | **I** | |
| Fuel pump pressure | | **I** |
| Body, Chassis and Accessories | | |
| Frame condition | **I** | |
| Seat Latch | **I** | |
| Winch | **I, C** | |
| Engine and Cooling | | |
| Engine oil and filter | **R** | |
| Valve clearance (regardless of calendar time) | **I, A** | |
| Spark plugs (regardless of calendar time) | | **R** |
| Engine seals and gaskets | **I** | |
| Engine cooling components (coolant concentration, coolant level, hose condition, clamps, leaks)* | **I, A** | |
| Engine coolant | **R**<br>Every 5 years or 12 000 km (7500 mi) | |
| Radiator | **C** | |
| Exhaust and Emissions | | |
| Fuel tank vent breather filter (Non-EVAP models) | **R** | |
| Canister vent pre-filter (CARB and EVAP models) | | **R** |
| Exhaust components (gaskets, pipes, muffler condition, leaks)* | **I** | |
| Muffler spark arrester | **C** | |
| Debris around exhaust pipe and muffler area | **C** | |

| REGULAR DUTY | A | B |
|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Brake | | |
| Brake components and function (oil level, brake pads, brake discs, calipers, brake lines, master cylinder)* | **I, C, L, A** | |
| Brake fluid | **R**<br>Every 2 years | |
| Drive | | |
| Gearbox oil | **R**<br>Replace at first 3000 km (1900 mi) and at 6000 km (3700 mi), then follow the regular schedule | |
| Gearbox oil | **I, A** | **R** |
| Front differential oil | **I, A** | **R** |
| Middle and rear final drive oil | **I, A** | **R** |
| Tires (wear and pressure) | **I, A** | |
| Wheel beadlock bolts (if equipped) | **T** | |
| Wheel lug nuts | **T** | |
| Drive components and function (Input and output shaft seals, drive shaft bellows, propeller shaft U-joints)* | **I, L** | |
| Controls | | |
| Gearbox position lever operation | **I, A** | |
| Throttle cable (If equipped) | **I, A, L** | |
| Throttle operation | **I** | |
| Continuously Variable Transmission (CVT) | | |
| CVT components and function * | **I, C, L** | |
| Electrical | | |
| Battery connections and condition | **I, C** | |
| Electronic modules (Fault codes and applicable software updates) | **I** | |
| Electrical harness routing | **I** | |
| Vehicle speed sensor | **C** | |

| REGULAR DUTY | A | B |
|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every year**<br>**or**<br>**100 hours**<br>**or**<br>**3000 km**<br>**(1900 mi)** | **Every 2 years**<br>**or**<br>**200 hours**<br>**or**<br>**6000 km**<br>**(3700 mi)** |
| Operation of control switches and lighting (All lights operation, all switches operations)* | **I** | |
| Steering | | |
| Steering components and function (Steering column, tie-rods)* | **I** | |
| Steering column half bushings | | **I, C, L** |
| Suspension | | |
| Suspension components and function (Shock absorber, spherical bearings, suspension arms, trailing arms)* | **I, C, L, T** | |
| Stabilizer bar bushings | **I, L**<br>Recommended at every 1000 km (620 mi) | |

*For an extensive list of maintenance actions to be performed, refer to your local dealership

| SEVERE DUTY | A+ | A | B |
|---|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every 6 months or 50 hours or 1500 km (900 mi)** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Air and Fuel Delivery | | | |
| Engine air filter | **I, C, L or R** | | |
| Air delivery components and function (air box, throttle body, ducts, clamps)* | **I, C** | | |
| Fuel components and function (Fuel tank cap, fuel tank, hoses, clamps, leaks)* | | **I** | |
| Fuel pump pressure | | | **I** |
| Body, Chassis and Accessories | | | |
| Frame condition | | **I** | |
| Seat Latch | | **I** | |
| Winch | **I, C** | | |
| Engine and Cooling | | | |
| Engine oil and filter | **R** | | |
| Valve clearance (regardless of calendar time) | | **I, A** | |
| Spark plugs (regardless of calendar time) | | | **R** |
| Engine seals and gaskets | | **I** | |
| Engine cooling components (coolant concentration, coolant level, hose condition, clamps, leaks)* | | **I, A** | |
| Engine coolant | **R**<br>Every 5 years or 12 000 km (7500 mi) | | |
| Radiator | | **C** | |
| Exhaust and Emissions | | | |
| Fuel tank vent breather filter (Non-EVAP models) | | **R** | |
| Canister vent pre-filter (CARB and EVAP models) | | | **R** |
| Exhaust components (gaskets, pipes, muffler condition, leaks)* | | **I** | |

| SEVERE DUTY | A+ | A | B |
|---|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every 6 months or 50 hours or 1500 km (900 mi)** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Muffler spark arrester | **C** | | |
| Debris around exhaust pipe and muffler area | **C** | | |
| Brake | | | |
| Brake components and function (oil level, brake pads, brake discs, calipers, brake lines, master cylinder)* | **I, C, L, A** | | |
| Brake fluid | **R**<br>Every 2 years | | |
| Drive | | | |
| Gearbox oil | **R**<br>Replace at first 3000 km (1900 mi) and at 6000 km (3700 mi), then follow the regular schedule | | |
| Gearbox oil | **I, A** | **R** | |
| Front differential oil | **I, A** | **R** | |
| Middle and rear final drive oil | **I, A** | **R** | |
| Tires (wear and pressure) | **I, A** | | |
| Wheel beadlock bolts (if equipped) | | **T** | |
| Wheel lug nuts | **T** | | |
| Drive components and function (Input and output shaft seals, drive shaft bellows, propeller shaft U-joints)* | **I, L** | | |
| Controls | | | |
| Gearbox position lever operation | | **I, A** | |
| Throttle cable (If equipped) | | **I, A, L** | |
| Throttle operation | | **I** | |
| Continuously Variable Transmission (CVT) | | | |
| CVT components and function * | | **I, C, L** | |
| Electrical | | | |
| Battery connections and condition | | **I, C** | |

| SEVERE DUTY | A+ | A | B |
|---|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every 6 months or 50 hours or 1500 km (900 mi)** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Electronic modules (Fault codes and applicable software updates) | | **I** | |
| Electrical harness routing | | **I** | |
| Vehicle speed sensor | | **C** | |
| Operation of control switches and lighting (All lights operation, all switches operations)* | | **I** | |
| Steering | | | |
| Steering components and function (Steering column, tie-rods)* | **I** | | |
| Steering column half bushings | | | **I, C, L** |
| Suspension | | | |
| Suspension components and function (Shock absorber, spherical bearings, suspension arms, trailing arms)* | **I, C, L** | **T** | |
| Stabilizer bar bushings | **I, L** Recommended at every 1000 km (620 mi) | | |

*For an extensive list of maintenance actions to be performed, refer to your local dealership

| DEEP MUD / WATER | A+ | A | B |
|---|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every 6 months or 50 hours or 1500 km (900 mi)** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Air and Fuel Delivery | | | |
| Engine air filter | **I, C, L or R** | | |
| Air delivery components and function (air box, throttle body, ducts, clamps)* | **I, C** | | |
| Fuel components and function (Fuel tank cap, fuel tank, hoses, clamps, leaks)* | | **I** | |
| Fuel pump pressure | | | **I** |
| Body, Chassis and Accessories | | | |
| Frame condition | | **I** | |
| Seat Latch | | **I** | |
| Winch | **I, C** | | |
| Engine and Cooling | | | |
| Engine oil and filter | **I, A** | **R** | |
| Valve clearance (regardless of calendar time) | | **I, A** | |
| Spark plugs (regardless of calendar time) | | | **R** |
| Engine seals and gaskets | | **I** | |
| Engine cooling components (coolant concentration, coolant level, hose condition, clamps, leaks)* | | **I, A** | |
| Engine coolant | **R**<br>Every 5 years or 12 000 km (7500 mi) | | |
| Radiator | **C** | | |
| Exhaust and Emissions | | | |
| Fuel tank vent breather filter (Non-EVAP models) | | **R** | |
| Canister vent pre-filter (CARB and EVAP models) | | | **R** |
| Exhaust components (gaskets, pipes, muffler condition, leaks)* | **I** | | |

| DEEP MUD / WATER | A+ | A | B |
|---|---|---|---|
| **A = Adjust<br>C = Clean<br>I = Inspect<br>L = Lubricate<br>R = Replace<br>T = Torque** | **Every 6 months or 50 hours or 1500 km (900 mi)** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Muffler spark arrester | **C** | | |
| Debris around exhaust pipe and muffler area | **C** | | |
| Brake | | | |
| Brake components and function (oil level, brake pads, brake discs, calipers, brake lines, master cylinder)* | **I, C, L, A** | | |
| Brake fluid | **R**<br>Every 2 years | | |
| Drive | | | |
| Gearbox oil | **R**<br>Replace at first 3000 km (1900 mi) and at 6000 km (3700 mi), then follow the regular schedule | | |
| Gearbox oil | **I, A** | | **R** |
| Front differential oil | **I, A** | | **R** |
| Middle and rear final drive oil | **I, A** | | **R** |
| Tires (wear and pressure) | **I, A** | | |
| Wheel beadlock bolts (if equipped) | | **T** | |
| Wheel lug nuts | **T** | | |
| Drive components and function (Input and output shaft seals, drive shaft bellows, propeller shaft U-joints)* | **I, L** | | |
| Controls | | | |
| Gearbox position lever operation | | **I, A** | |
| Throttle cable (If equipped) | | **I, A, L** | |
| Throttle operation | **I** | | |
| Continuously Variable Transmission (CVT) | | | |
| CVT components and function * | | **I, C, L** | |
| Electrical | | | |
| Battery connections and condition | | **I, C** | |

| DEEP MUD / WATER | A+ | A | B |
|---|---|---|---|
| **A = Adjust**<br>**C = Clean**<br>**I = Inspect**<br>**L = Lubricate**<br>**R = Replace**<br>**T = Torque** | **Every 6 months or 50 hours or 1500 km (900 mi)** | **Every year or 100 hours or 3000 km (1900 mi)** | **Every 2 years or 200 hours or 6000 km (3700 mi)** |
| Electronic modules (Fault codes and applicable software updates) | | **I** | |
| Electrical harness routing | | **I** | |
| Vehicle speed sensor | | **C** | |
| Operation of control switches and lighting (All lights operation, all switches operations)* | | **I** | |
| Steering | | | |
| Steering components and function (Steering column, tie-rods)* | **I** | | |
| Steering column half bushings | | | **I, C, L** |
| Suspension | | | |
| Suspension components and function (Shock absorber, spherical bearings, suspension arms, trailing arms)* | **I, C, L** | **T** | |
| Stabilizer bar bushings | **I, L** Recommended at every 1000 km (620 mi) | | |

*For an extensive list of maintenance actions to be performed, refer to your local dealership

# Maintenance Records

Send photocopy of maintenance record to BRP if needed.

| Pre-delivery | |
|---|---|
| Serial number: _____<br>Mileage / km: _____<br>Hours: _____<br>Date: _____<br>Dealer no: _____<br>Notes: _____ | Signature/Print: |
| Refer to vehicle Pre-Delivery Bulletin for detailed installation procedures | |

| FIRST inspection | |
|---|---|
| Mileage / km: _____<br>Hours: _____<br>Date: _____<br>Dealer no: _____<br>Notes: _____ | Signature/Print: |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

| Service | |
|---|---|
| Mileage / km: | Signature/Print: |
| Hours: | |
| Date: | |
| Dealer no: | |
| Notes: | |
| For maintenance schedule refer to Maintenance Information section of this operator's guide | |

# MAINTENANCE PROCEDURES

This section includes instructions for basic maintenance procedures.

Due to the complexity of some of the maintenance procedures, good mechanical skills are required.

If you are not comfortable with these procedures, do not hesitate to contact an authorized Can-Am off-road dealer, repair shop or person of your own choosing.

**⚠ WARNING**

**Unless otherwise indicated, the engine must be stopped and the key always removed before performing any maintenance**

**⚠ WARNING**

**Should removal of a locking device be required (e.g. lock tab, self-locking fastener, etc.) , always replace it with a new one.**

## Resetting the Message: Maintenance Required

1. Using the LOWER button, select **RES MAIN** in **SETTINGS**.
2. Hold the button to reset the maintenance message.

## ENGINE AIR FILTER

### *Removing the Engine Air Filter*

***NOTICE***

**Never remove or modify any component in the air filter housing. Otherwise, engine performance degradation or damage can occur. The engine is calibrated to operate specifically with these components.**

1. Remove the operator's seat.
2. Lift rear portion of console upwards until the studs are released from the grommets.




*TYPICAL*

1. *Console*
2. *Studs and grommets*

3. Pull console rearwards.
4. Rotate air filter cover counterclockwise to remove.

**NOTE:**
A socket wrench may be used to ease removal.

1. *Air filter cover*

5. Remove air filter.

### *Inspecting and Draining the Engine Air Filter Housing*

1. Remove LH side panel.
2. Drain air filter housing inlet drain tube.




*TYPICAL*

*1. Air filter housing inlet drain tube*

3. Check air filter dirty chamber for cleanliness.
   – If any debris or water are found, clean air filter chamber using a vacuum cleaner.

**NOTICE**

**Do not blow compressed air into air filter chamber.**

4. Check air filter drain tube (clean chamber).
   – If any debris or water are found, refer to *Special Procedures*.
   – Investigate for contamination source.




*TYPICAL*

*1. Air filter drain tube*

### *Cleaning and Oiling the Engine Air Filter*

#### Cleaning the Paper Filter

1. Ensure that the foam filter is removed from paper filter.
2. Tap out heavy dust from the paper filter.

   This will allow dirt and dust to get out of the paper filter.

**NOTE:**
Paper filter have a limited life span; replace filter if too dirty or clogged.

**NOTICE**

**It is not recommended to blow compressed air on the paper element; this could damage the paper fibers and reduce its filtration ability when used in dusty environments. If engine air filter is too dirty and cannot be cleaned following the recommended procedure, it should be replaced.**

**NOTICE**

**Do not wash the paper filter with any cleaning solution.**

#### Cleaning the Foam Filter

1. Spray the foam filter inside and out with a good air filter cleaner and follow manufacturer's instructions.

*TYPICAL*

2. Dry the foam filter completely.



*TYPICAL*

**NOTE:**
A second application may be necessary for heavily soiled elements.

### Oiling the Foam Filter

1. Make sure filter is clean. Refer to *Cleaning the Foam Filter*.
2. Spray an air filter oil on the foam filter previously dried.

*TYPICAL*

3. Let stand for 3 to 5 minutes.
4. Remove any excess of oil that could transfer to the paper filter by wrapping the foam filter into an absorbent cloth and squeezing gently. This will also ensure a full oil coverage on foam filter.
5. Reinstall the foam filter over the paper filter.

*TYPICAL*

6. Slightly grease plastic body of filter for ease of installation and future removal.

### *Installing the Engine Air Filter*

1. Reinstall oiled foam filter on paper air filter.
2. Slightly grease O-ring seal and plastic body of air filter.
3. Install air filter as the reverse of removal.
4. Ensure air filter cover is properly locked onto the air filter housing. See indications on filter cover and housing.




1. *Cover position arrow*
2. *Locked*
3. *Unlocked*

5. Install console as the reverse of removal. However, pay attention to the following.
   - Align console front tabs with slots, then push console forward.
   - Then align and insert studs with grommets on rear portion of console until studs engage with grommets.




*TYPICAL*

1. *Console*
2. *Studs and grommets*

6. Reinstall the seat.

## CVT AIR FILTER

### *Removing the CVT Air Filter*

1. Remove the gauge support.

1. *Pull up*
2. *Slide*

2. Push on tabs (3) and remove air filter.




1. *CVT air filter*
2. *Tab*

### *Cleaning the CVT Air Filter*

1. Spray filter inside and out with a good air filter cleaner and follow manufacturer's instructions.
2. Dry filter completely.




1. *CVT air filter (slip-on type)*




1. *CVT air filter (clip-on type)*

3. Clean inside the CVT air inlet end.

### *Installing the CVT Air Filter*

**Models with Slip-On Air Filter**

Install air filter on CVT inlet by stretching its sides.

### Models with Clip-On Air Filter

Install air filter on CVT by inserting tabs in their slots and push on air filter until it clicks.

### All Models

Install the gauge support.

1. *Hook*
2. *Engage retaining tab*

## ENGINE OIL

### *Verifying the Engine Oil Level*

**NOTICE**

**Operating the engine/gearbox with an improper level may severely damage engine/gearbox.**

**NOTICE**

**Check the oil level when the engine is cold.**

1. Place vehicle on a level surface.
2. Clean dipstick area to avoid foreign particles falling down in the engine.

***TYPICAL - RH SIDE OF ENGINE***

1. *Dipstick*

3. Unscrew dipstick then remove it and wipe clean.
4. Reinstall dipstick, screw in it completely.
5. Remove and check oil level. It should be near or equal to the upper mark.




***TYPICAL***

1. *Full*
2. *Add*
3. *Operating range*

If the level is between marks, reinstall the dipstick.

If the level is below the lower mark, add oil as follow:

– Place a funnel into the dipstick hole.
– Add a small amount of recommended oil and recheck oil level.

– Continue to add oil until the level reaches the upper mark.

**NOTICE**

**Do not overfill. Wipe off any spillage.**

6. Properly tighten dipstick.

### *Recommended Engine Oil*

Rotax® engines were developed and validated using the XPS® oil.

BRP recommends the use of its XPS engine oil or an equivalent at all time.

Damages caused by the use of an oil not suitable for the engine may not be covered by the BRP Limited Warranty.

| XPS Recommended Engine Oil | |
|---|---|
| General purpose | 5W40 Synthetic oil |
| Cold temperature | 0W40 Synthetic oil |
| Warm temperature | 10W50 Synthetic oil |
| If the recommended XPS Engine Oil Is Not Available | |
| Use a 4-stroke SAE synthetic engine oil meeting or exceeding the following lubricant industry specifications.<br>Always check the API service label certification on the oil container, it must contain at least one of the indicated standards.<br>– **API service classification SN, or**<br>– **JASO MA2** | |

### *Changing the Engine Oil*

**⚠ CAUTION**

**The engine oil can be very hot. Wait until engine oil is warm.**

**NOTICE**

**Engine oil and oil filter must be replaced at the same time.**

1. Ensure vehicle is on a level surface.
2. Bring engine to its normal operating temperature and stop it.
3. Remove dipstick.
4. Clean the oil drain plug area.
5. Place a drain pan under the oil drain plug area.
6. Unscrew magnetic drain plug and discard the gasket ring.

**⚠ CAUTION**

**The engine oil can be very hot.**




1. *Magnetic drain plug*
2. *Access through the frame*

7. Allow enough time for oil to flow out of engine and oil filter.
8. Replace the oil filter, refer to *Engine Oil Filter*.
9. Clean the magnetic drain plug from metal shavings and residue.

**NOTICE**

**Presence of debris gives an indication of internal engine damages.**

10. Install a NEW gasket ring on the magnetic drain plug.

**NOTICE**

**Never use the gasket ring a second time.**
**Always replace by a new one.**

11. Install and tighten magnetic drain plug.

| Tightening Torque | |
|---|---|
| M12 drain plug | 20 ± 2 Nm (15 ± 1 lbf-ft) |
| M18 drain plug | 30 ± 2 Nm (22 ± 1 lbf-ft) |

12. Refill engine at the proper level with the recommended oil.

    Refer to *Technical Specifications* for oil capacity.
13. Start engine and let idle for a few minutes.
14. Ensure oil filter area and oil drain plug areas are not leaking.
15. Stop engine.
16. Wait a while to allow oil to flow down to crankcase then check oil level.
17. Refill as necessary.
18. Dispose of oil as per your local environmental regulations.

## ENGINE OIL FILTER

### *Removing the Oil Filter*

Clean oil filter area.

Remove oil filter cover.

Remove oil filter.




***TYPICAL***

1. *Oil filter screw*
2. *Oil filter cover*
3. *O-ring*
4. *Oil filter*

### *Installing the Oil Filter*

1. Check and clean the oil filter inlet and outlet area for dirt and other contaminations.




1. *Inlet bore from the oil pump to the oil filter*
2. *Outlet bore to the engine oil providing system*

2. Install a NEW O-ring on oil filter cover.
3. Install the new filter into the cover.
4. Apply engine oil on O-ring and grease on the end of filter.




1. *Slightly oil*
2. *Slightly oil*

**NOTICE**

**Pay attention to avoid pinching the O-ring during filter and cover installation.**

5. Install the cover on the engine.
6. Tighten oil filter cover screws to recommended specification.

| Tightening Torque | |
|---|---|
| Oil filter cover screws | 10 ± 1 Nm (89 ± 9 lbf-in) |

7. Wipe off any oil spillage on engine.

## EVAPORATIVE EMISSION SYSTEM FILTER

### *Replacing the Evaporative Emission System Filter*

The evaporative emission system filter is located behind the left front inner fender on the top of the EVAP canister.



1. Cut the locking tie securing the round filter on the top of the EVAP canister support.
2. Pull the filter enough to access both hoses.
3. Cut the Oetiker clamps retaining hoses to filter.
4. Remove and discard the filter.
5. Install the new filter using new Oetiker clamps.

## FUEL VENT BREATHER FILTER

### *Replacing the Fuel Vent Breather Filter*

The fuel vent breather filter is located under the rear fender between the fuel tank neck and the seat.



1. By the rear right-hand wheel arch, unplug hoses from the filter.



2. Remove and discard the filter.
3. Install the new filter with the arrow pointing towards the rear of the vehicle.



4. Make sure hoses are well plugged.

## RADIATOR

### *Inspecting the Radiator*

1. Periodically check the radiator area for cleanliness.

*TYPICAL*

2. Inspect radiator and hoses for leaks or any damage.
3. Inspect radiating fins. They must be clean, free of mud, dirt, leaves and any other deposit that would prevent the radiator to cool properly.
4. Remove as much deposits as you can with your hands.

**NOTE:**
Inner fenders can be removed to ease cleaning.

If water is available in proximity, try rinsing the radiating fins.

**⚠ CAUTION**

**Never clean radiator with your hands when it is hot.**
**Let the radiator cool down before cleaning.**

***NOTICE***

**Be careful not to damage the radiating fins when cleaning.**
**Do not use any object/tool that could damage the fins.**
**The fins are purposely thin parts to allow efficient cooling.**
**When hosing, use low pressure only.**
**Never use a HIGH PRESSURE washer.**

5. See an authorized Can-Am Off--road dealer, repair shop or person of your own choosing to check the performance of the cooling system.

## ENGINE COOLANT

### *Verifying the Engine Coolant Level*

**⚠ WARNING**

**Check coolant level with engine cold.**
**Never add coolant in cooling system when engine is hot.**

**NOTE:**
A cooling system that frequently requires coolant is the indication of leaks or engine problems. See an authorized Can-Am Off-road dealer.

1. Place vehicle on a level surface.
2. Remove the gauge support.




1. *Pull up*
2. *Slide*

3. Remove the coolant reservoir cap.

**⚠ WARNING**

**Do not remove the coolant reservoir cap if engine is hot.**

4. With vehicle on a level surface, liquid should be between MIN. and MAX. level marks of coolant reservoir.

1. *Engine coolant reservoir*

**NOTE:**
When checking level at temperature lower than 20 °C (68 °F), it may be slightly lower than MIN. mark.

5. Add coolant if required.

**NOTE:** Use a funnel to avoid spillage. **Do not overfill.**

6. Properly reinstall and tighten reservoir cap.
7. Reinstall gauge support.

1. *Hook*
2. *Engage retaining tab*

### *Recommended Engine Coolant*

| XPS Recommended Engine Coolant |
|---|
| XPS Extended life pre-mixed coolant |
| If the Recommended XPS Engine Coolant Is Not Available |
| Distilled water and antifreeze solution (50% distilled water, 50% antifreeze) |

**NOTICE**

**Always use ethylene-glycol antifreeze containing corrosion inhibitors specifically for internal combustion aluminum engines.**

### *Engine Coolant Replacement*

#### Draining the Cooling System

1. Remove the gauge support.




1. *Pull up*
2. *Slide*

2. Remove the coolant reservoir cap.

**⚠ WARNING**

**In order to avoid potential burns, do not remove the pressure cap or loosen the coolant drain plug if the engine is hot.**

*1. Engine coolant reservoir cap*

3. Unscrew partially the coolant drain plug and drain the coolant into a suitable container.




*1. Coolant drain plug*

***650 Engines***

4. Disconnect the lower radiator hose and drain the remaining coolant into a suitable container.

**NOTE:**
Take note of the position of the hose clamp on the lower radiator hose at the radiator.

5. Reinstall radiator hose as noted prior to removal.

***All Engines***

6. Reinstall cooling system drain plug with a new sealing ring.
7. Tighten the coolant drain plug.

| Tightening Torque | |
|---|---|
| Drain plug | 10± 1 Nm (89 ± 9 lbf-in) |

8. Bleed cooling system, refer to *Filling and Bleeding the Cooling System*.

## Filling and Bleeding the Cooling System

1. Unscrew bleed screws above both front and rear cylinders.

***TYPICAL***

*1. Front cylinder bleed screw*




***TYPICAL***

*1. Rear cylinder bleed screw*

2. Fill the cooling system until coolant comes out of the bleed screw(s).

***650 Engines***

3. Squeeze the top of the coolant hose between the radiator and coolant pump several times until all air is bled from the highest point of the hose.

***All Models***

4. Install the bleed screw using a **NEW** gasket rings and tighten to specification.

| Tightening torque | |
|---|---|
| Bleed screws | 5.0 ± 0.6 Nm (44 ± 5 lbf-in) |

5. Continue adding coolant until system is full up to the pressure cap.
6. Refill coolant tank up to MAX level mark.
7. Run engine at idle with the radiator cap off. Slowly add coolant if necessary.
8. At this point, wait until engine reaches normal operating temperature.
9. Depress the throttle lever two or three times; then add coolant if required.
10. Stop the engine and let it cool down.
11. Install coolant reservoir cap.
12. Inspect all connections for leaks and check coolant level in the reservoir.

# EXHAUST SYSTEM

## *Cleaning the Area Surrounding the Exhaust System*

**⚠ WARNING**

**Debris accumulation could lead to a vehicle fire when the exhaust system is hot and the debris are dried.**
**In some cases, that could result in serious properly damages, injuries or even death.**
**Clean often and regularly the area surrounding the exhaust system when riding in swamp, bog, hay or dead leaves.**
**In other situations, clean as per maintenance schedule requirement.**
**Also, check all exhaust heat shields for damage regularly and replaced when needed.**

**⚠ CAUTION**

**Never perform this operation immediately after the engine has been running because exhaust system is very hot.**

1. From the rear of the vehicle, clean the areas around the muffler.
2. Remove the seat.
3. Remove the LH side panel with the middle panel.
4. Remove the left front inner fender.
5. Clean the areas around the front exhaust pipe and all along the rear exhaust pipe.

**⚠ WARNING**

**Clean also under the heat shields.**

6. Reinstall all removed parts.

### *Cleaning and Inspecting the Muffler Spark Arrester*

**NOTE:**
Spark arrester screen replacement is required only when damaged.

**⚠ CAUTION**

**Let exhaust system cool down before proceeding with cleaning and inspection.**

1. Remove the muffler cover. Discard retaining screws.

**NOTICE**

**Do not use impact tool for any screw removal.**




*TYPICAL*

1. *Screws*
2. *Cover*

2. Remove and discard the tail pipe retaining screws.




*TYPICAL*

1. *Screws*
2. *Tail pipe*

3. Remove exhaust tail pipe, gasket (discard) and spark arrester.




*TYPICAL*

1. *Spark arrester*
2. *Gasket*
3. *Exhaust tail pipe*

4. Remove carbon deposits from the spark arrester using a brush.

**NOTICE**

**Use a metallic soft brush and be careful to avoid damaging spark arrester mesh.**




1. *Clean spark arrester*

5. Inspect mesh of spark arrester for any damage. Replace as required.

**NOTE:**
Spark arrester screen replacement is required only when damaged

6. Inspect spark arrester chamber in muffler. Clean any debris as required.
7. Install new gasket, tail pipe and new retaining screws.
8. Reinstall muffler cover with new retaining screws. Tighten to specification.

| Tightening torque | |
|---|---|
| Tail pipe screws | 11 ± 1 Nm (97 ± 9 lbf-in) |
| Cover screws | |

## GEARBOX

### *Verifying The Gearbox Oil Level*

**NOTICE**

**Check level and refill if necessary. Do not overfill.**
**Operating the gearbox with an improper level may severely damage gearbox.**
**Wipe off any spillage.**

1. Place the vehicle on a level surface.
2. Select NEUTRAL position.
3. Apply the parking brake.

**NOTE:**
Check the gearbox oil level when engine is cold and not running.

4. Remove the gearbox oil level plug.




*TYPICAL*

1. *Drain plug*
2. *Oil level plug*

5. Check the level. The oil should be level with the bottom of the oil level hole.
6. Refill as required until gearbox oil level flows through oil level hole.

### *Recommended Gearbox Oil*

The XPS oil is specially formulated to meet the lubrication requirements of this gearbox. BRP strongly recommends the use of its XPS oil.

| XPS Recommended Gearbox oil |
|---|
| XPS 75W140 Synthetic gear oil |
| If the Recommended XPS Gearbox Oil Is Not Available |
| Use a gearbox oil meeting or exceeding the following lubricant industry specifications.<br>– 75W 140 API GL-5 synthetic gear oil |

**NOTICE**

**Do not use another type of oil when servicing.**

### *Changing the Gearbox Oil*

#### Draining the Gearbox Oil

1. Ensure vehicle is on a level surface.
2. Bring engine to its normal operating temperature and stop it.

**NOTE:** Running the engine at idle is not sufficient, vehicle gearbox must be operated.

3. Clean the areas around the drain and level plugs.

**⚠ CAUTION**

**The gearbox and the gearbox oil can be very hot.**




*1. Drain plug*
*2. Oil level plug*

4. Place a drain pan underneath the drain and level plugs.
5. Remove the magnetic drain plug.
6. Discard the sealing ring.
7. Remove the oil level plug and its O-ring.
8. To completely drain the gearbox, place a jack under the left footrest and tilt the vehicle toward the right side.
9. Wait a while to allow oil to flow out of the gearbox.
10. When the gearbox is empty, install the drain plug and replace the vehicle on the ground.
11. Clean the magnetic drain plug from metal shavings and residue.

**NOTICE**

**Presence of debris gives an indication of internal gearbox damages.**

12. Install a NEW sealing washer on the magnetic drain plug.

**NOTICE**

**Never use the sealing washer a second time.**
**Always replace by a new one.**

13. Install and tighten magnetic drain plug.

| Tightening Torque | |
|---|---|
| Magnetic drain plug | 20 ± 2 Nm (15 ± 1 lbf-ft) |

14. Dispose of oil as per your local environmental regulations.

### Filling the Gearbox Oil

1. With the oil level plug, add recommended gearbox oil through the oil level hole until the level reach the bottom of the hole.
2. Install the oil level plug with its O-ring.

| Tightening Torque | |
|---|---|
| Oil level plug | 5 ± 0.6 Nm (44 ± 5 lbf-in) |

## SPARK PLUGS

### *Removing the Spark Plug*

1. Remove the side panels to reach the spark plug areas.
2. Unplug the spark plug cable.
3. Unscrew spark plugs one turn.
4. Clean spark plugs and cylinder heads with pressurized air if possible.
5. Unscrew spark plugs completely using a spark plug socket, then remove them.




*RH SIDE — REAR CYLINDER*

*1. Spark plug*




*LH SIDE — FRONT CYLINDER*

*1. Spark plug*

### *Installing the Spark Plug*

1. Prior to installation, make sure that contact surfaces of cylinder heads and spark plugs are free of grime.
2. Using a feeler gauge, set the electrode gap as specified in *Technical Specifications*.
3. Apply a small of lubricant over spark plug threads to prevent a possible seizure.

**Copper based anti-seize lubricant**

4. Screw spark plugs into cylinder heads by hand and tighten with a torque wrench and a proper socket.

**NOTICE**

**Do not overtighten spark plugs, engine damage can occur.**

| Tightening Torque | |
|---|---|
| 650 | 20 ± 2 Nm<br>(15 ± 2 lbf-ft) |
| 1000 | 11 ± 1 Nm<br>(97 ± 9 lbf-in) |

## CVT COVER

For a better understanding, some illustrations are taken with engine out of vehicle. To perform the following instructions, it is not necessary to remove engine.

**⚠ WARNING**

**Never touch CVT while engine is running.**
**Never drive vehicle when CVT cover is removed.**

**⚠ CAUTION**

**Engine must be cool before cover is removed.**

**NOTICE**

**This CVT is lubrication free.**
**Never lubricate any components except drive pulley bearing and thrust rollers bearing.**

### *Accessing the CVT Cover*

The CVT cover is located on the LH side of the vehicle.

Remove the following:

– LH side and extension panels
– LH footboard panel.




*TYPICAL*

1. *CVT cover*

### *Removing the CVT Cover*

1. Disconnect the inlet and outlet air cooling ducts from the CVT cover.
2. Remove all CVT cover retaining screws.
3. Remove the center top screw last to support the cover during removal.

**NOTICE**

**Do not use an impact tool to remove CVT cover screws.**

4. Remove the CVT cover and its gasket.

1. *CVT cover screw*
2. *CVT cover*
3. *Gasket*

### *Installing the CVT Cover*

1. Position the cover against the engine.
2. Install the center top screw of first.

**NOTICE**

**Do not use an impact tool to install CVT cover screws.**

3. Tighten the CVT cover screws as per following sequence.

| Tightening torque | |
|---|---|
| CVT cover screws | 7 ± 0.8 Nm (62 ± 7 lbf-in) |

4. Install the inlet and outlet air cooling ducts.

## DRIVE BELT

### *Inspecting the Drive Belt*

1. Inspect drive belt for cracks, fraying or abnormal wear. Replace if necessary.
2. Check drive belt width at cord level. Replace if the belt is out of the specification.

| Drive Belt Width | |
|---|---|
| Service limit | 30 mm (1.181 in) |




1. *Drive belt*
2. *Cord in drive belt*

### *Removing the Drive Belt*

**NOTICE**

**In case of a drive belt failure, the CVT cover, drain reservoir and air outlet must be cleaned and inspected for obstruction.**

1. Remove the *CVT Cover*.
2. Open the driven pulley.

| | |
|---|---|
| **Puller/locking tool**<br><br>**(P/N 529036098)** | |

3. Screw tool in the threaded hole of driven pulley and tighten to open the pulley.




1. *Puller/locking tool*
2. *Fixed sheave of driven pulley*

4. Slide the belt over the top edge of fixed sheave to remove it.

### *Installing the Drive Belt*

For installation, reverse the removal procedure. Pay attention to the following details.

The maximum drive belt life span is obtained when the drive belt has the proper rotation direction.

1. Install drive belt so that the arrow printed on belt is pointing towards front of the vehicle, viewed from top.




1. *Arrow printed on belt*
2. *Drive pulley (front)*
3. *Driven pulley (rear)*
4. *Rotation direction*

2. Turn the driven pulley until the lowest portion of the cogs on the external surface of drive belt is even with the driven pulley edge.

1. *Lowest portion of cogs even with external surface of drive belt*

## DRIVE AND DRIVEN PULLEYS

### *Inspecting the Drive and Driven Pulleys*

This inspection must be performed by an authorized Can-Am Off-road dealer, repair shop, or person of your own choosing for maintenance, repair, or replacement.

#### Drive Pulley

Inspect the bushings and rollers of the sliding sheave of the drive pulley, replace worn parts.

#### Driven Pulley

Inspect the bushings of the cam and of the sliding sheave of the driven pulley, replace worn parts.

## BATTERY

**⚠ CAUTION**

**Never charge a battery while installed in vehicle.**

These vehicles are equipped with a VRLA battery (Valve Regulated Lead Acid). It is a maintenance-free type battery, there is no need to add water to adjust electrolyte level.

**NOTICE**

**Never remove the battery sealing cap.**

### *Removing the Battery*

1. Disconnect BLACK (-) cable first then RED (+) cable.

**NOTICE**

**Always disconnect BLACK (-) battery cable first.**

2. Remove retaining screws, battery holding strap then pull the battery out of frame.




1. *Battery holding strap*
2. *Retaining screws*

### *Cleaning the Battery*

1. Clean battery, battery casing and battery posts using a solution of baking soda and water.
2. Remove corrosion from battery cable terminals and battery posts using a firm wire brush.

### *Installing the Battery*

The installation is the reverse of the removal procedure.

**NOTICE**

**Always connect RED (+) battery cable first.**

# FUSES

| | |
|---|---|
| Battery/voltage regulator fuse | 40 A |
| DPS fuse | 40 A |

### *Fuses Location*

The main fuse box is located under the gauge support.

**NOTE:**
Check inside fuse box cover to know fuses location.

The holder of the following fuse are located behind the rear of the right side panel.



### *Main Fuse Box Description*

### *Models Equipped with an Electronic Throttle Control (ETC)*

| No. | Description | Rating |
|---|---|---|
| RY1 | Cooling fan relay | — |
| RY2 | Main relay | — |
| RY3 | Lights relay | — |
| RY5 | Accessory relay | — |
| RY6 | Brake relay | — |
| F1 | Start switch/Cluster | 10A |
| F2 | Lights | 30A |
| F3 | ACC 1 | 20A |
| F4 | ACC2 | 20A |
| F5 | Fuel Pump/Injectors/ Ignition coils/EVAP | 10A |
| F6 | Cluster/Relays/DPS/ Speed limiter | 10A |
| F7 | Brake lights/Tail lights | 10A |
| F8 | D.E.S.S/ECM | 10A |
| F9 | 2WD/4WD | 10A |
| F12 | Cooling fan (resettable) | 25A |

# LIGHTS

**⚠ CAUTION**

**Always remove the D.E.S.S. key from the D.E.S.S. post or turn the ignition switch to OFF position before replacing a defective bulb.**

Always check light operation after replacement.

### *Headlight Bulb Replacement*

No headlight bulb replacement is required for this vehicle. It is equipped with LEDs (Light Emitting Diode) headlights. This technology has proven itself to be very reliable.

In the unlikely event they do not work, have them checked by an authorized Can-Am Off-road dealer, repair shop or person of your own choosing.

### *Headlight Beam Aiming*

1. Load the vehicle as per normal use.
2. Position vehicle on a level surface 5 m (16 ft) in front of a test surface (wall or screen) as in first illustration.
3. Measure the distance from the center of each headlight to the ground (high beam and low beam).
4. Trace a line on the test surface parallel to the ground at each measured height (one for high beam and one for low beam).

   Low beam aiming is correct when the crest of the low beam is 50 mm (2 in) **below** the applicable horizontal center line traced on the test surface as per specification.

   High beam aiming is correct when the center of the high beam (focus point) is 40 mm (1.57 in) **below** the applicable horizontal center line traced on the test surface as per specification.

**NOTE:**
The headlights can only be adjusted vertically.




***TYPICAL***

*1. Light beam center*

*A. 5 m (16 ft)*
*B. Beam aiming specification*




***TYPICAL***

*1. Headlight center lines*
*2. Light beam center*

5. To adjust, turn the adjustment screw.

### *Turn Signal Light Bulb Replacement*

No turn signal light bulb replacement is required for this vehicle.

It is equipped with LEDs (Light Emitting Diode) headlights.

This technology has proven itself to be very reliable.

In the unlikely event they do not work, have them checked by an authorized Can-Am Off-road dealer, repair shop or person of your own choosing.

### *Front Position Light Bulb Replacement*

No front position light bulb replacement is required for this vehicle.

It is equipped with LEDs (Light Emitting Diode) headlights.

This technology has proven itself to be very reliable.

In the unlikely event they do not work, have them checked by an authorized Can-Am Off-road dealer, repair shop or person of your own choosing.

## DRIVE SHAFT BELLOW AND PROTECTOR

### *Inspecting the Drive Shaft Bellow and Protector*

Visually inspect drive shaft protectors and bellows conditions.

Check protectors for damage or rubbing against shafts.

Check bellows for cracks, tears, leaking grease etc.

Repair or replace damaged parts as necessary.




***TYPICAL — FRONT OF VEHICLE***

1. *Drive shaft bellows*
2. *Protector*




***TYPICAL — REAR OF VEHICLE***

1. *Drive shaft bellows*
2. *Protector*

## WHEEL BEARING

### *Inspecting the Wheel Bearing*

1. Place vehicle on a level surface.
2. Apply the parking brake.
3. Lift and support vehicle.
4. Secure vehicle on jack stands.
5. Push and pull the wheels from the upper edge to feel the play.
6. See an authorized Can-Am Off--road dealer if there is an abnormal play.

*TYPICAL*

## WHEELS AND TIRES

### *Tire Pressure*

**⚠ WARNING**

**Tire pressure greatly affects vehicle handling and stability. Insufficient pressure may cause tire to deflate and rotate on wheel. Overpressure may burst the tire. Always follow recommended pressure.**
**NEVER set tire pressure below minimum. It could cause the tire to dislodge from the rim.**

Check pressure when tires are **cold** before using the vehicle. Tire pressure changes with temperature and altitude. Recheck pressure if one of these conditions has changed.

Refer to the *Tire Pressure and Maximum Load* decal for proper tire pressure.

**NOTE:**
Although the tires are specifically designed for off-road use, a flat may still occur. Therefore, it is recommended to carry a tire gauge, tire pump and a repair kit.

### *Tire Inspection*

Check tire for damage and wear. Replace if necessary.

**⚠ WARNING**

**Do not rotate tires. The front and rear tires have a different size. The left and right tires have different unidirectional tread patterns.**

### *Tire Replacement*

Tire replacement should be performed by an authorized Can-Am dealer, a repair shop or a person of your choosing.

**⚠ WARNING**

**Replace tires only with the same type and size as original tires. For unidirectional tread pattern, ensure that the tires are installed in the correct direction of rotation. Tires should be replaced, by an experienced person, in accordance with tire industry standards and tools.**

### *Removing the Wheel*

1. Place vehicle on a level surface.
2. Apply the parking brake.
3. Loosen lug nuts then lift vehicle.
4. Secure vehicle on jack stands.
5. Remove lug nuts, then remove wheel.

### *Installing the Wheel*

Occasionally, the wheel lug nuts should be removed to apply anti-seize lubricant to the studs to ease future removal. This is particularly important when the vehicle is used in a salt water environment or in mud. Remove one nut at a time, lubricate and then re-torque.

1. If tires are unidirectional, make sure to install wheel according to tire rotation.

2. Carefully tighten lug nuts in a criss-cross sequence then tighten to specification.

**NOTICE**

**Always use the recommended wheel lug nuts for the type of wheel.**
**Using a different wheel lug nuts could cause damages to the rim or studs.**

| Tightening Torque | |
|---|---|
| Wheel lug nut | 80 ± 5 Nm (59 ± 4 lbf-ft) |

### *Inspecting Wheel Beadlock*

#### Wheel Beadlock Retorque

**NOTICE**

**Do not use an impact wrench for installing beadlock screws. The risk of screw breaking or screw stripping is high when using an impact wrench.**

1. Retorque all screws to specification and according to the following tightening sequence.

| Tightening torque | |
|---|---|
| Beadlock screws | 11 ± 1 Nm (97 ± 9 lbf-in) |




*TYPICAL - FINAL TIGHTENING SEQUENCE*

2. Tighten screws **a few turns at a time** to ensure even pressure on the beadlock clamp ring.

**NOTE:**
It is normal that the beadlock clamp ring flexes slightly to match the tire bead.

#### Verifying the Wheel Beadlock Gap

1. Verify the gap between tire and beadlock clamp ring, it should be practically equal all around the ring.




*TYPICAL*

*1. Gap between tire and ring*

If the gap is not acceptable, refer to *Tire Mounting on Beadlock Wheels*.

### *Tire Mounting on Beadlock Wheel*

1. On the opposite side of beadlock, apply tire mounting lube on inner bead of tire and wheel to ensure proper seat when inflating.
2. Mount the inner bead over the wheel like normal.
3. Seat tire outer bead in the shoulder of the beadlock inner ring and center the tire.
4. Install manually all beadlock screws to avoid cross threading.

**NOTICE**

**Do not use an impact wrench for installing beadlock screws. The risk of screw breaking or screw stripping is high when using an impact wrench.**



*TYPICAL*

5. Tighten beadlock screws as per following specification and sequence.

**NOTE:**
To ensure even pressure on the beadlock clamp ring, tighten screws **a few turns at a time**.

| Tightening torque | |
|---|---|
| Beadlock screws (FIRST Sequence) | 3 ± 1 Nm (27 ± 9 lbf-in) |




*TYPICAL - TIGHTENING SEQUENCE*

6. At this time check if the tire is still centered on wheel. Reposition it if necessary.

7. Tighten beadlock screws as per the **second** torque using the same sequence.

| Tightening torque | |
|---|---|
| Beadlock screws (SECOND Sequence) | 8 ± 1 Nm (71 ± 9 lbf-in) |




*TYPICAL - TIGHTENING SEQUENCE*

**NOTE:**
The beadlock clamp ring can flex slightly to match the tire bead. IT IS NORMAL.

8. Verify the gap between tire and beadlock clamp ring, it should be practically equal all around the ring.




1. *Tire*
2. *Beadlock clamp ring edge*

1. *Gap equal all around beadlock clamp ring*

If the gap is not acceptable,

- Loosen all screws.
- Check tire position on wheel and reposition it if necessary.

– Restart the torquing sequence as detailed.

9. Torque beadlock screws a **final** time following the indicated sequence.

| Tightening torque | |
|---|---|
| Beadlock screws (FINAL Sequence) | 11 ± 1 Nm (97 ± 9 lbf-in) |




*TYPICAL - FINAL TIGHTENING SEQUENCE*

10. Inflate tire to seat the inner bead on wheel. Always use safe practices, such as a tire safety cage.

**⚠ WARNING**

**Never exceed tire's recommended maximum pressure for seating beads.**

## STEERING

### *Inspecting Tie-Rod Ends*

1. Place vehicle on a level surface.
2. Apply the parking brake.
3. Lift vehicle.
4. Secure vehicle on jack stands.
5. Inspect tie-rod bellows for cracks.
6. Push and pull the wheels from the front or rear edge to feel the play.
7. See an authorized Can-Am Off--road dealer if there is an abnormal play or the bellow is cracked.

**⚠ WARNING**

**The tie-rod end must be replaced if the bellow is cracked or shows an abnormal play.**

## SUSPENSION

### *Lubricating the Front Suspension*

1. Lubricate front stabilizer bar bushing and suspension arms at grease fittings.

**XPS Synthetic suspension grease**

### *Lubricating the Rear Suspension*

1. Lubricate rear stabilizer bar links and pivot bushing at grease fittings.

**XPS Synthetic suspension grease**

### *Inspecting the Suspension*

See an authorized Can-Am Off-road-dealer, a repair shop or person of your choosing if any problem is detected.

#### Shock Absorbers

1. Inspect shock absorber for oil leaks or other damage.
2. Check tightness of fasteners.
3. See an authorized Can-Am Off--road dealer as necessary.

#### Ball Joints

1. Place vehicle on a level surface.
2. Apply the parking brake.
3. Lift vehicle.
4. Secure vehicle on jack stands.
5. Inspect ball joint bellow for cracks.

6. Push and pull the wheels from the upper and lower edge to feel the play.
7. See an authorized Can-Am Off--road dealer if there is an abnormal play or the bellow is cracked.

*TYPICAL*

**⚠ WARNING**

**The ball joint must be replaced if the bellow is cracked or it shows an abnormal play.**

### Front Suspension Arms

1. Check suspension arms for cracks, bending or other damage.
2. See an authorized Can-Am Off--road dealer as necessary.

### Rear Trailing Arms

1. Check trailing arms for distortion, cracks or bending.
2. See an authorized Can-Am Off--road dealer if any problem is detected.

## BRAKES

### *Verifying the Front Brake Reservoir Level*

1. Turn steering in the straight-ahead position to ensure reservoir is level.
2. Check the brake fluid level, the reservoir is full when the fluid reaches of the top of window.
3. Visually inspect lever boot condition.
4. Check for cracks, tears, etc. Replace if damaged.

*TYPICAL*

### *Verifying the Rear Reservoir Level*

1. Remove the seat.
2. With vehicle on a level surface, liquid should be between MIN. and MAX. level marks of brake pedal fluid reservoir.

*1. Rear brake fluid reservoir*

### *Adding Brake Fluid*

1. Clean filler cap.

**⚠ WARNING**

**Clean filler cap before removing to avoid brake system contamination.**

2. Remove reservoir cap.
3. Add fluid as required using a clean funnel. **Do not overfill.**

**NOTICE**

**Brake fluid can damage plastic and painted surface. Wipe off and clean any spillage.**

4. Reinstall reservoir cap.

**NOTE:**
Ensure filler cap diaphragm is pushed inside the cap before closing the brake fluid reservoir.

5. On front reservoir, tighten screws to specification.

| Tightening Torque | |
|---|---|
| Brake fluid reservoir screws | 1.3 ± 0.1 Nm (12 ± 1 lbf-in) |

### *Recommended Brake Fluid*

Always use brake fluid meeting the specification DOT 4 only.

**NOTICE**

**To avoid serious damage to the braking system, do not use fluids other than the recommended one, nor mix different fluids for topping up.**
**Do not use brake fluid taken from old or already opened containers.**

### *Inspecting the Brake System*

**⚠ WARNING**

**The brake fluid replacement or brake system maintenance and repairs should be performed by an authorized Can-Am Off-road dealer.**

**⚠ CAUTION**

**The brakes can be very hot after prolonged use of the vehicle and can cause burns. Wait for the brakes to cool down.**

The brake inspection, maintenance and repair should be performed by an authorized Can-Am Off-road dealer.

1. However, verify the following between visits to your dealer:
   - Brake fluid level
   - Brake system for fluid leaks
   - Brake cleanliness.

## Vehicle Cleaning and Protection

**NOTICE**

**Never use a high pressure washer to clean the vehicle. USE LOW PRESSURE ONLY (like a garden hose).**
**High pressure can cause damage to electrical or mechanical components.**

Pay attention to certain areas where salt-water, mud or debris can accumulate and potentially cause:

- Fire
- Wear
- Interference
- Corrosion.

This list includes but is not limited to:

- Around exhaust system and between muffler and muffler cover
- Under and around the fuel tank
- Radiator
- Shock absorbers
- Around front and rear differentials
- Around and underneath engine and gearbox
- Inside wheels
- On top of skid plates.

**⚠ WARNING**

**Debris accumulation could lead to a vehicle fire when the exhaust system is hot and the debris are dried.**
**In some cases, that could result in serious properly damages, injuries or even death.**
**Clean often and regularly the area surrounding the exhaust system when riding in swamp, bog, hay or dead leaves.**
**In other situations, clean as per maintenance schedule requirement.**

When vehicle is used in salt-water environment rinsing the vehicle with fresh water is necessary to preserve vehicle and its components after each operating day.

Metallic parts lubrication is highly recommended.

Use anti-corrosive lubricant or an equivalent.

**XPS Lubricant and anti-corrosive**

Painted parts which are damaged should be properly repainted to prevent rust.

When required, wash the body with warm water and soap (only use mild detergent). Apply non-abrasive wax.

**NOTICE**

**Never clean plastic parts with strong detergent, degreasing agent, paint thinner, acetone, etc.**

Protect the vehicle with a cover to prevent dust accumulation during storage.

**NOTICE**

**The vehicle has to be stored in a cool and dry place and covered with an opaque tarpaulin. This will prevent sun rays and grime from affecting plastic components and vehicle finish.**

### *Non Compatible Cleaning Products*

| Material Type | Non-compatible Cleaning Products |
|---|---|
| Polypropy lene | – Any petroleum base cleaning products<br>– XPS ATV finishing spray<br>– XPS ATV cleaning kit (it contains the above XPS ATV Finishing Spray) |

### *Compatible Cleaning Products*

| Material Type | Compatible Cleaning Product |
|---|---|
| Polypropy lene | – XPS ATV wash<br>– Soapy water |

# STORAGE AND PRESEASON PREPARATION

When a vehicle is not in use for more than 4 months, proper storage is a necessity.

If the vehicle is to be remain inactive for more than 21 days, disconnect the BLACK (-) cable of the battery.

The use of a low amperage trickle charger is recommended to keep battery fully charged.

Before using your vehicle after storage, a preparation is required.

See an authorized Can-Am Off-road dealer, a repair shop, or a person of your own choosing to have your vehicle prepared properly.

While reading this Operator's Guide, remember that:

**⚠ WARNING**

**Indicates a potential hazard which, if not avoided, could result in serious injury or death.**

This page is intentionally blank

# TECHNICAL INFORMATION

# INTENDED USE

Agricultural tractor that can be used to carry materials.

Check the maximum allowable load of the vehicle indicated on the statutory plate and vehicle maximum load label, refer to *Important On-Product Labels*.

The Can-Am T Category tractor can tow a trailer on the road.

Check the maximum allowable load of the trailer.

Check the regulations for your area regarding the use of a tractor and trailer on the road.

Connect the trailer lights on the vehicle.

# VEHICLE IDENTIFICATION

The main components of your vehicle (engine and frame) are identified using different serial numbers.

It may sometimes become necessary to locate these numbers for warranty purposes or to trace your vehicle in the event of loss.

These numbers are also required by the authorized Can-Am Off-road dealer to complete warranty claims properly.

We strongly recommend that you take note of all the serial numbers on your vehicle and supply them to your insurance company.

## Vehicle Identification Number

The VIN is on the statutory plate located under the seat and on the VIN label.




***STATUTORY PLATE***

1: Category

2: Type-approval number

3: VIN

4: Permissible maximum laden mass (es) of the vehicle

5-7: Permissible maximum mass (es) per axle

B-1: Permissible towable mass on rear coupling point; unbraked trailer

B-2: Permissible towable mass on rear coupling point; inertia-braked trailer



1. *VIN label - On frame under the seat*
2. *Stamped VIN - On right side, below the front differential*

# Engine Identification Number (EIN)

## *V-Twin Engine*

*1. EIN (Engine Identification Number)*

## Compliance Label

### *Regulation (EU) 2016/1628 applicable for Non-Road Mobile Machineries*

Vehicles who comply to Regulation (EU) 2016/1628 (NRMM) are identified on the engine valve cover as well as on the frame under the seat.



*TYPICAL*

*1. NRMM Label - On the frame under the seat*




***TYPICAL - NRMM IDENTIFICATION LABEL***

**NOTE:**
Tampering with the engine or its components voids the EU type-approval of that particular engine.

## *Emission Control Information (Typical)*

CARB and EPA Models



### *Trailer Hitch Compliance*

This label is located on the trailer hitch.

### *Category 1 Vehicle*

This label is located in front of the fuel cap.

| | |
|---|---|
| CATEGORY 1 | The cab does not offer any protection against substances which are harmful to health. |

### *Fuel Ethanol Rating*

This label is located near the gas cap.

## Technical Information Labels

### *Air Filter Maintenance Label*

This label is located under the seat.




### *Removing the Middle Deck*

1. Unlatch cover and gently lower it. Lift cover upwards.
2. Pull and lower it.
3. Pull off the middle deck.





### *Using the Release Handle*

- Engage the release handle and push up the cargo bed.
- Disengage the release handle and push down the cargo bed.



- Engage the release handle and push up the cargo bed.
- Disengage the release handle and push down the cargo bed.



### *Park Position Pictogram*

This pictogram is located just beside the shift pattern.

### *Brake Fluid Pictogram*

This pictogram is located near all brake reservoirs.

### *Grease Fitting Position – Front Suspension*

These labels are located on the lower suspension arms, near the frame.

Its indicates the number of available grease fittings.




### *Grease Fitting Position – Rear Suspension*

These labels are located on the trailing arms, near the wheels.

Its indicates the number of available grease fittings.




### *Lifting Locations Pictogram*

These labels are located where the placing a jack (to lift) or a jack stand (to support) the vehicle.

Refer to *Vehicle Lifting Instructions* for lifting point locations and procedures.



# BRP RF DESS POST GEN3 (MOWP)

## USA and Canada

This device complies with FCC Part 15 and Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Le dispositif a été évalué à satisfaire l’exigence générale de l’exposition aux rf. L’appareil peut être utilisé dans des conditions d’exposition portatif sans restriction.

L’émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d’Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

1. l'appareil ne doit pas produire de brouillage, et
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**IC**: 12006A-1001317030 For variant 1001316155 (MOWP)

**FCC ID**: 2ACER–1001317030 For variant 1001316155 (MOWP).

## Mexico

IFETEL

Marca: BRP Megatech

Número: BRME1023-28191

BRP Megatech Certificate number : 1450979

Modelo: 1001316155

NOM-208-SCFI-2016 (Disposición Técnica IFT-008-2015)

La operación de este equipo está sujeta a las siguientes dos condiciones:

1. Es posible que este equipo o dispositivo no cause interferencia perjudicial y
2. Este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

## Brazil

Número: 05254-23-15603

BRP Megatech Certificate number: 1450991

Modelo: 1001316155

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados. Para maiores infor- mações, consulte o site da ANATEL.

## Japan

This device is granted pursuant to the Japanese Radio Law (電波法) and the Japanese Telecommunications Business Law (電気通信事業法). This device should not be modified (otherwise the granted designation number will become invalid).

## Europe

### Declaration of Conformity

Simplified EU Declaration of Conformity according Radio Equipment Directive 2014/ 53/EU

CE

**DE**

Hiermit erklärt BRP Megatech, dass der Funkanlagentyp 1001316154 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: https://www. brp. com/en/sustainability/product-responsibility.html

**FR**

Le soussigné, BRP Megatech, déclare que l'équipement radioélectrique du type 1001316154 est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: https://www.brp.com/en/sustainability/product-responsibility.html

**BG**

С настоящото BRP Megatech декларира, че този тип радиосъоръжение 1001316154 е в съответствие с Директива 2014/53/ЕС.

Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: https://www.brp.com/en/sustainability/product-responsibility.html

**EL**

Με την παρούσα ο/η BRP Megatech, δηλώνει ότι ο ραδιοεξοπλισμός 1001316154 πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: https://www.brp.com/en/sustainability/product-responsibility.html

**CS**

Tímto BRP Megatech prohlašuje, že typ rádiového zařízení 1001316154 je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: https://www. brp. com/en/sustainability/product-responsibility.html

## DA

Hermed erklærer BRP Megatech, at radioudstyrstypen 1001316154 er i overensstemmelse med direktiv 2014/53/EU.

EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: https://www.brp.com/en/sustainability/product-responsibility.html

## ET

Käesolevaga deklareerib BRP Megatech, et käesolev raadioseadme tüüp 1001316154 vastab direktiivi 2014/53/EL nõuetele.

ELi vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetiaadressil: https://www.brp.com/en/sustainability/product-responsibility.html

## ES

Por la presente, BRP Megatech declara que el tipo de equipo radioeléctrico 1001316154 es conforme con la Directiva 2014/53/UE.

El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: https://www.brp.com/en/sustainability/product-responsibility.html

## FI

BRP Megatech vakuuttaa, että radiolaitetyyppi 1001316154 on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: https://www. brp. com/en/sustainability/product-responsibility.html

## EN

Hereby, BRP Megatech declares that the radio equipment type 1001316154 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.brp.com/en/sustainability/product-responsibility.html

## HR

BRP Megatech ovime izjavljuje da je radijska oprema tipa 1001316154 u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: https://www. brp. com/en/sustainability/product-responsibility.html

## HU

BRP Megatech igazolja, hogy a 1001316154 típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: https://www. brp. com/en/sustainability/product-responsibility.html

## IT

Il fabbricante, BRP Megatech, dichiara che il tipo di apparecchiatura radio 1001316154 è conforme alla direttiva 2014/53/UE.

Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: https://www. brp. com/en/sustainability/product-responsibility. html

**LT**

Aš, BRP Megatech, patvirtinu, kad radijo įrenginių tipas 1001316154 atitinka Direktyvą 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: https://www.brp.com/en/sustainability/product-responsibility.html

**LV**

Ar šo BRP Megatech deklarē, ka radioiekārta 1001316154 atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: https://www.brp.com/en/sustainability/product-responsibility.html

**MT**

B'dan, BRP Megatech, niddikjara li dan it-tip ta' tagħmir tar-radju 1001316154 huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: https://www.brp.com/en/sustainability/product-responsibility.html

**NL**

Hierbij verklaar ik, BRP Megatech, dat het type radioapparatuur 1001316154 conform is met Richtlijn 2014/53/EU.

De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: https://www. brp. com/en/sustainability/product-responsibility.html

**PL**

BRP Megatech niniejszym oświadcza, że typ urządzenia radiowego 1001316154 jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: https://www. brp. com/en/sustainability/product-responsibility.html

**PT**

O(a) abaixo assinado(a) BRP Megatech declara que o presente tipo de equipamento de rádio 1001316154 está em conformidade com a Diretiva 2014/53/UE.

O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: https://www. brp. com/en/sustainability/product-responsibility. html

**RO**

Prin prezenta, BRP Megatech declară că tipul de echipamente radio 1001316154 este în conformitate cu Directiva 2014/53/UE. Textul integral al declaratiei UE de conformitate este disponibil la următoarea adresă internet: https://www.brp.com/en/sustainability/product-responsibility.html

**SV**

Härmed försäkrar BRP Megatech att denna typ av radioutrustning 1001316154 överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: https://www.brp.com/en/sustainability/product-responsibility.html

## SL

BRP Megatech potrjuje, da je tip radijske opreme 1001316154 skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: https://www. brp. com/en/sustainability/product-responsibility.html

## SK

BRP Megatech týmto vyhlasuje, že rádiové zariadenie typu 1001316154 je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: https://www.brp.com/en/sustainability/product-responsibility.html

## IS

BRP Megatech lýsir því hér með yfir að þráðlausi fjarskiptabúnaðurinn 1001316154 er í samræmi við tilskipun 2014/53/ESB. Óstyttan texta ESB-samræmisyfirlýsingarinnar er að finna á veffanginu: https://www.brp.com/en/sustainability/product-responsibility.html

## Liechtenstein

Hiermit erklärt BRP Megatech, dass der Funkanlagentyp 1001316154 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: https://www.brp.com/en/sustainability/product-responsibility.html

## NO

Hermed erklærer BRP Megatech at radioutstyrstypen 1001316154 er i samsvar med direktiv 2014/53/EU. Hele teksten i EU-samsvarserklæringen finnes på følgende internettadresse: https://www. brp. com/en/sustainability/product-responsibility.html

## RU

Компания BRP Megatech настоящим заявляет, что радиотехническое оборудование категории 1001316154 отвечает требованиям Директивы 2014/53/EU.

Полный текст декларации соответствия ЕС доступен на сайте https://www.brp.com/en/sustainability/product-responsibility.html

# NOISE EMISSION AND VIBRATION VALUES

| Noise and Vibration[1] | | | |
|---|---|---|---|
| Exterior sound level (dB (A)) According to Annex II(EU) 2018/985 | Stationary | 650 | 79 dB (A) |
| | | 1000 | 81 dB (A) |
| | Moving | | 85 dB (A) |
| Driver perceived sound level (dB (A)) According to Annex XIII (EU) 1322/2014 | | | 78 dB (A) |
| Seat vibration According to Directive 78/764/EEC | Light driver $a_{ws}$ | | 0.508 |
| | Heavy driver $a_{ws}$ | | 0.534 |
| [1]: Noise emission and Vibration values are measured in accordance with Standard EN 15997:2011 on a paved surface, at Neutral. | | | |

565 de la Montagne Street
Valcourt (Quebec) J0E 2L0
Canada

www.brp.com

ADVENTURE BY DESIGN

# EU Declaration of Conformity

**Authorized Representative**: BRP-Rotax GmbH Co. KG, Rotaxstrasse 1, Gunskirchen, A- 4623, Austria

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The undersigned, representing the manufacturer, hereby declares that model year **2025 All Terrain Vehicles** marked with the CE mark and a 17-character vehicle identification number structured as **3JBxxxxxxSxxxxxxx** under commercial names **Can-Am Outlander** and **Can-Am Renegade** comply with all the relevant provisions of the following Directives and Regulations:

| | |
|---|---|
| Machinery (MD) Directive 2006/42/EC as amended up to and including Regulation(EU) 2019/1243 | ISO 12100:2010 |
| Non-Road Mobile Machinery (NRMM) Regulation (EU) 2016/1628 on gaseous pollutants as amended up to and including Regulation (EU) 2020/1040 | Category ATS,<br>Stage V emissions limits |
| Electromagnetic Compatibility (EMC) Directive 2014/30/EU as amended up to and including Regulation (EU) 2018/1139 | CISPR 12:2007/A1:2009 &<br>IEC 61000-6-1:2016 or<br>UN R10.04 or later version |
| Battery Directive 2006/66/EC as amended up to and including Directive (EU) 2018/849 and,<br>Regulation (EU) 1103/2010 on battery capacity labelling | EN 50342-7:2015 |
| Radio Equipment (RED) Directive 2014/53/EU as amended up to and including Regulation(EU) 2018/1139<br>(If fitted with radio frequency (RF) D.E.S.S. key) | Art. 3.1a: IEC 62368-1:2014<br>Art. 3.1b: CISPR 25:2016 & ISO 11452-2:2004<br>Art. 3.2: ETSI EN 300 330 V2.1.1:2017 |

Renald Plante, Eng.
Director, Product Development, Can-Am
Bombardier Recreational Products Inc.

Valcourt, QC, Canada
Jan 19, 2024

ski-doo LYNX SEA-DOO EVINRUDE ROTAX can-am

565 de la Montagne Street
Valcourt (Quebec) J0E 2L0
Canada

www.brp.com

BRP ADVENTURE BY DESIGN

# UK Declaration of Conformity

**Authorized Representative**: BRP UK Ltd., (BWM Accountants Limited), Suite 5.1, 12 Tithebarn Street, Liverpool, L2 2DT

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The undersigned, representing the manufacturer, hereby declares that model year **2025 All Terrain Vehicles** marked with the UK CA mark and a 17-character vehicle identification number structured as **3JBxxxxxxSxxxxxxx** under commercial names **Can-Am Outlander** and **Can-Am Renegade** comply with all the relevant provisions of the following Statutory Instruments:

| | |
|---|---|
| Supply of Machinery (Safety) Regulations 2008, UK SI 2008/1597 as amended up to and including SI 2020/1112 | ISO 12100:2010 |
| Non-Road Mobile Machinery (Type-Approval and Emission of Gaseous and Particulate Pollutants) Regulations 2018, UK SI 2018/764 as amended up to and including SI 2020/1393 | Category ATS,<br>Stage V emissions limits |
| Electromagnetic Compatibility Regulations 2016, UK SI 2016/1091 as amended up to and including SI 2020/1112 | CISPR 12:2007/A1:2009 &<br>IEC 61000-6-1:2016 or<br>UN R10.04 or later version |
| Batteries and Accumulators (Placing on the Market) Regulations 2008, UK SI 2008/2164 as amended up to and including UK SI 2020/904 | EN 50342-7:2015 |
| Radio Equipment Regulations 2017, UK SI 2017/1206 as amended up to and including SI 2020/1112<br>(If fitted with radio frequency (RF) D.E.S.S. key) | Art. 3.1a: IEC 62368-1:2014<br>Art. 3.1b: CISPR 25:2016 & ISO 11452-2:2004<br>Art. 3.2: ETSI EN 300 330 V2.1.1:2017 |

Renald Plante, Eng.
Director, Product Development, Can-Am ATV & Spyder
Bombardier Recreational Products Inc.

Valcourt, QC, Canada
Jan 19, 2024

ski-doo LYNX SEA-DOO EVINRUDE ROTAX can-am

# EAC DECLARATION OF CONFORMITY

**Left blank for Eurasian Conformity mark where applicable**

This page is intentionally blank

# TECHNICAL SPECIFICATIONS

# TECHNICAL SPECIFICATIONS

| Engine | | | |
|---|---|---|---|
| Type | | | ROTAX®, 4-stroke, 2 cylinders (V-twin), liquid cooled |
| Valve train | | | 4 valves/cylinder (mechanical adjustment), single over head camshaft (SOHC) with timing chain |
| Valve clearance | Intake | | 0.06 to 0.14 mm (.0024 to .0055 in) |
| | Exhaust | | 0.11 to 0.19 mm (.0043 to .0075 in) |
| Bore | | 650 | 82 mm (3.23 in) |
| | | 1000 | 91 mm (3.58 in) |
| Stroke | | 650 | 61.5 mm (2.42 in) |
| | | 1000 | 75 mm (2.95 in) |
| Displacement | | 650 | 650 cm³ (39.7 in³) |
| | | 1000 | 976 cm³ (59.6 in³) |
| Exhaust system | | NRMM models | Catalyst equipped |
| | | Other models | Spark arrestor approved by USDA Forest Service |
| Engine air filter | | | Synthetic paper filter with foam |

| Lubrication System | | | |
|---|---|---|---|
| Type | | | Wet sump. Replaceable cartridge oil filter |
| Oil filter | | | BRP Rotax paper type, replaceable |
| Engine oil | Capacity (oil change with filter) | | 2.0 l (2.1 qt (liq.,US)) |
| | Recom mended XPS oil | General purpose | XPS 4T 5W40 Synthetic blend oil |
| | | Cold temperature | XPS 4T 0W40 Synthetic oil |

| Lubrication System | | | |
|---|---|---|---|
| | | Warm temperature | XPS 4T 10W50 Synthetic oil |
| | Alternate oil if XPS products are not available | | 5W40 or 10W50 motor oil that meets the requirements for API service classification SN or JASO MA2 |

| Cooling System | | | |
|---|---|---|---|
| Coolant | Recommended XPS coolant | | XPS extended life pre-mixed coolant |
| | Alternate if XPS product is not available | | Ethyl glycol / water mix (50%/50%). or coolant specifically designed for aluminum engines |
| | Capacity | 650 | 3.4 l (.9 gal (liq.,US)) |
| | | 1000 | 3.5 l (.92 gal (liq.,US)) |

| Transmission | |
|---|---|
| Type | CVT (Continuously Variable Transmission), sub-transmission with L/H/N/R/P, standard engine braking |
| Engagement RPM | 1650 RPM ± 100 RPM |

| Gearbox | | |
|---|---|---|
| Type | | Dual range (HI-LO) with park, neutral and reverse |
| Gearbox oil | Capacity | 450 ml (15.22 fl oz (US)) |
| | Recommended XPS oil | XPS 75W140 Synthetic gear oil |
| | Alternate if XPS product is not available | 75W140 API GL-5 synthetic gear oil |

| Electrical System | | |
|---|---|---|
| Magneto generator output | | 650 W @ 6000 RPM |
| Ignition system type | | IDI (Inductive Discharge Ignition) |
| Ignition timing | | Not adjustable |
| Spark plug | Quantity | 2 |
| | Make and type | NGK DCPR8E or equivalent |
| | Gap | 0.8 to 0.9 mm (.031 to .035 in) |
| Engine RPM limiter setting | Forward | 8000 RPM |
| | Reverse (without override) | 15 km/h (9 MPH) |
| Battery | Type | Maintenance free |
| | Voltage | 12 volts |
| | Nominal rating | 18 A•h |
| | Power starter output | 750 W |
| Headlights | High | LEDs |
| | Low | LEDs |
| Taillights | | 2 x 5/21 W |
| Turn signal lights | | LEDs |
| Position lights | | LEDs |
| Licence plate light | | 2 x 5 W |
| Fuses | | Refer to *Fuses* in *Maintenance* |

| Fuel System | | |
|---|---|---|
| Fuel delivery | | Electronic Fuel Injection (EFI), 46 mm throttle body, 1 injector per cylinder |
| Fuel pump | Type | Electrical (in fuel tank) |
| Idle speed | | 1250 RPM ± 100 RPM |
| Fuel | Type | Regular unleaded gasoline<br>Refer to *Fuel Requirement* |
| | Minimum octane rating | 91 RON or higher |

| Fuel System | |
|---|---|
| Fuel tank capacity | 20.5 l<br>(5.4 gal (liq.,US)) |
| Fuel remaining when low fuel light turns ON | ± 5 l<br>(1.3 gal (liq.,US)) |

| Drive System | | | |
|---|---|---|---|
| Drive system type | | | Selectable 4WD, 6WD and 6WDLock |
| Front drive | | | Visco-4Lok auto-locking and full lock front differential |
| Front drive ratio | | | 3.6:1 |
| Rear drive | | | Spiral bevel gear / Shaft driven final drive |
| Rear drive ratio | | | 3.6:1 |
| Front differential oil | Capacity | | 400 ml<br>(14 fl oz (US)) |
| | Recommended oil | | 75W90 Synthetic gear oil |
| | If XPS product in ot available | | Use synthetic gear oil 75W90 API GL-5 |
| Middle differential oil<br>Rear final drive oil | Capacity | Middle | 400 ml<br>(14 fl oz (US)) |
| | | Rear | 300 ml<br>(10.2 fl oz (US)) |
| | Recommended XPS oil | | XPS 75W140 Synthetic gear oil |
| | Alternate if XPS product is not available | | 75W140 API GL-5 synthetic gear oil |
| CV joint grease | | | XPS CV joint grease or an equivalent |
| Propeller shaft grease | | | XPS Propeller shaft grease or an equivalent |

| Front Suspension | | |
|---|---|---|
| Suspension type | | Double arched suspension-arm with stabilizer bar |
| Suspension travel | | 23.3 cm<br>(9.2 in) |
| Shock absorber | Qty | 2 |

| Front Suspension | | |
|---|---|---|
| | Type | Oil |
| Preload adjustment type | | 5 positions cam |

| Rear Suspension | | |
|---|---|---|
| Suspension type | | Double Torsional Trailing arm Independent (TTI2) with quick release stabilizer bar |
| Suspension travel | | 25.1 cm (9.9 in) |
| Shock absorber | Qty | 4 |
| | Type | Oil |
| Preload adjustment type | | 5 position cam |

| Brakes | | |
|---|---|---|
| Type | | Hydraulic disc brakes |
| Front brake | Qty | 2 |
| | Type | 214 mm cross drilled disc brakes with hydraulic twin-piston calipers |
| Rear brake | Qty | 2 |
| | Type | 214 mm cross drilled disc brake with hydraulic twin-piston caliper |
| Brake fluid | Capacity | 260 ml (8.8 fl oz (US)) |
| | Type | DOT 4 |
| Caliper | | Floating twin pistons (2 x 26 mm) |
| Brake pad material | | Organic |
| Minimum brake pad thickness | | 1 mm (.04 in) |
| Minimum brake disc thickness | | 4.0 mm (.157 in) |
| Maximum brake disc warpage | | 0.2 mm (.01 in) |

| Tires | | |
|---|---|---|
| Pressure | | Recommended tire inflation pressure is found on the Tire Label. Refer to appropriate *Important On-Product Labels* section for its location. |
| Minimum tire thread depth | | 3 mm (.118 in) |
| Size | Front | 205/90-14 (26x8-14) |
| | Rear | 255/70-14 (26x10-14) |

| Wheels | | |
|---|---|---|
| Type | | Cast aluminum |
| Rim size | Front | 35,6 x 16,5 cm (14 x 6.5 in) |
| | Rear | 35,6 x 21.6 cm (14 x 8.5 in) |
| Wheel offset | Front | 41.2 mm (1.62 in) |
| | Middle Rear | 51 mm (2.01 in) |
| Wheel lug nut torque | | 80 ± 5 Nm (59 ± 4 lbf-ft) |

| Dimensions | | |
|---|---|---|
| Overall length | 1-UP | 297 cm (117 in) |
| | 2-UP | 317 cm (124,8 in) |
| Overall width | | 122 cm (48 in) |
| Overall height | 1-UP | 149,4 cm (58,8 in) |
| | 2-UP | 163,4 cm (64,3 in) |
| Wheelbase | 1-UP | 208 cm (82 in) |
| | 2-UP | 228 cm (90 in) |

| Dimensions | | |
|---|---|---|
| Wheel track | Front | 101 cm (40 in) |
| | Rear | 96 cm (38 in) |
| Ground clearance | | 27,9 cm (11 in) |

| Weight and Loading Capacity | | | |
|---|---|---|---|
| Dry weight | 1-UP | 650 | 574 kg (1,265 lb) |
| | | 1000 | 576 kg (1,270 lb) |
| | 2-UP | 650 | 595 kg (1,312 lb) |
| | | 1000 | 597 kg (1,316 lb) |
| Front rack capacity | | | 45 kg (100 lb) |
| Cargo bed | | | 318 kg (700 lb) of which at least 45 kg (100 lb) in rear storage box |
| Weight distribution per axle Front/Middle/Rear (%) | | | 28/35/37 |
| Total payload allowed (including driver, passenger, all other loads and added accessories) | | 1-UP | 460 kg (1.015 lb) |
| | | 2-UP | 460 kg (1.015 lb) |
| Towing capacity | Trailer without brakes | | 674 kg (1,486 lb) |
| | Trailer with inertial-brakes | | 907 kg (2,000 lb) |
| Tongue capacity (unbraked or inertial brakes) | | | 67.5 kg (149 lb) |

# PARTS CATALOG

# ONLINE PARTS CATALOG

The parts catalog required for your Can-Am ATV is available on our website at:

**www.epc.brp.com**

# TROUBLESHOOTING

# TROUBLESHOOTING GUIDELINES

## Engine Does Not Turn

### 1. Engine stop switch.

– *Make sure that engine stop switch is in ON position.*

### 2. D.E.S.S. key is not installed on D.E.S.S. post.

– *Securely install D.E.S.S. key to D.E.S.S. post.*

### 3. The digital display shows BAD KEY.

– *Wrong D.E.S.S. key, use the proper key for this vehicle.*

### 4. Transmission is not set on PARK or NEUTRAL.

– *Set transmission either in PARK or in NEUTRAL or press the brake lever.*
– *Press the brake lever*

### 5. Burnt fuse.

– *Check main fuse condition.*

### 6. Weak battery or loose connections.

– *Check charging system.*
– *Check connections and terminals condition.*
– *Have the battery checked.*
– *Contact an authorized Can-Am Off-road dealer.*

### 7. Weak starter or loose connections.

– *Check starter connections.*
– *Check starter relay.*

## Engine Turns Over But Fails To Start

### 1. Flooded engine (spark plug wet when removed).

– *Refer to Flooded Engine in Special Procedures.*

### 2. No fuel to the engine (spark plug dry when removed).

– *Check fuel tank level.*
– *Check fuel pump fuse and relay.*
– *A failure of the fuel pump may have occurred.*
– *If engine does not start, seek service from an authorized Can-Am dealer, repair shop, or person of your own choosing for maintenance, repair, or replacement.*

### 3. Spark plug/ignition (no spark).

– *Check injectors/ignition fuse condition.*
– *Remove spark plug then reconnect to ignition coil.*
– *Start engine with spark plug grounded to the engine away from spark plug hole. If no spark appears, replace spark plug.*

– *If trouble persists, seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement*

### 4. CHECK ENGINE indicator lamp is on and the digital display shows CHECK ENGINE.

– *Seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

### 5. Engine is under a protection mode (limp home).

– *The CHECK ENGINE indicator lamp is on and the digital display shows CHECK ENGINE, seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

## Engine Lacks Acceleration or Power

### 1. Fouled or defective spark plug.

– *Refer to Engine Turns Over But Fails To Start.*

### 2. Lack of fuel to engine.

– *Refer to Engine Turns Over But Fails To Start.*

### 3. Engine is overheating. (CHECK ENGINE indicator light will turn on and HI TEMP will appear in the digital display.)

– *Refer to Engine Overheats.*

### 4. Air filter/housing clogged or dirty.

– *Check air filter and clean if necessary.*
– *Check deposits in air filter housing drain.*
– *Check the position of the air intake tube.*

### 5. CVT dirty or worn-out.

– *Contact an authorized Can-Am dealer.*

### 6. Engine is under a protection (limp home) mode.

– *Check digital display for messages.*
– *The CHECK ENGINE indicator lamp is on and the digital display shows CHECK ENGINE or LIMP HOME, seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

## Engine Overheats

### 1. Low coolant in cooling system.

– *Check engine coolant, refer to Verifying the Engine Coolant in Maintenance Procedures.*

### 2. Dirty radiator fins.

– *Clean radiator fins, refer to Inspecting the Radiator in Maintenance Procedures.*

### 3. Cooling fan inoperative.

– *Check cooling fan fuse or relay, refer to Fuses in Maintenance Procedures. If the fuse is good, seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

## Engine Backfire

### 1. Exhaust system leakage.

– *Seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

### 2. Engine is running too hot.

– *Refer to Engine Lacks Acceleration Or Power.*

### 3. Ignition timing is incorrect or there is an ignition system failure.

– *Seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

## Engine Misfire

### 1. Fouled/defective/worn spark plug.

– *Clean/verify spark plug and heat range. Replace as required.*

### 2. Water in fuel.

– *Drain fuel system and refill with fresh fuel.*

## Vehicle Cannot Reach Full Speed

### 1. Engine problems.

– *Refer to Engine Lacks Acceleration Or Power.*

### 2. Brake lock lever engaged.

– *Ensure the brake lock lever is completely disengaged.*

### 3. Air filter/housing plugged or dirty.

– *Check air filter and clean if necessary.*
– *Check deposits in air filter housing drain.*
– *Check the position of the air intake tube.*

### 4. CVT dirty or worn-out.

– *Contact an authorized Can-Am dealer.*

### 5. Engine is under a protection mode (limp home).

– *Check digital display for messages.*
– *The CHECK ENGINE indicator lamp is on and the digital display shows CHECK ENGINE or LIMP HOME, seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

## Shift Lever Is Hard To Move

### 1. Transmission gears are in a position that prevents the shift lever to work.

– *Rock the vehicle back and forth to move the gears in the transmission and allow the shift lever to be set.*

### 2. CVT dirty or worn-out.

– *Contact an authorized Can-Am dealer.*

## The RPM Increases But The Vehicle Does Not Move

### 1. The transmission is on PARK or NEUTRAL position.

– *Select the R, HI or LO position.*

### 2. CVT dirty or worn-out.

– *Contact an authorized Can-Am dealer.*

### 3. Water in the CVT housing.

– *Contact an authorized Can-Am dealer.*

## Reduced Power Steering Assist

### 1. When DPS is subjected to sustained severe steering conditions, the assistance provided by the DPS motor may be reduced to protect the system.

– *Once the load is reduced, the normal steering assistance will return.*

### 2. The CHECK ENGINE indicator lamp is ON and the digital display shows CHECK DPS

– *Seek service from an authorized Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement.*

# DIGITAL DISPLAY MESSAGES

| Message | Pilot lamp(s) ON | Beeper | Description |
|---|---|---|---|
| BAD KEY | | None | Indicates that you have used the wrong ignition key or D.E.S.S. key, use the proper key for this vehicle. It is also possible that the key has a bad contact, remove and clean key. |
| DESS KEY NOT RECOG NIZED | | None | Indicates that there possibly is a bad contact, remove and clean key. |
| BRAKE | | Single - short | Is displayed when the brake lock lever is engaged for more than 15 seconds (while riding) or, When the brake lever or the foot brake pedal is activated while riding. |
| LO BATT | | None | Low battery voltage, check battery voltage and charging system. |
| HI BATT | | None | High battery voltage, check battery voltage and charging system. |
| LOW OIL (1) | | Single - long | Engine low oil pressure, stop engine immediately. |
| HI TEMP | | Single - long | Engine is overheating, refer to *ENGINE OVERHEATS* in *Troubleshooting* |
| LIMP HOME | | Single - long | Serious fault on the engine that can change the normal operation of the engine, CHECK ENGINE indicator lamp will also blink, refer to *Troubleshooting*. |
| CHECK ENGINE | | None | Engine fault, CHECK ENGINE indicator lamp will also be ON, refer to *Troubleshooting*. |
| NO ECM COMMUNICA TION | | None | Communication error between speedometer and engine control module (ECM) |
| CHECK DPS | | None | Indicates that the Dynamic Power Steering (DPS) does not work properly. See an authorized Off-road Can-Am dealer. |
| MAINTE NANCE REQUIRED | | None | Displayed in gauge when vehicle is due for a maintenance |

| | | | |
|---|---|---|---|
| TPS FAULT PRESS OVERRIDE BUTTON TO LIMP HOME | | None | Throttle position sensor does not work properly. Seek service from an authorized OFF-road Can-Am dealer, repair shop or person of your own choosing for maintenance, repair or replacement. |
| FRONT DIFFEREN TIAL LOCK -UNLOCK | None | Double - short | The front differential lock is unlocked. |
| SPORT MODE ACTIVE | SPORT | Single - short | The SPORT mode is now selected. |
| SPEED LIMITER ACTIVE | | Single - short | The speed limiter is activated. |

**NOTICE**

**(1) If the message and the check engine light stays on after engine starting, stop engine. Check engine oil level. Refill if necessary. If the oil level is good, seek service from an authorized Can-Am off-road dealer, repair shop or person of your own choosing for maintenance, repair or replacement. Please refer to the US EPA Emissions-related warranty contained herein for information about warranty claims. Do not use the vehicle until repaired.**

This page is intentionally blank

# WARRANTY

# BRP LIMITED WARRANTY USA AND CANADA: 2025 CAN-AM® ATV

## 1) SCOPE OF THE LIMITED WARRANTY

Bombardier Recreational Products Inc. ("**BRP**") warrants its 2025 Can-Am ATV (the "**Product**") sold by authorized BRP dealers in the United States of America ("USA") and in Canada (a "**BRP Dealer**") from defects in material or workmanship for the period and under the conditions described below.

This limited warranty will become null and void if:

1. the Product was used for racing or any other competitive activity, at any point, even by a previous owner; or
2. the Product has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

Non-factory installed parts and accessories are not covered under this limited warranty. Please refer to the applicable parts and accessories limited warranty text.

## 2) LIMITATIONS OF LIABILITY

TO THE EXTEND PERMITTED BY LAW, THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM COVERAGE UNDER THIS WARRANTY. SOME STATES/PROVINCES DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE. AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM STATE TO STATE, OR PROVINCE TO PROVINCE.

Neither the distributor, any BRP Dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the Product, other than those contained in this limited warranty, and if made, shall not be enforceable against BRP.

BRP reserves the right to modify this limited warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the Products sold while this warranty is in effect.

## 3) EXCLUSIONS–ARE NOT WARRANTED

The following are not warranted under any circumstances:

– Normal wear and tear;
– Routine maintenance items, tune ups, adjustments;
– Damage caused by negligence or failure to provide proper maintenance and/or storage, as described in the Operator's Guide;
– Damage resulting from removal of parts, improper repairs, service, maintenance, modifications or use of parts not manufactured or approved by BRP or

resulting from repairs done by a person that is not an authorized servicing BRP Dealer;
- Damage caused by abuse, abnormal use, neglect or operation of the Product in a manner inconsistent with the recommended operation described in the Product's Operator's Guide;
- Damage resulting from accident, submersion, fire, theft, vandalism or any act of God;
- Operation with fuels, oils or lubricants which are not suitable for use with the Product (see the Operator's Guide);
- Damages from rust, corrosion or exposure to the elements;
- Damage resulting from water or snow ingestion;
- Incidental or consequential damages, or damages of any kind including without limitation transportation expenses, towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan payments, loss of time, loss of income or time missed for downtime experience due to service work.

## 4) WARRANTY COVERAGE PERIOD

This limited warranty will be in effect from (1) the date of delivery to the first retail consumer, or (2) the date the Product is first put into use, whichever occurs first and for the applicable period below:

- SIX (6) consecutive months, for private use or commercial use owners
- **For emission-related components**, please also refer to the *US EPA Emission– Related Warranty*.
- **For evaporative emission-related components of California models equipped with evaporative emission control system produced by BRP for sale in the State of California** that are originally sold to a resident or subsequently warranty registered to a resident in the State of California, also refer to the *California Evaporative Emissions Control Warranty Statement*.

The repair or replacement of parts or the performance of service under this warranty does not extend the life of this limited warranty beyond its original expiration date.

## 5) CONDITIONS TO HAVE WARRANTY COVERAGE

This warranty coverage is available only if each of the following conditions has been fulfilled:

- The Product must be purchased as new and unused by its first owner from a BRP Dealer authorized to sell the Products in the country in which the sale occurred;
- The BRP specified pre-delivery inspection process must be completed, documented and signed by the purchaser;
- The Product must have undergone proper registration by an authorized BRP Dealer;
- The Product must be purchased in the country in which the purchaser resides;
- Routine maintenance outlined in the Operator's Guide must be timely performed in order to maintain warranty coverage. BRP reserves the right to make warranty coverage contingent upon proof of proper maintenance.

BRP will not honor this limited warranty to any private use owner or commercial use owner if one of the preceding conditions has not been met. Such limitations

are necessary in order to allow BRP to preserve both the safety of its products, and also that of its consumers and the general public.

## 6) WHAT TO DO TO OBTAIN WARRANTY COVERAGE

The customer must cease using the Product upon the appearance of an anomaly, notify a servicing BRP Dealer within three (3) days of the appearance of the anomaly and provide the BRP Dealer with reasonable access to the Product and reasonable opportunity to repair it.

The customer must also present to the BRP Dealer, proof of purchase of the Product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair.

All parts replaced under this limited warranty become the property of BRP.

## 7) WHAT BRP WILL DO

BRP’s obligations under this warranty are limited to, at its sole discretion, repairing or replacing parts found defective under normal use, maintenance and service without charge for parts and labor, at any authorized BRP Dealer during the warranty coverage period under the conditions described herein. No claim of breach of warranty shall be cause for cancellation or rescission of the sale of the Product to the owner.

In the event that service is required outside of the country of original sale, the owner will bear responsibility for any additional charges due to local practices and conditions, such as, but not limited to, freight, insurance, taxes, license fees, import duties, and any and all other financial charges, including those levied by governments, states, territories and their respective agencies.

BRP reserves the right to improve or modify products from time to time without assuming any obligation to modify products previously manufactured.

## 8) TRANSFER

If the ownership of a Product is transferred during the warranty coverage period, this limited warranty, subject to its terms and conditions, shall also be transferred and be valid for the remaining coverage period provided BRP or an authorized BRP Dealer receives a proof that the former owner agreed to the transfer of owner- ship, in addition to the coordinates of the new owner.

## 9) CONSUMER ASSISTANCE

In the event of a controversy or a dispute in connection with this limited warranty, BRP suggests that you try to resolve the issue at the dealership level. We recommend dis- cussing the issue with the authorized BRP dealer's service manager or owner.

If the matter still remains unresolved, contact BRP by filling out the customer contact form at **www.brp.com** or contact BRP by mail at one of the addresses listed under the *Contact Us* section of this guide.

# US EPA EMISSION - RELATED WARRANTY

Bombardier Recreational Products Inc. (“BRP”) warrants to the ultimate purchaser and each subsequent purchaser that this new vehicle, including all parts of its exhaust emission control system and its evaporative emission control system, meets two conditions:

1. It is designed, built, and equipped so it conforms at the time of sale to the ultimate purchaser with the requirements of 40 CFR 1051 and 40 CFR 1060.
2. It is free from defects in materials and workmanship that may keep it from meeting the requirements of 40 CFR 1051 and 40 CFR 1060.

Where a warrantable condition exists, BRP will repair or replace, as it elects, any part or component with a defect in materials or workmanship that would increase the engine’s emissions of any regulated pollutant within the stated warranty period at no cost to the owner, including expenses related to diagnosing and repairing or replacing emission-related parts. All defective parts replaced under this warranty become the property of BRP.

For all emission-related warranty claims, BRP is limiting the diagnosis and repair of emission-related parts to the authorized Can-Am dealers, unless for emergency repairs as required by item 2 of the following list.

As a certifying manufacturer, BRP will not deny emission-related warranty claims based on any of the following:

1. Maintenance or other service BRP or BRP's authorized facilities performed.
2. Engine/equipment repair work that an operator performed to correct an unsafe, emergency condition attributable to BRP as long as the operator tries to restore the engine/equipment to its proper configuration as soon as possible.
3. Any action or inaction by the operator unrelated to the warranty claim.
4. Maintenance that was performed more frequently than BRP specify.
5. Anything that is BRP fault or responsibility.
6. The use of any fuel that is commonly available where the equipment operates unless BRP written maintenance instructions state that this fuel would harm the equipment’s emission control system and operators can readily find the proper fuel. See maintenance information section and fuel requirements of fueling section.

## Emission-Related Warranty Period

The emission-related warranty is valid for the following period whichever comes first.

| | HOURS | MONTHS | KILOMETERS |
|---|---|---|---|
| Exhaust emission-related components | 500 | 30 | 5000 |
| Evaporative emission-related components | N/A | 24 | N/A |

## Components Covered

The emission-related warranty covers all components whose failure would increase an engine’s emissions of any regulated pollutant, including the following listed components:

1. For exhaust emissions, emission-related components include any engine parts related to the following systems:
   - Air-induction system
   - Fuel system
   - Ignition system
   - Exhaust gas recirculation systems.
2. The following parts are also considered emission-related components for exhaust emissions:
   - After treatment devices
   - Crankcase ventilation valves
   - Sensors
   - Electronic control units.
3. The following parts are considered emission-related components for evaporative emissions:
   - Fuel tank
   - Fuel cap
   - Fuel line
   - Fuel line fittings
   - Clamps*
   - Pressure relief valves*
   - Control valves*
   - Control solenoids*
   - Electronic controls*
   - Vacuum control diaphragms*
   - Control cables*
   - Control linkages*
   - Purge valves
   - Vapor hoses
   - Liquid/vapor separator
   - Carbon canister
   - Canister mounting brackets
   - Carburetor purge port connector.

**NOTE:**
*As related to the evaporative emission control system.

4. Emission-related components also include any other part whose only purpose is to reduce emissions or whose failure will increase emissions without significantly degrading engine/equipment performance.

## Limited Applicability

As a certifying manufacturer, BRP may deny emission-related warranty claims for failures that have been caused by the owner's or operator's improper maintenance or use, by accidents for which the manufacturer has no responsibility, or by acts of God. For example, an emission-related warranty claim need not be honored for failures that have been directly caused by the operator's abuse of the engine/equipment or the operator's use of the engine/equipment in a manner for which it was not designed and are not attributable to the manufacturer in anyway.

If you have any question regarding your warranty rights and responsibility or for the name and location of the nearest authorized BRP dealer, you should contact BRP by filling out the customer contact form at **www.brp.com** or contact BRP by mail at one of the addresses listed under the CONTACT US section of this guide, or call at 1-888-272-9222.

# CALIFORNIA EVAPORATIVE EMISSIONS CONTROL WARRANTY STATEMENT

The warranty periods begin on the date the new Off-Highway Recreational Vehicle (“OHRV”) is delivered to an ultimate purchaser.

Bombardier Recreational Products Inc. (“BRP”) warrants to the ultimate purchaser and each subsequent purchaser that the OHRV is:

1. Designed, built, and equipped so as to conform, at the time of sale, with all applicable laws, rules and regulations; and
2. Free from defects in materials and workmanship that may cause the failure of a warranted part. All replacement parts must be identical in all material respects to that part as described in BRP’s Executive Order of Certification application.

The warranty on emissions-related parts function as follows:

1. Repair or replacement of any warranted part must be performed at no charge to the OHRV owner, at a warranty station, except in the case of a temporary repair when a warranted part or a warranty station is not reasonably available to the OHRV owner. In the event a temporary repair is permitted, repairs may be performed at any available service establishment, or by the owner, using any replacement part. BRP must reimburse the owner for his or her expenses including diagnostic charges for such temporary repair or replacement, not to exceed BRP's suggested retail price for all warranted parts replaced and labor charges based on BRP's recommended time allowance for the warranty repair and the geographically appropriate hourly labor rate.
2. The lack of availability of warranted parts or the incompleteness of repairs within a reasonable time period, not to exceed 30 days from the time the OHRV is initially presented to the warranty station for repair, will qualify the need for a temporary repair.
3. Any warranted part which is not scheduled for replacement as part of maintenance in the written instructions must be warranted for the warranty period defined below. If any such part fails during the warranty period, it must be repaired or replaced by BRP. Any such part repaired or replaced under warranty must be fully warranted.
4. Any warranted part which is scheduled only for regular inspection in the written instructions must be warranted for the warranty period defined below. A statement in such written instructions to the effect of “repair or replace as necessary” does not reduce the period of warranty coverage. Any such part repaired or replaced under warranty is warranted for the remaining warranty period.
5. Any warranted part which is scheduled for replacement as part of maintenance in the written instructions is warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails before the first scheduled replacement point, the part will be repaired or replaced by BRP. Any such part repaired or replaced under warranty is warranted for the remainder of the period prior to the first scheduled replacement point for the part.
6. Warranty services or repairs are provided at all manufacturer dealerships that are owned by the manufacturer or franchised to service the subject OHRVs.
7. The OHRV owner will not be charged for diagnostic labor which leads to the determination that a warranted part is, in fact, defective, provided that such diagnostic work is performed at a warranty station.

8. BRP is liable for damages to other vehicle components proximately caused by a failure, under warranty, of any warranted part.
9. Any replacement part designated by BRP may be used in warranty repairs provided without charge to the OHRV owner. Such use will not reduce the warranty obligations of BRP, except that BRP will not be liable for repair or replacement of any replacement part which is not a warranted part.
10. Any add-on or modified part exempted by the Air Resources Board from the prohibitions of section 27156 of the California Vehicle Code may be used on an OHRV. Such use, in and of itself, will not be grounds for disallowing a warranty claim. BRP is not liable to warrant failures of warranted parts caused by the use of an add-on or modified part (s) unless such part (s) are also warranted.

Conditions and exclusions:

– BRP may deny you warranty coverage if your OHRV or a part has failed directly due to abuse, neglect, improper maintenance or unapproved modifications.

## Your Warranty Rights And Obligations

The California Air Resources Board is pleased to explain the evaporative emissions control system warranty on your 2025 All-Terrain Vehicle. In California, new off-highway recreational vehicles must be designed, built, and equipped to meet the State's stringent anti-smog standards. BRP must warrant the evaporative emissions control system on your All-Terrain Vehicle for the periods of time listed below provided there has been no abuse, neglect, improper maintenance, or unapproved modification of your All-Terrain Vehicle.

Your evaporative emissions control system may include parts such as the carburetor or fuel-injection system, fuel tank, fuel hoses, carbon canister, and engine computer. Also included may be hoses, belts, connectors and other evaporative emissions-related assemblies. Where a warrantable condition exists, Bombardier Recreational Products Inc. will repair your All-Terrain Vehicle at no cost to you including diagnosis, parts and labor.

## OHRV Manufacturer's Warranty Coverage

The warranty period for this OHRV is 60 months, or 5000 miles, or 500 hours, whichever comes first.

Parts covered:

1. Canister Mounting Bracket(s)
2. Carbon Canister
3. Purge Port Connector
4. Clamp(s)*
5. Electronic Control*
6. Fuel Cap
7. Filler Neck
8. Filler Neck Hose
9. Fuel Line(s)
10. Fuel Line Fitting(s)
11. Fuel Tank
12. Pressure Relief Valve(s)*

13. Purge Valve(s)
14. Check Valve(s)*
15. Vapor Hose(s)
16. Flow Reducer
17. Filter(s)*
18. Fuel pump
19. All other parts not listed that may affect the evaporative emissions control system

**NOTE:**
*As related to the evaporative emission control system.

If any evaporative emissions-related part on your All-Terrain Vehicle is defective the part will be repaired or replaced by Bombardier Recreational Products Inc.

## Owner's Warranty Responsibilities

As the All-Terrain Vehicle owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Bombardier Recreational Products Inc. recommends that you retain all receipts covering maintenance on your All-Terrain Vehicle, but Bombardier Recreational Products Inc. cannot deny warranty solely for the lack of receipts or for failure to ensure the performance of a scheduled maintenance.

As an owner you are responsible for presenting your All-Terrain Vehicle to a Bombardier Recreational Products Inc. dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable time, not to exceed 30 days.

As an All-Terrain Vehicle owner, you should also be aware that Bombardier Recreational Products Inc. may deny you warranty coverage if your All-Terrain Vehicle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact:

– Bombardier Recreational Products Inc. at 1-888-272-9222 or,
– The California Air Resources Board at 4001 Iowa Avenue, Riverside, CA 92507.

# BRP INTERNATIONAL LIMITED WARRANTY: 2025 CAN-AM® ATV

## 1) SCOPE OF THE LIMITED WARRANTY

Bombardier Recreational Products Inc. ("**BRP**") warrants its 2025 Can-Am ATV (the "**Product**") sold by distributors or dealers authorized by BRP to distribute the Pro- ducts outside of the United States of America ("**USA**"), Canada, member states of the European Economic Area (which is comprised of the states of the European Union plus the United Kingdom, Norway, Iceland and Liechtenstein) ("**EEA**"), member states of the Commonwealth of the Independent States (including Ukraine and Turkmenistan) ("**CIS**") and Turkey (a "**BRP Distributor/ Dealer**") from defects in material or workmanship for the period and under the conditions described below.

This limited warranty will become null and void if:

1. the Product was used for racing or any other competitive activity, at any point, even by a previous owner; or
2. the Product has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

Non-factory installed parts and accessories are not covered under this limited warranty. Please refer to the applicable parts and accessories limited warranty text.

## 2) LIMITATIONS OF LIABILITY

TO THE EXTEND PERMITTED BY LAW, THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM COVERAGE UNDER THIS WARRANTY. SOME JURISDICTIONS DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE. AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM COUNTRY TO COUNTRY. BRP SHALL NOT BE HELD LIABLE IF PRODUCTS OR WARRANTY PARTS ARE NOT AVAILABLE IN CERTAIN COUNTRIES FOR REASONS OUTSIDE OF BRP'S CONTROL.

For Products purchased in Australia, refer to the Australia-specific section below.

Neither any BRP Distributor/Dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the Product, other than those contained in this limited warranty, and if made, shall not be enforceable against BRP.

BRP reserves the right to modify this limited warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the Products sold while this warranty is in effect.

## 3) EXCLUSIONS – ARE NOT WARRANTED

The following are not warranted under any circumstances:

- Normal wear and tear;
- Routine maintenance items, tune ups, adjustments;
- Damage caused by negligence or failure to provide proper maintenance and/ or storage, as described in the Operator's Guide;
- Damage resulting from removal of parts, improper repairs, service, maintenance, modifications or use of parts not manufactured or approved by BRP or resulting from repairs done by a person that is not an authorized servicing BRP Distributor/ Dealer;
- Damage caused by abuse, abnormal use, neglect or operation of the Product in a manner inconsistent with the recommended operation described in the Product’s Operator’s Guide;
- Damage resulting from accident, submersion, fire, theft, vandalism or any act of God;
- Operation with fuels, oils or lubricants which are not suitable for use with the Product (see the Operator’s Guide);
- Damages from rust, corrosion or exposure to the elements;
- Damage resulting from water or snow ingestion;
- Incidental or consequential damages, or damages of any kind including without limitation transportation expenses, towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan payments, loss of time, loss of income or time missed for downtime experience due to service work.

## 4) WARRANTY COVERAGE PERIOD

This limited warranty will be in effect from (1) the date of delivery to the first retail consumer, or (2) the date the Product is first put into use, whichever occurs first and for the applicable period below:

- SIX (6) consecutive months, for private use or commercial use owners

In AUSTRALIA and NEW ZEALAND only, this warranty will be in effect from (1) the date of delivery to the first retail consumer or (2) the date the Product is first put into use, whichever occurs first, and for a period of TWELVE (12) CONSECUTIVE MONTHS and THIRTY-SIX (36) CONSECUTIVE MONTHS for Powertrain Engine and Transmission systems only, for private use or commercial use.

The repair or replacement of parts or the performance of service under this warranty does not extend the life of this warranty beyond its original expiration date.

The warranty coverage period identified above are a minimal limited warranty period which can be extended by any applicable warranty promotional program, as the case may be.

Note that the duration and any other modalities of the warranty coverage are subject to the applicable national or local legislation in the customer's country.

FOR PRODUCTS SOLD IN AUSTRALIA ONLY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.

You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Nothing in these Warranty terms and conditions should be taken to exclude, restrict or modify the application of any condition, warranty, guarantee, right or remedy conferred or implied under the Competition and Consumer Act 2010 (Cth), including the Australian Consumer Law or any other law, where to do so would contravene that law, or cause any part of these terms and conditions to be void. The benefits given to you under this limited warranty are in addition to other rights and remedies that you have under Australian law.

## 5) CONDITIONS TO HAVE WARRANTY COVERAGE

This warranty coverage is available only if each of the following conditions has been fulfilled:

- The Product must be purchased as new and unused by its first owner from a BRP Distributor/Dealer authorized to distribute the Products in the country in which the sale occurred;
- The BRP specified pre-delivery inspection process must be completed, documented and signed by the purchaser;
- The Product must have undergone proper registration by an authorized BRP Distributor/ Dealer;
- The Product must be purchased in the country in which the purchaser resides;
- Routine maintenance outlined in the Operator’s Guide must be timely performed in order to maintain warranty coverage. BRP reserves the right to make warranty coverage contingent upon proof of proper maintenance.

BRP will not honor this limited warranty to any private use owner or commercial use owner if one of the preceding conditions has not been met. Such limitations are necessary in order to allow BRP to preserve both the safety of its products, and also that of its consumers and the general public.

## 6) WHAT TO DO TO OBTAIN WARRANTY COVERAGE

The customer must cease using the Product upon the appearance of an anomaly, notify a servicing BRP Distributor/Dealer within two (2) months of the appearance of the anomaly and provide the BRP Distributor/Dealer with reasonable access to the Product and reasonable opportunity to repair it.

The notification period is subject to the applicable national or local legislation in customer's country.

The customer must also present to the BRP Distributor/Dealer, proof of purchase of the Product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair.

All parts replaced under this limited warranty become the property of BRP.

## 7) WHAT BRP WILL DO

To the extent permitted by law, BRP’s obligations under this warranty are limited to, at its sole discretion, repairing or replacing parts found defective under normal use, maintenance and service without charge for parts and labor, at any

authorized BRP Distributor/Dealer during the warranty coverage period under the conditions described herein. BRP's responsibility is limited to making the required repairs or replacements of parts. No claim of breach of warranty shall be cause for cancellation or rescission of the sale of the Product to the owner. You may have other legal rights which may vary from country to country.

In the event that service is required outside of the country of original sale, the owner will bear responsibility for any additional charges due to local practices and conditions, such as, but not limited to, freight, insurance, taxes, license fees, import duties, and any and all other financial charges, including those levied by governments, states, territories and their respective agencies

BRP reserves the right to improve or modify products from time to time without assuming any obligation to modify products previously manufactured.

## 8) TRANSFER

If the ownership of a Product is transferred during the warranty coverage period, this limited warranty, subject to its terms and conditions, shall also be transferred and be valid for the remaining coverage period provided BRP or an authorized BRP Distributor/Dealer receives a proof that the former owner agreed to the transfer of ownership, in addition to the coordinates of the new owner.

## 9) CONSUMER ASSISTANCE

In the event of a controversy or a dispute in connection with this limited warranty, BRP suggests that you try to resolve the issue at the BRP Distributor/Dealer level. We recommend discussing the issue with the authorized BRP Distributor/Dealer's service manager or owner.

If the matter still remains unresolved, contact BRP by filling out the customer contact form at **www.brp.com** or contact BRP by mail at one of the addresses listed under the *Contact Us* section of this guide.

# BRP LIMITED WARRANTY FOR THE EUROPEAN ECONOMIC AREA, THE COMMONWEALTH OF THE INDEPENDENT STATES AND TURKEY: 2025 CAN-AM® ATV

## 1) SCOPE OF THE LIMITED WARRANTY

Bombardier Recreational Products Inc. ("**BRP**") warrants its 2025 Can-Am ATV (the "**Product**") sold by distributors or dealers authorized by BRP to distribute the Products in member states of the European Economic Area (which is comprised of the states of the European Union plus the United Kingdom, Norway, Iceland and Liechtenstein) ("**EEA**"), member states of the Commonwealth of the Independent States (including Ukraine and Turkmenistan) ("**CIS**") and Turkey (a "**BRP Distributor/Dealer**") from defects in material or workmanship for the period and under the conditions described below.

This limited warranty will become null and void if:

1. the Product was used for racing or any other competitive activity, at any point, even by a previous owner; or
2. the Product has been altered or modified in such a way so as to adversely affect its operation, performance or durability, or has been altered or modified to change its intended use.

Non-factory installed parts and accessories are not covered under this limited warranty. Please refer to the applicable parts and accessories limited warranty text.

## 2) LIMITATIONS OF LIABILITY

TO THE EXTEND PERMITTED BY LAW, THIS WARRANTY IS EXPRESSLY GIVEN AND ACCEPTED IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT THAT THEY CANNOT BE DISCLAIMED, THE IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIFE OF THE EXPRESS WARRANTY. INCIDENTAL AND CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM COVERAGE UNDER THIS WARRANTY. SOME JURISDICTIONS DO NOT ALLOW FOR THE DISCLAIMERS, LIMITATIONS AND EXCLUSIONS IDENTIFIED ABOVE. AS A RESULT, THEY MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH MAY VARY FROM JURISDICTION TO JURISDICTION. BRP SHALL NOT BE HELD LIABLE IF PRODUCTS OR WARRANTY PARTS ARE NOT AVAILABLE IN CERTAIN COUNTRIES FOR REASONS OUTSIDE OF BRP'S CONTROL.

For Products purchased in France, refer to the France-specific section below.

Neither any BRP Distributor/Dealer nor any other person has been authorized to make any affirmation, representation or warranty regarding the product, other than those contained in this limited warranty, and if made, shall not be enforceable against BRP.

BRP reserves the right to modify this limited warranty at any time, being understood that such modification will not alter the warranty conditions applicable to the Products sold while this warranty is in effect.

## 3) EXCLUSIONS – ARE NOT WARRANTED

The following are not warranted under any circumstances:

– Normal wear and tear;
– Routine maintenance items, tune ups, adjustments;
– Damage caused by negligence or failure to provide proper maintenance and/ or storage, as described in the Operator's Guide;
– Damage resulting from removal of parts, improper repairs, service, maintenance, modifications or use of parts not manufactured or approved by BRP or resulting from repairs done by a person that is not an authorized servicing BRP Distributor/ Dealer;
– Damage caused by abuse, abnormal use, neglect or operation of the Product in a manner inconsistent with the recommended operation described in the Product’s Operator’s Guide;
– Damage resulting from accident, submersion, fire, theft, vandalism or any act of God;
– Operation with fuels, oils or lubricants which are not suitable for use with the Product (see the Operator’s Guide);
– Damages from rust, corrosion or exposure to the elements;
– Damage resulting from water or snow ingestion;
– Incidental or consequential damages, or damages of any kind including without limitation transportation expenses, towing, storage, telephone, rental, taxi, inconvenience, insurance coverage, loan payments, loss of time, loss of income or time missed for downtime experience due to service work.

## 4) WARRANTY COVERAGE PERIOD

This limited warranty will be in effect from (1) the date of delivery to the first retail consumer, or (2) the date the Product is first put into use, whichever occurs first and for the applicable period below:

1. TWENTY-FOUR (24) consecutive months, for private use owners.
2. SIX (6) consecutive months, for commercial use owners.

A Product is used commercially when it is used in connection with any work or employment that generates income during any part of the warranty period. A Product is also used commercially when, at any point during the warranty period, it is licensed for commercial use.

The repair or replacement of parts or the performance of service under this warranty does not extend the life of this warranty beyond its original expiration date.

The warranty coverage period identified above are a minimal limited warranty period which can be extended by any applicable warranty promotional program, as the case may be.

Note that the duration and any other modalities of the warranty coverage are subject to the applicable national or local legislation in the customer's country.

## 5) FOR PRODUCTS SOLD IN FRANCE ONLY

The following terms and conditions are applicable to products sold in France only.

The seller shall deliver goods that are complying with the contract and shall be responsible for defects existing upon delivery. The seller shall also be responsible for defects resulting from packaging, assembling instructions or the installation when it is its responsibility per the contract or if accomplished under its responsibility. To be compliant with the contract, the good shall:

1. Be fit for normal use for goods similar thereto and, if applicable:
   - Correspond to the description provided by the seller and have the qualities presented to the buyer though sample or model;
   - Have the qualities that a buyer may legitimately expect considering the public declarations of the seller, the manufacturer of its representative, including in advertising or labeling; or
2. Have the characteristics mutually agreed upon as between the parties or be fit for the specific use intended by the buyer and brought to the attention of the seller and which were accepted by the seller.

The action for failure to comply is prescribed after two years after delivery of the goods. The seller is responsible for the warranty for hidden defects of the good sold if such hidden defects are rendering the good unfit for the intended use, or if they diminish its use in such a way that the buyer would not have acquired the good or would have given a lesser price, had he known. The action for such hidden defects shall be taken by the buyer within 2 years of the discovery of the defect.

## 6) CONDITIONS TO HAVE WARRANTY COVERAGE

This warranty coverage is available only if each of the following conditions has been fulfilled:

- The Product must be purchased as new and unused by its first owner from a BRP Distributor/Dealer authorized to distribute Products in the country or in the case of the EEA, union of countries in which the sale occurred;
- The BRP specified pre-delivery inspection process must be completed, documented and signed by the purchaser;
- The Product must have undergone proper registration by an authorized BRP Distributor/ Dealer;
- The Product must be purchased in the country or in the case of the EEA, union of countries in which the purchaser resides;
- Routine maintenance outlined in the Operator’s Guide must be timely performed in order to maintain warranty coverage. BRP reserves the right to make warranty coverage contingent upon proof of proper maintenance.

BRP will not honor this limited warranty to any private use owner or commercial use owner if one of the preceding conditions has not been met. Such limitations are necessary in order to allow BRP to preserve both the safety of its products, and also that of its consumers and the general public.

## 7) WHAT TO DO TO OBTAIN WARRANTY COVERAGE

The customer must cease using the Product upon the appearance of an anomaly, notify a servicing BRP Distributor/Dealer within two (2) months of the appearance of the anomaly and provide the BRP Distributor/Dealer with reasonable access to the Product and reasonable opportunity to repair it.

The notification period is subject to the applicable national or local legislation in customer's country.

The customer must also present to the BRP Distributor/Dealer, proof of purchase of the Product and must sign the repair/work order prior to starting the repair in order to validate the warranty repair.

All parts replaced under this limited warranty become the property of BRP.

## 8) WHAT BRP WILL DO

To the extent permitted by law, BRP's obligations under this warranty are limited to, at its sole discretion, repairing or replacing parts found defective under normal use, maintenance and service without charge for parts and labor, at any authorized BRP Distributor/Dealer during the warranty coverage period under the conditions described herein. No claim of breach of warranty shall be cause for cancellation or rescission of the sale of the Product to the owner. You may have other legal rights which may vary from country to country.

In the event that service is required outside of the country of original sale, or for EEA residents if service is required outside of the EEA, the owner will bear responsibility for any additional charges due to local practices and conditions, such as, but not limited to, freight, insurance, taxes, license fees, import duties, and any and all other financial charges, including those levied by governments, states, territories and their respective agencies.

BRP reserves the right to improve or modify products from time to time without assuming any obligation to modify products previously manufactured.

## 9) TRANSFER

If the ownership of a Product is transferred during the warranty coverage period, this limited warranty, subject to its terms and conditions, shall also be transferred and be valid for the remaining coverage period provided BRP or an authorized BRP Distributor/Dealer receives a proof that the former owner agreed to the transfer of ownership, in addition to the coordinates of the new owner.

## 10) CONSUMER ASSISTANCE

In the event of a controversy or a dispute in connection with this limited warranty, BRP suggests that you try to resolve the issue at the BRP Distributor/Dealer level. We recommend discussing the issue with the authorized BRP Distributor/Dealer's service manager or owner.

If the matter still remains unresolved, contact BRP by filling out the customer contact form at **www.brp.com** or contact BRP by mail at one of the addresses listed under the *Contact Us* section of this guide.

# CUSTOMER INFORMATION

# DATA PRIVACY INFORMATION

## DATA PRIVACY INFORMATION

Bombardier Recreational Products Inc., its affiliates and subsidiaries (“BRP”) is committed to protecting your privacy. This notice is to inform you about how we collect, use and disclose your personal information in the course of managing our relationship with you. More details can be found by visiting the BRP’s Privacy Policy website.

*HTTPS://BRP.COM/EN/ PRIVACY-POLICY.HTML*

Please be assured that we have appropriate measures in place to ensure that your personal information is kept secured and protected against unauthorized access, use or disclosure.

The personal information we hold about you is collected either directly from you or through our authorized dealers and third parties (e.g. with whom we offer services or engage in joint-marketing activities), and includes:

- Contact, Demographic & Registration Information (e.g., name, full address, phone number, email, ownership history, language of communication)
- Transactional Information (e.g., information necessary to handle returns, payment information when you purchase our products or services through our websites or mobile applications and other issues related to your purchase of BRP products).
- Vehicle Information (e.g., serial number, vehicle identification number, mileage, purchase and delivery date, unit usage, vehicle location and movements)
- Your comments, opinions and reviews of our products and services
- Information collected automatically when you navigate on BRP or dealer’s websites or mobile apps collected via cookies and similar technologies (e.g., IP address, type of device, operating system, browser type, webpages you view).

We may also receive information about you from social media platforms when you interact with us on those platforms.

We use your personal information for various reasons, mostly to:

- Manage your order of BRP products and services (e.g., to complete or deliver your order, or service your BRP product)
- Provide customer support, assistance, and after-sales (e.g., complete or follow up with you about your order or maintenance, help with any delivery issues, handle returns, and other issues related to your purchase of BRP products)
- Manage your BRP products registration, warranty, security, safety recall, and dispute resolution (e.g. to offer warranty and after-sales service to you, protect your security and safety, perform safety recalls)
- Send you commercial communications about our products and services (e.g. inform you about new BRP products, services or features; share news about contests, promotions, and events or discuss products or services offered by BRP that may be of interest to you)

- Offer you personalized experience, content, or offers and services based on profiling or geolocation technologies (e.g. to notify you when your vehicle may need servicing, to locate your nearest dealership)
- Perform data analytics and statistics data that no longer identifies you personally, for business intelligence and have insights on how to improve our products and services
- Prevent, detect, and control fraud and any unauthorized or illegal activities (e.g., to detect and control fraud in relation to BRP products or services purchase; manage illegal or unauthorized activities and cyberthreats)
- Comply with applicable laws and regulations.

Your personal information may be disclosed to the following: BRP, BRP's authorized dealerships, distributors, service providers, advertising & market research partners and other authorized third parties.

Depending on the circumstances, your personal information may be communicated outside the region where you reside. Your personal information is retained only for as long as necessary for the purpose for which we obtained it and according to our retention policies.

To exercise your data privacy rights (e.g. right of access, right of rectification), to withdraw your consent in order to be removed from the address list for marketing purposes or for the satisfaction survey or for general data privacy questions, please contact BRP's Data Protection Officer at or by mail at privacyofficer@brp.com or by mail at: BRP Legal Service, 726 St-Joseph, Valcourt, Quebec, Canada, J0E 2L0.

**When BRP processes your personal information, they do so in compliance with its Privacy Policy available at:**

*HTTPS://BRP.COM/EN/PRIVACY-POLICY.HTML*

# CONTACT US

***www.brp.com***

## Asia Pacific

**BRP Asia**
107D and 107E, 17/F, Tower 1,
Grand Century Place, Mongkok,
Kowloon, Hong Kong

**Australia**
Level 26
477 Pitt Street
Sydney, NSW 2020

**China**
上海市徐汇区衡山路10号6号楼301
Rm 301, Building 6,
No.10 Heng Shan Rd,
Shanghai, China

**Japan**
21F Shinagawa East One Tower
2–16–1 Konan, Minato-ku-ku,
Tokyo 108–0075

## Europe, Middle East and Africa

**Belgium**
Oktrooiplein 1
9000 Gent

**Czech Republic**
Stefanikova 43a
Prague 5
150 00

**Germany**
Alte Papierfabrik 16
D-40699 Erkrath

**Finland**
Isoaavantie 7
PL 8040
96101 Rovaniemi

**France**
Arteparc Bâtiment B
Route de la côte d'Azur, Le Canet
13 590 Meyreuil

**Norway**
Ingvald Ystgaards veg 15

N-7484 Trondheim

**Sweden**
Spinnvägen 15
903 61 Umeå

**Switzerland**
Avenue d'Ouchy 4-6
1006 Lausanne

## Latin America

**Brazil**
Rua Odila Maia Rocha Brito, 25
Edificio Beaumont, andar 1 ao 5
CEP 13092-110 Campinas -SP

**Mexico**
Av. Ferrocarril 202
Parque Industrial Querétaro
Santo Rosa Jauregui, Querétaro
C.P. 76220

## North America

**Canada**
3200A, rue King Ouest,
Suite 300
Sherbrooke (Québec) J1L 1C9

**United States of America**
10101 Science Drive
Sturtevant, Wisconsin
53177

# CHANGE OF ADDRESS AND OWNERSHIP

If your address has changed or if you are the new owner of the vehicle, be sure to notify BRP by either:

– Notifying an authorized Can-Am dealer.
– **North America Only:** calling at 1 888 272-9222.
– Mailing one of the change of address cards on the following pages at one of the BRP addresses indicated in the *Contact Us* section of this guide.

In case of change of ownership, please join a proof that the former owner agreed to the transfer.

Notifying BRP, even after the expiration of the limited warranty, is very important as it enables BRP to reach the vehicle owner if necessary, like when safety recalls are initiated. It is the owner's responsibility to notify BRP.

**STOLEN UNITS:** If your personal vehicle is stolen, you should notify BRP or an authorized Can-Am dealer. We will ask you to provide your name, address, phone number, the vehicle identification number and the date it was stolen.

CHANGE OF ADDRESS ❑ CHANGE OF OWNERSHIP ❑

VEHICLE IDENTIFICATION NUMBER

Model Number Vehicle Identification Number (V.I.N.)

OLD ADDRESS OR PREVIOUS OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

NEW ADDRESS OR NEW OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

E-MAIL ADDRESS

CHANGE OF ADDRESS ❑ CHANGE OF OWNERSHIP ❑

VEHICLE IDENTIFICATION NUMBER

Model Number Vehicle Identification Number (V.I.N.)

OLD ADDRESS OR PREVIOUS OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

NEW ADDRESS OR NEW OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

E-MAIL ADDRESS

This page is intentionally blank

CHANGE OF ADDRESS ❑ CHANGE OF OWNERSHIP ❑

VEHICLE IDENTIFICATION NUMBER

Model Number Vehicle Identification Number (V.I.N.)

OLD ADDRESS OR PREVIOUS OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

NEW ADDRESS OR NEW OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

E-MAIL ADDRESS

CHANGE OF ADDRESS ❑ CHANGE OF OWNERSHIP ❑

VEHICLE IDENTIFICATION NUMBER

Model Number Vehicle Identification Number (V.I.N.)

OLD ADDRESS OR PREVIOUS OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

NEW ADDRESS OR NEW OWNER:

NAME

NO. STREET APT

CITY STATE/PROVINCE ZIP/POSTAL CODE

COUNTRY TELEPHONE

E-MAIL ADDRESS

This page is intentionally blank

NOTE:

NOTE:

NOTE:

NOTE:

NOTE:

NOTE:

NOTE:

NOTE:

NOTE:

NOTE:

Model No. _____

**VEHICLE**
IDENTIFICATION NUMBER (V.I.N.) _____

**ENGINE**
IDENTIFICATION NUMBER (E.I.N.) _____

**Owner:** _____
NAME

_____
No. STREET APT

_____
CITY STATE/PROVINCE ZIP/POSTAL CODE

**Purchase Date** _____ | _____ | _____ | _____ | _____
YEAR MONTH DAY

**Warranty Expiry Date** _____ | _____ | _____ | _____ | _____
YEAR MONTH DAY

To be completed by the dealer at the time of the sale.

DEALER IMPRINT AREA

This page is intentionally blank

## ⚠ WARNING

THIS VEHICLE CAN BE HAZARDOUS TO OPERATE. A collision or rollover can occur quickly, even during routine maneuvers such as turning and driving on hills or over obstacles, if you fail to take proper precautions.

SEVERE INJURY OR DEATH
can result if you do not follow these instructions:

- BEFORE YOU OPERATE THIS VEHICLE, READ THIS OPERATOR'S GUIDE, ALL ON PRODUCT SAFETY LABELS AND WATCH THE SAFETY VIDEO.
- NEVER OPERATE THIS VEHICLE WITHOUT PROPER INSTRUCTIONS.
  Complete a certified training course.
- FOR MAX MODELS, NEVER CARRY MORE THAN ONE PASSENGER. You increase your risk of losing control if you carry more than one passenger.
- FOR 1UP MODELS, NEVER CARRY A PASSENGER. You increase your risk of losing control if you carry a passenger.
- ALWAYS RESPECT THE ROAD TRAFFIC LAWS when you operate the vehicle on the roadway, even a dirt or gravel road.
- OPERATOR AND PASSENGER (MAX models) SHOULD ALWAYS WEAR AN APPROVED HELMET, eye protection, and protective clothing.
- NEVER USE WITH DRUGS OR ALCOHOL. They slow reaction time and impair judgment.
- NEVER OPERATE THIS VEHICLE AT EXCESSIVE SPEEDS.
  You increase your risk of losing control if you operate this vehicle at speeds too fast for the terrain, visibility conditions, or your experience.
- NEVER ATTEMPT WHEELIES, JUMPS, OR OTHER STUNTS.

®TM and the BRP logo are trademarks of BOMBARDIER RECREATIONAL PRODUCTS INC. or its affiliates.
©2024 BOMBARDIER RECREATIONAL PRODUCTS INC. ALL RIGHTS RESERVED.

www.brp.com

**ALUMACRAFT®** **CAN-AM®** **LYNX®**
**MANITOU®** **QUINTREX®** **ROTAX®**
**SEA-DOO®** **SKI-DOO®**

219002435_REV1