


# **ERRATA**

1992 Formula Operator's Guide

Concerning Formula MX XTC/R Only

# PAGE 13

The illustration should show as follows:




## PAGE 18

V paragraph should read as follows:

#### V) Gear Shift Lever (models with reverse gear only)

With machine fully stopped and engine at idle, turn lever right or left to engage foward or reverse gear.

Do not force into reverse. If not able to shift to reverse, apply throttle to move vehicle and try again.



CAUTION: Bring vehicle to complete stop before changing gear.


WARNING: This snowmobile is capable of a fast reverse. On first outing, operator should become familiar with this operation by practicing on level ground. Ensure the path behind is clear of obstacles or bystanders. Fast reverse, while turning, could result in loss of stability.

WARNING: Before starting engine, check that lever is in foward position.

## PAGE 34

Replace Chaincase Oil Level paragraph by: Gearbox Oil Level.


With vehicle on a level surface, check the oil level by removing dipstick. With dipstick unscrewed, oil level must be at lower mark. Refill as required using BOMBARDIER synthetic chaincase oil (P/N 413 8026 00 - 250 mL (9 oz)).



NOTE: The gearbox oil capacity is approximately 400 mL (13.5 oz).

### Gear Shift Lever

Oil moving parts once a year.



## PAGE 52

#### Gearbox (instead of Chaincase).

See an authorized dealer for draining.

NOTE: The gearbox oil capacity is approximately 400 mL (13.5 oz).

# PAGE 63

Gearbox oil: 400 mL (13.5 oz) instead of 200 mL (7 oz).